

REPAIR MANUAL 2009



690 Enduro EU

690 Enduro AUS/UK

690 Enduro R EU

690 Enduro R AUS/UK

690 Enduro R USA

Article no. 3206076en



Read this repair manual carefully and thoroughly before beginning work.

Only use **ORIGINAL KTM SPARE PARTS**.

The vehicle will only be able to meet the demands placed on it if the specified service work is performed regularly and properly.

This repair manual was written to correspond to the latest state of this series. We reserve the right to make changes in the interest of technical advancement without at the same time updating this manual.

We shall not provide a description of general workshop methods. Likewise, safety rules that apply in a workshop are not specified here. It is assumed that the repair work will be performed by a fully trained mechanic.

All specifications are non-binding. KTM Sportmotorcycle AG specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2010 KTM-Sportmotorcycle AG, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

According to the international quality management standard ISO 9001, KTM uses quality assurance processes that lead to the maximum possible quality of the products.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

KTM-Sportmotorcycle AG
5230 Mattighofen, Austria









MEANS OF REPRESENTATION	5	Disassembling the piston rod	48
IMPORTANT NOTES	6	Checking the damper	49
LOCATION OF SERIAL NUMBERS	7	Removing the heim joint	50
Chassis number/type label (690 Enduro, 690 Enduro R EU, 690 Enduro R AUS/UK)	7	Installing the heim joint	51
Chassis number/type label (690 Enduro R USA)	7	Assembling the piston rod	52
Key number	7	Assembling the damper	53
Engine number	7	Bleeding and filling the damper	55
Fork part number	8	Filling the damper with nitrogen	57
Shock absorber part number	8	Installing the spring	58
MOTORCYCLE	9	05/EXHAUST	59
Raising the motorcycle with the lift stand	9	Removing the exhaust manifold	59
Removing the motorcycle from the lift stand	9	Installing exhaust manifold	59
Raising the motorcycle with the work stand	9	Removing the main silencer	60
Removing the motorcycle from the work stand	10	Installing the main silencer	61
Starting	10	06/AIR FILTER	63
Starting the motorcycle to make checks	11	Removing the air filter	63
01/FORK, TRIPLE CLAMP	12	Installing the air filter	63
Adjusting the compression damping of the fork	12	Removing the air filter box	63
Adjusting the rebound damping of the fork	12	Installing the air filter box	64
Bleeding the fork legs	13	07/FUEL TANK, SEAT, TRIM	66
Cleaning the dust boots of the fork legs	13	Opening filler cap	66
Loosening the fork protection	14	Closing filler cap	66
Positioning the fork protection	14	Removing the seat	66
Removing fork legs	15	Mounting the seat	66
Installing the fork legs	16	Taking off the side cover	67
Servicing the fork	17	Mounting the side cover	67
Disassembling the fork legs	18	Checking the fuel pressure	67
Disassembling the cartridge	20	Changing the fuel filter	68
Disassembling the tap compression	22	09/FRONT WHEEL	72
Checking the fork legs (690 Enduro)	23	Removing the front wheel	72
Checking the fork legs (690 Enduro R)	24	Installing the front wheel	72
Assembling the tap compression	25	Checking the tire air pressure	73
Assembling the cartridge	26	Checking the tire condition	73
Assembling the fork legs (690 Enduro)	27	Checking the brake discs	74
Assembling the fork legs (690 Enduro R)	31	10/REAR WHEEL	75
Checking the steering head bearing play	35	Removing rear wheel	75
Adjusting the play of the steering head bearing	35	Installing the rear wheel	75
02/HANDLEBAR, INSTRUMENTS	37	Checking the chain tension	76
Handlebar position	37	Adjusting the chain tension	76
Adjusting handlebar position	37	Adjusting chain guide	77
Checking the play in the throttle cable	37	Checking the chain, rear sprocket and engine sprocket	77
Adjusting the play in the throttle cable	38	Cleaning the chain	78
03/FRAME	39	Checking the rear hub rubber dampers	79
Removing the engine guard	39	Checking the spoke tension	79
Installing the engine guard	39	Checking the rim run-out	80
04/SHOCK ABSORBER, SWINGARM	40	11/WIRING HARNESS, BATTERY	81
Adjusting the high-speed compression damping of the shock absorber	40	Removing the battery	81
Adjusting the low-speed compression damping of the shock absorber	40	Installing the battery	81
Adjusting the rebound damping of the shock absorber	41	Disconnecting the battery	81
Measuring the unloaded rear wheel sag	42	Connecting the battery	82
Checking the static sag of the shock absorber	42	Recharging the battery	82
Checking the riding sag of the shock absorber	42	Checking the charging voltage	83
Adjusting the spring preload of the shock absorber	43	Changing the main fuse	83
Adjusting the riding sag	43	Changing fuses of individual power consumers	84
Removing the shock absorber	44	Adjusting the engine characteristic	85
Installing the shock absorber	45	13/BRAKE SYSTEM	86
Servicing the shock absorber	46	Checking the front brake linings	86
Removing the spring	46	Changing the front brake linings	86
Dismantling the damper	47	Checking the free travel of the hand brake lever	88
		Adjusting the free travel of the hand brake lever	88
		Checking the front brake fluid level	88

Adding front brake fluid	89	Work on the clutch cover	124
Changing the front brake fluid	89	Removing crankshaft bearing inner ring	125
Checking the rear brake linings	90	Removing balancer shaft drive wheel	125
Changing rear brake linings	91	Changing the conrod bearing	125
Checking the free travel of foot brake lever	92	Checking crankshaft run-out at bearing pin	127
Adjusting the basic position of the foot brake lever	92	Installing balancer shaft drive wheel	127
Checking rear brake fluid level	93	Installing crankshaft bearing inner ring	127
Adding rear brake fluid	93	Measuring axial clearance of crankshaft and balancer shaft	128
Changing the rear brake fluid	94	Cylinder - Nikasil® coating	128
14/LIGHT SYSTEM, INSTRUMENTS	96	Checking/measuring the cylinder	129
Setting kilometers or miles	96	Checking/measuring the piston	129
Setting the clock	96	Checking piston ring end gap	130
Combination instrument - setting/resetting TRIP 1	97	Checking piston/cylinder mounting clearance	131
Combination instrument - setting/resetting TRIP 2	97	Checking oil pumps for wear	131
Combination instrument - setting the wheel circumference (690 Enduro)	98	Replacing autodecompressor	131
Checking the headlight setting	98	Preparing timing chain tensioner for installation	132
Adjusting the headlight range	99	Checking timing assembly	133
Removing the headlight mask with the headlight	99	Removing rocker arm	133
Installing the headlight mask with the headlight	100	Changing camshaft bearing	133
Changing the parking light bulb	101	Removing valves	134
Changing the headlight bulb	102	Checking valves	135
Changing the turn signal bulb	103	Checking valve springs	135
30/ENGINE	104	Checking valve spring retainer	135
Removing the engine	104	Checking cylinder head	135
Installing the engine	106	Installing valves	136
30/DISASSEMBLING THE ENGINE	110	Installing rocker arm	137
Clamping engine into engine work stand	110	Dismantling antihopping clutch	137
Draining the engine oil	110	Checking the clutch	138
Removing starter motor	110	Preassembling antihopping clutch	139
Removing valve cover	110	Checking shift mechanism	140
Removing the alternator cover	111	Preassembling shift shaft	140
Removing spacer	111	Disassembling the main shaft	141
Removing gear position sensor	111	Dismantling countershaft	142
Removing oil filter	111	Checking the transmission	143
Removing thermostat	112	Assembling the main shaft	145
Setting engine to ignition top dead center	112	Assembling countershaft	146
Removing water pump wheel	112	Checking electric starter drive	147
Removing clutch cover	113	Removing freewheel	148
Removing spacer and spring	113	Checking freewheel	148
Removing spark plug	113	Installing freewheel	149
Removing timing chain tensioner	114	30/ASSEMBLING THE ENGINE	150
Removing camshafts	114	Installing transmission shafts	150
Removing cylinder head	114	Installing crankshaft and balancer shaft	151
Removing piston	114	Installing left engine case	151
Removing rotor	115	Installing oil pumps	152
Removing timing chain rails	115	Installing locking lever	152
Removing timing chain and timing chain sprocket	116	Installing shift drum locating	152
Removing crankshaft position sensor	116	Installing shift shaft	153
Removing clutch cage	116	Installing starter drive	153
Removing primary gear	118	Installing primary gear	153
Removing starter drive	118	Installing clutch cage	154
Removing shift shaft	118	Installing crankshaft position sensor	155
Removing shift drum locating	118	Installing timing chain and timing chain sprocket	155
Removing locking lever	119	Installing timing chain rails	156
Removing oil pumps	119	Installing rotor	156
Removing left engine case	119	Adjusting crankshaft position sensor distance	156
Removing crankshaft and balancer shaft	120	Setting engine to top dead center	157
Removing transmission shafts	120	Installing piston	157
30/ENGINE - WORK ON INDIVIDUAL PARTS	122	Installing cylinder head	158
Work on the right section of the engine case	122	Installing camshafts	159
Work on the left section of the engine case	123	Installing timing chain tensioner	159

Checking valve clearance	160	CLEANING/PROTECTIVE TREATMENT	198
Adjusting valve clearance	160	Cleaning the motorcycle	198
Installing spark plug	161	Protective treatment for winter operation	199
Installing spacer and spring	161	STORAGE	200
Installing clutch cover	161	Storage	200
Mounting water pump cover	162	Putting into operation after storage	200
Installing thermostat	162	SERVICE SCHEDULE	201
Installing the oil filter	162	Service schedule	201
Installing gear position sensor	163	WIRING DIAGRAM	202
Installing the spacer	163	Page 1 of 10 (690 Enduro)	202
Installing oil screens	164	Page 2 of 10 (690 Enduro)	204
Installing alternator cover	164	Page 3 of 10 (690 Enduro)	206
Installing starter motor	165	Page 4 of 10 (690 Enduro)	208
Installing valve cover	165	Page 5 of 10 (690 Enduro)	210
Taking engine off universal mounting rack	165	Page 6 of 10 (690 Enduro)	212
32/CLUTCH	166	Page 7 of 10 (690 Enduro)	214
Checking/rectifying the fluid level of the hydraulic clutch	166	Page 8 of 10 (690 Enduro)	216
35/WATER PUMP, COOLING SYSTEM	167	Page 9 of 10 (690 Enduro)	218
Draining the coolant	167	Page 10 of 10 (690 Enduro)	220
Filling the cooling system	167	Page 1 of 10 (690 Enduro R)	222
Checking the antifreeze and coolant level	168	Page 2 of 10 (690 Enduro R)	224
Checking the coolant level	169	Page 3 of 10 (690 Enduro R)	226
38/LUBRICATION SYSTEM	170	Page 4 of 10 (690 Enduro R)	228
Oil circuit	170	Page 5 of 10 (690 Enduro R)	230
Checking the engine oil level	170	Page 6 of 10 (690 Enduro R)	232
Checking the engine oil pressure	171	Page 7 of 10 (690 Enduro R)	234
Changing the engine oil and filter, cleaning the oil screens	172	Page 8 of 10 (690 Enduro R)	236
Draining the engine oil	172	Page 9 of 10 (690 Enduro R)	238
Removing the oil filter	173	Page 10 of 10 (690 Enduro R)	240
Installing the oil filter	173	SUBSTANCES	242
Cleaning the oil screens	174	AUXILIARY SUBSTANCES	244
Filling up with engine oil	175	SPECIAL TOOLS	246
Adding engine oil	175	STANDARDS	258
39/IGNITION SYSTEM	176	INDEX	259
Alternator - checking the stator winding	176		
Checking the spark plug connector	176		
Ignition coil - checking the secondary winding	177		
41/THROTTLE VALVE BODY	178		
Checking the basic setting of the motor drive	178		
Adjusting the basic setting of the motor drive	179		
Flashing the EFI control unit and/or the EPT control unit	182		
Requesting the enabling code	183		
Coding the EFI control unit and/or EPT control unit	184		
TECHNICAL DATA - ENGINE	186		
Capacity - engine oil	186		
Capacity - coolant	186		
TECHNICAL DATA - TOLERANCE, WEAR LIMITS OF ENGINE	187		
TECHNICAL DATA - ENGINE TIGHTENING TORQUES	189		
TECHNICAL DATA - CHASSIS	191		
Lighting equipment	192		
Capacity - fuel	192		
TECHNICAL DATA - FORK	193		
690 Enduro	193		
690 Enduro R	193		
TECHNICAL DATA - SHOCK ABSORBER	194		
690 Enduro	194		
690 Enduro R	194		
TECHNICAL DATA - CHASSIS TIGHTENING TORQUES	196		

Symbols used

The symbols used are explained in the following.

	Indicates an expected reaction (e.g. of a work step or a function).
	Indicates an unexpected reaction (e.g. of a work step or a function).
	Identifies a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
	Indicates the result of a testing step.
	Identifies a voltage measurement.
	Identifies a current measurement.
	Identifies a resistance measurement.

Formats used

The typographical and other formats used are explained below.

Specific name	Indicates a proprietary name.
Name[®]	Identifies a protected name.
Brand[™]	Identifies a trademark.

Warranty

The work prescribed in the service plan must only be carried out in an authorized KTM workshop and confirmed in the service record; otherwise all warranty claims will be disregarded. No warranty claim can be met for damage resulting from manipulation and/or other changes to the vehicle.

Fuel, oils, etc.

You should use the fuels, oils and greases according to specifications as listed in the repair manual.

Spare parts, accessories

Only use spare parts and accessories approved and/or recommended by KTM. KTM accepts no liability for other products and any resulting damage.

You will find the current **KTM PowerParts** for your vehicle on the KTM website.

International KTM Website: <http://www.ktm.com>

Work rules

Special tools are necessary for certain tasks. The tools are not contained in the vehicle but can be ordered under the number in parentheses. Example: valve spring mounter (59029019000)

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

If a thread lock (e.g. **Loctite**®) is used for screw connections, be sure to comply with the manufacturer's specific instructions on its usage.

Parts that you want to reuse following repairs and servicing should be cleaned and checked for damage and wear. Change damaged or worn parts.

Following repairs or servicing, the vehicle must be checked for roadworthiness.

Notes/warnings

Pay close attention to the notes/warnings.



Info

Various information and warning labels are affixed to the vehicle. Do not remove information/warning labels. If they are missing, you or others may not recognize potential hazards and may therefore be injured.

Grades of risks



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.




Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

Repair manual


- Read this repair manual carefully and thoroughly before beginning work. It contains useful information and tips that will help you repair and service your motorcycle.
- This manual assumes that the necessary special KTM tools and workplace and workshop equipment are available.

Chassis number/type label (690 Enduro, 690 Enduro R EU, 690 Enduro R AUS/UK)




The chassis number ❶ is stamped on the right of the steering head.
The type label ❷ is on the right of the frame behind the steering head.

Chassis number/type label (690 Enduro R USA)



The chassis number ❶ is stamped on the right of the steering head.
The USA type label ❷ is on the right of the frame behind the steering head.



The Canada type label ❸ is on the right of the frame behind the steering head.

Key number




The key number ❶ can be found on the **KEYCODECARD**.



Info


You need the key number to order a spare key. Keep the **KEYCODECARD** in a safe place.

Engine number




The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

Fork part number



The fork part number ❶ is stamped on the inner side of the fork stub.

Shock absorber part number



The shock absorber part number ❶ is on the right of the shock absorber.

Raising the motorcycle with the lift stand

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



(690 Enduro)

- Raise the motorcycle using the underride guard under the motorcycle.
- ✓ The wheels must no longer touch the ground.
- Secure the motorcycle against falling over.



(690 Enduro R)

- Raise the motorcycle using the underride guard under the motorcycle.
- ✓ The wheels must no longer touch the ground.
- Secure the motorcycle against falling over.

Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Remove the motorcycle from the lift stand and rest it on its side stand.
- Remove the lift stand.

Raising the motorcycle with the work stand

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Mount the special tool on the footrest.

Work stand adapter (75029036000) (➔ p. 250)



- Position the motorcycle upright, align the special tool and raise the motorcycle.


Work stand (62529055000) (➔ p. 249)

Removing the motorcycle from the work stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Secure the motorcycle against falling over.
- Remove the work stand and lean the vehicle on the side stand.



- Remove the special tool.

Starting



Danger

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.



Caution


Danger of accidents If the vehicle is operated with a discharged battery or without a battery, electronic components and safety equipment may be damaged.

- Never operate the vehicle with a discharged battery or without a battery.


Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



- Turn the emergency OFF switch to the position ○.
- Switch on the ignition by turning the ignition key to position **ON** ○.
- ✓ After you switch on the ignition, you can hear the fuel pump working for about 2 seconds. At the same time, the function test of the combination instrument is run.
- Shift gear to neutral.
- ✓ The green idling speed indicator lamp **N** lights up.
- Press the electric starter button ③.

 **Info**

Do not press the electric starter button until the function test of the combination instrument is finished.


When starting, **DO NOT** open the throttle. If you open the throttle during the starting procedure, fuel is not injected by the engine management system and the engine cannot start.

Press the starter for a maximum of 5 seconds. Wait for at least 5 seconds before trying again.

This motorcycle is equipped with a safety start system. You can only start the engine if the gearbox is in neutral or if the clutch is pulled when a gear is engaged. If the side stand is folded out and you shift into gear and release the clutch, the engine stops.


- Take the weight off the side stand and swing it back up with your foot as far as it will go.

Starting the motorcycle to make checks


 **Danger**

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

 **Info**

Press the starter for a maximum of 5 seconds. Wait for a least 5 seconds before trying again.



- Turn the emergency OFF switch to the position ○.
- Shift gear to neutral.
- Switch on the ignition.
- Press the electric starter button ③.

 **Info**


Do not open the throttle.

Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



- Remove protection covers ❶.
- Turn adjusting screws ❷ clockwise until they stop.



Info

The adjusting screws are located at the bottom end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

(690 Enduro)

Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

(690 Enduro R)

Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

- Mount protection covers ❶.

Adjusting the rebound damping of the fork



Info

The hydraulic rebound damping determines the fork rebound behavior.



(690 Enduro)

- Turn adjusting screws ❶ clockwise until they stop.



Info

The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

**(690 Enduro R)**

- Turn adjusting screws ❶ clockwise until they stop.

**Info**

The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.


- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

**Info**

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

Bleeding the fork legs


- Lean the motorcycle on the side stand.

(690 Enduro)

- Remove bleeder screws ❶ briefly.
✓ Any excess pressure escapes from the interior of the fork.
- Mount and tighten bleeder screws.

**Info**

Carry out this action on both fork legs.

**(690 Enduro R)**

- Remove bleeder screws ❶ briefly.
✓ Any excess pressure escapes from the interior of the fork.
- Mount and tighten bleeder screws.

**Info**

Carry out this action on both fork legs.

Cleaning the dust boots of the fork legs

- Raise the motorcycle with the lift stand. (🔧 p. 9)
- Loosen the fork protection. (🔧 p. 14)
- Push dust boot ❶ of both fork legs downwards.

**Info**

The dust boots should remove dust and coarse dirt particles from the fork tubes. Over time, dirt can penetrate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tube of both fork legs.

Universal oil spray (🔧 p. 245)


- Press the dust boots back into their normal position.
- Remove excess oil.
- Position the fork protection. (🔧 p. 14)
- Remove the motorcycle from the lift stand. (🔧 p. 9)

Loosening the fork protection



(690 Enduro)


- Remove screws ❶ and take off clamp.
- Remove screws ❷ on left fork leg. Push the fork protection downwards.
- Remove the screws on the right fork leg. Push the fork protection downwards.



(690 Enduro R)

- Remove screws ❶ and take off clamp.
- Remove screws ❷ on left fork leg. Push the fork protection downwards.
- Remove the screws on the right fork leg. Push the fork protection downwards.

Positioning the fork protection



(690 Enduro)


- Position the fork protection on the left fork leg. Mount and tighten screws ❶.
- Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

- Position the brake line and wiring harness. Put the clamp on, mount and tighten screws ❷.
- Position the fork protection on the right fork leg. Mount and tighten the screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------



(690 Enduro R)

- Position the fork protection on the left fork leg. Mount and tighten screws ❶.
- Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

- Position the brake line and wiring harness. Put the clamp on, mount and tighten screws ❷.
- Position the fork protection on the right fork leg. Mount and tighten the screws.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

Removing fork legs




201332-10

- Raise the motorcycle with the lift stand. (☛ p. 9)
- Tie the rear of the vehicle down.
- Remove screws ①.
- Press back the brake linings with a light lateral tilting of the brake caliper on the brake disc. Carefully pull the brake caliper backwards from the brake disc.



Info

Do not pull the handbrake lever when the brake caliper is removed.



201333-10


- Loosen screws ② and screw ③.
- Unscrew screw ③ about 6 turns and press your hand on the screw to push the wheel spindle out of the axle clamp. Remove screw ③.



Warning


Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- Always lay the wheel down in such a way that the brake disc is not damaged.




201334-10

- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.
- Remove screws ④. Take the brake line and wiring harness out of the clamp.




201335-10

- Remove the screws of the wheel speed sensor ⑤. Hang the wheel speed sensor to one side.




201336-10

- Loosen screws ⑥ of the triple clamp on both sides. Remove the fork legs from the bottom.



- Remove screws 7. Remove the fork protector from above.


Installing the fork legs



- Slide on the fork protector from above and position it. Mount and tighten screws 1.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Slide the fork legs into the triple clamps on both sides.



Info

The bleeder screws must face forwards.


The topmost milled groove in the fork leg must be flush with the top edge of the upper triple clamp.

The upper fork projection must be the same on both sides.

- Tighten screws 2 on both sides.

Guideline


Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)




- Position the wheel speed sensor. Mount and tighten screws 3.

Guideline

Screw, wheel speed sensor	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
---------------------------	----	-------------------	---------------



- Position the brake line, wiring harness and clamp.
- Mount and tighten screws 4.

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean screw 5 and the wheel spindle.
- Lift the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw 5.

Guideline


Screw, front wheel spindle	M24x1.5	40 Nm (29.5 lbf ft)
----------------------------	---------	------------------------

- Position the brake caliper and check that the brake linings are seated correctly.
- Mount and tighten screws 6.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
----------------------------	----	------------------------	---------------

- Unload the rear of the vehicle.
- Remove the motorcycle from the lift stand. (🔧 p. 9)




- Pull the front brake and compress the fork powerfully a few times.

✓ The fork legs straighten.

- Tighten screws 7.


Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	------------------------

**Servicing the fork****Condition**

The fork legs have been removed.

- Disassemble the fork legs. (🔧 p. 18)
- Disassemble the cartridge. (🔧 p. 20)
- Disassemble the tap compression. (🔧 p. 22)
- Check the fork legs. (🔧 p. 23)
- Assemble the tap compression. (🔧 p. 25)
- Assemble the cartridge. (🔧 p. 26)
- Assemble the fork legs. (🔧 p. 27)




Disassembling the fork legs



Info


These operations are the same on both fork legs.



Condition

The fork legs have been removed.

- Remove protection cap **A**.
- Note down the current state of the rebound **1** and compression damping **2**.
- Completely open the adjusters of the rebound and compression damping.



- Clamp the fork leg in the area of the lower triple clamp.

Clamping stand (T1403S) (☞ p. 257)



- Loosen the screw cover **3**.



Info

The screw cover cannot be removed yet.




- Release the fork leg and clamp it with the fork stub.



Info

Use soft jaws.




- Push the outer tube downward.
- Pull the spring downward. Mount the special tool on the hexagon.

Open-end wrench (T14032) (☞ p. 256)




Info


The preload spacers **4** should be above the special tool.



- Clamp the special tool in the vise. Loosen the screw cover ③.



- Remove screw cover ③ with preload spacers ④.
- Remove the adjusting tube ⑤.



- Pull the spring downward. Remove the special tool.
- Remove the spring.




- Empty the fork oil.



Info

Pull out and push in the piston rod a few times to empty the cartridge.



- Clamp the fork leg with the fork stub.
- Loosen and remove the tap compression ⑥.




Info


Place a container underneath to catch any oil that may run out.



- Remove the cartridge.



- Remove dust boot 7.




- Remove lock ring 8.



Info

The lock ring has a beveled end where a screwdriver can be applied.



- Heat up the outer tube in area B of the lower sliding bushings.

Guideline

50 °C (122 °F)

- Pull the outer tube from the inner tube with a jerk.



Info

The lower sliding bushing 9 must be pulled from its bearing seat.



- Remove the upper sliding bushing 10.



Info

Without using a tool, carefully pull the stack apart by hand.



- Take off the lower sliding bushing 9.
- Take off support ring 11.
- Take off seal ring 12.
- Take off lock ring 8.
- Take off dust boot 7.
- Unclamp the fork leg.


Disassembling the cartridge



Info

These operations are the same on both fork legs.


- Disassemble the fork legs. (☛ p. 18)




- Degrease the piston rod.
- Clamp the piston rod with the special tool.

Clamping stand (T14016S) (☛ p. 256)


- Remove fluid barrier ❶ from the piston rod.



- Take piston rod ❷ out of the cartridge.



- Take washer ❸ and spring seat ❹ off of the cartridge.



- Degrease the cartridge and clamp it with the special tool.

Clamping stand (T14015S) (☛ p. 256)

- Heat the cartridge in area ❹.

Guideline

50 °C (122 °F)

- Loosen and remove screw sleeve ❺.




Info

This operation is not needed for further disassembly.




- Degrease the piston rod.
- Clamp the piston rod with the special tool.


Clamping stand (T14016S) (☛ p. 256)




- Remove nut ❻.
- Completely remove shim stack ❼.



- Remove piston 8.
- Completely remove shim stack 9.



- Remove spring 10.
- Loosen and remove tap rebound 11.




- Remove spring 12.
- Remove valve 13 of the rebound damping with the spring.
- Unclamp the piston rod.

Disassembling the tap compression




Info


These operations are the same on both fork legs.



- Disassemble the fork legs. (p. 18)
- Clamp the tap compression in a vise using soft jaws.
- Remove nut 1.
- Remove the spring.
- Remove washer 2.



- Remove piston 3.
- Remove shim stack 4.




- Remove O-ring ⑤ and seal ring ⑥ from the tap compression.
- Unclamp the tap compression.


Checking the fork legs (690 Enduro)

Condition

Fork dismantled.




- Check the inner tube and the axle clamp for damage.
 - » If damage is found:
 - Replace the inner tube.



- Measure the external diameter of the inner tube in several places.

External diameter of inner tube	47.975... 48.005 mm (1.88878... 1.88996 in)
---------------------------------	---


- » If the measured value is less than the specified value:
 - Replace the inner tube.




- Measure the run-out of the inner tube.

Run-out of inner tube	≤ 0.20 mm (≤ 0.0079 in)
-----------------------	-------------------------


- » If the measured value is greater than the specified value:
 - Replace the inner tube.



- Check the outer tube for damage.
 - » If damage is found:
 - Replace the outer tube.



- Check the surface of the sliding bushings.
 - » If the bronze-colored layer **A** under sliding layer **B** is visible:
 - Replace the sliding bushings.



- Check the spring length.

Guideline

Spring length with preload spacer(s)	472 mm (18.58 in)
--------------------------------------	-------------------

- » If the measured value is greater than the specified value:
 - Reduce the strength of the pretensioning bushes.
- » If the measured value is less than the specified value:
 - Increase the strength of the preload spacers.


Checking the fork legs (690 Enduro R)

Condition

Fork dismantled.




- Check the inner tube and the axle clamp for damage.
 - » If damage is found:
 - Replace the inner tube.



- Measure the external diameter of the inner tube in several places.

External diameter of inner tube	47.975... 48.005 mm (1.88878... 1.88996 in)
---------------------------------	---


- » If the measured value is less than the specified value:
 - Replace the inner tube.




- Measure the run-out of the inner tube.

Run-out of inner tube	≤ 0.20 mm (≤ 0.0079 in)
-----------------------	-------------------------


- » If the measured value is greater than the specified value:
 - Replace the inner tube.



- Check the outer tube for damage.
 - » If damage is found:
 - Replace the outer tube.



- Check the surface of the sliding bushings.
 - » If the bronze-colored layer **A** under sliding layer **B** is visible:
 - Replace the sliding bushings.



- Check the spring length.

Guideline

Spring length with preload spacer(s)	495 mm (19.49 in)
--------------------------------------	-------------------


- » If the measured value is greater than the specified value:
 - Reduce the strength of the pretensioning bushes.
- » If the measured value is less than the specified value:
 - Increase the strength of the preload spacers.

Assembling the tap compression




Info

These operations are the same on both fork legs.



- Clamp the tap compression in a vise using soft jaws.
- Mount O-ring **1** and seal ring **2**.
- Lubricate the O-ring.

Lubricant (T158) (☛ p. 244)



- Mount shim stack **3**.



Info

Mount with the smaller shims facing downward.

- Mount piston **4** with the O-ring.




Info

The side with the larger inside diameter **A** faces upward.

- Lubricate the O-ring of the piston.

Fork oil (SAE 5) (☛ p. 243)



- Mount washer ⑤.
- Mount spring ⑥ with the tighter coil facing downward.
- Mount and tighten the nut ⑦.

Guideline

Tap compression nut	M6x0.5	3 Nm (2.2 lbf ft)
---------------------	--------	-------------------



Info

Washer ⑤ must be movable against the spring force.


- Lock the nut using a punch.
- Unclamp the tap compression.

Assembling the cartridge



Info


These operations are the same on both fork legs.



- Clamp the piston rod.
- Mount valve ① of the rebound damping with the spring and O-ring.
- Lubricate the O-ring.

Lubricant (T158) (☞ p. 244)

- Mount spring ②.



- Lubricate the O-ring of tap rebound ③.


Lubricant (T158) (☞ p. 244)

- Mount and tighten the tap compression.

Guideline

Tap rebound	M9x1	18 Nm (13.3 lbf ft)	Loctite® 2701
-------------	------	------------------------	---------------

- Position spring ④.



- Mount shim stack ⑤.



Info

Mount with the smaller shims facing downward.

- Press the shim stack down against the spring force.



Info

The shim stack must be pressed down over the collar.

- Mount piston ⑥ with the piston ring.



Info

The side with the larger inside diameter should face downward.

- Mount shim stack ⑦.



Info

Align the triangular plates exactly with the opening of the piston.

- Mount and tighten the nut ⑧.


Guideline


Tap rebound nut	M6x0.5	5 Nm (3.7 lbf ft)
-----------------	--------	-------------------



Info

Mount the nut with the collar facing downward.






- Lock the nut using a punch.
- Degrease the cartridge and clamp it with the special tool.

Clamping stand (T14015S) (☛ p. 256)


- Mount and tighten screw sleeve 9.

Guideline


Screw sleeve	M29x1	46 Nm (33.9 lbf ft)	Loctite® 241
--------------	-------	------------------------	--------------



- Mount washer 10 and spring seat 11.



- Slide piston rod 12 into the cartridge.



- Screw on fluid barrier 13 as far as it will go.



Info

The fluid barrier must be tightened as much as possible. Do not use tools.

Assembling the fork legs (690 Enduro)



Info

These operations are the same on both fork legs.



- Check the fork legs. (☛ p. 23)
- Assemble the cartridge. (☛ p. 26)
- Assemble the tap compression. (☛ p. 25)
- Clamp the inner tube with the axle clamp.
- Mount the special tool.

Protecting sleeve (T1401) (☛ p. 255)

- Grease and push on dust boot 1.

Lubricant (T511) (☛ p. 244)



Info

Always replace the dust boot, the seal ring, the lock ring, and the support ring.

Mount the sealing lip with the spring expander facing downward.

- Push on lock ring ❷.
- Grease and push on seal ring ❸.

Lubricant (T511) (☛ p. 244)



Info

Sealing ring downward, open side upward.

- Push on support ring ❹.
- Remove the special tool.
- Sand the edges of the sliding bushes with 600-grit sandpaper, then clean and grease them.

Fork oil (SAE 5) (☛ p. 243)



200670-10




200671-10

- Push on the lower sliding bushing ❺.
- Mount the upper sliding bushing ❻.



Info

Without using a tool, carefully pull the stack apart by hand.



200723-10

- Push on the outer tube.
- Heat up the outer tube in area A of the lower sliding bushings.

Guideline

50 °C (122 °F)

- Hold the lower sliding bushing with the longer side of the special tool.

Assembly tool (T1402S) (☛ p. 256)

- Press on the outer tube as far as it will go.




200724-10

- Position the support ring.
- Hold the seal ring with the shorter side of the special tool.

Assembly tool (T1402S) (☛ p. 256)

- Press on the outer tube as far as it will go.




200656-11

- Mount lock ring ❷.




Info

The lock ring must engage audibly.



- Install dust boot ❶.



- Mount adjusting tube ❷ of the rebound damping in the cartridge.
 - ✓ The adjusting tube protrudes 5 mm from the cartridge and can be pressed in against the resistance of the spring.
 - ✗ The adjusting tube protrudes more than 7 mm from the cartridge and cannot be pressed in against the resistance of the spring.
- Screw on fluid barrier ❸ as far as it will go.



Info

The fluid barrier must be tightened as much as possible. Do not use tools.


- Install the special tool on the cartridge.

Gripping tool (T14026S1) (☛ p. 256)



Info

The special tool must be used to prevent the adjusting tube being lifted and thus to prevent oil from reaching the piston rod.



- Slide the cartridge into the inner tube.
- Mount and tighten tap compression ❸.

Guideline

Tap compression	M29x1	35 Nm (25.8 lbf ft)
-----------------	-------	------------------------



Info

If the cartridge itself turns, press the piston rod slightly to one side.




- Clamp the fork vertically.
- Fill it with fork oil.

Fork oil per fork leg	620 ml (20.96 fl. oz.)	Fork oil (SAE 5) (☛ p. 243)
-----------------------	---------------------------	-----------------------------



Info

Pull out and push in the piston rod completely a few times to remove air from the cartridge.



- Remove pin ❹ of the special tool.

Gripping tool (T14026S1) (☛ p. 256)

- Pull out the piston rod. Mount the spring. Mount the spring again.



- Pull the spring downward. Mount the special tool on the hexagon.

Guideline

Spring rate	
Soft	5.2 N/mm (29.7 lb/in)
Medium (standard)	5.4 N/mm (30.8 lb/in)
Hard	5.6 N/mm (32 lb/in)

Open-end wrench (T14032) (☛ p. 256)

- Remove the special tool.

Gripping tool (T14026S1) (☛ p. 256)

- Clamp the special tool in the vise.
- Grease the thread of the piston rod.

Lubricant (T159) (☛ p. 244)

- Lubricate top edge **D** of the piston rod.

Lubricant (T158) (☛ p. 244)

- Screw the screw cover with the preload spacers on to the piston rod.



Info

The screw cover must be screwed to the stop before the piston rod starts to turn. If the thread of the piston rod is stiff, it must be held to prevent it from turning. If the screw cover is not screwed to the stop, the rebound adjustment will not work correctly.

- Tighten the screw cover.

Guideline

Screw cover on piston rod	M12x1	25 Nm (18.4 lbf ft)
---------------------------	-------	------------------------

- Release the special tool. Pull the spring downward and take off the special tool.



- Push the outer tube upward.
- Clamp the outer tube in the area of the lower triple clamp.

Clamping stand (T1403S) (☛ p. 257)

- Grease the O-ring of the screw cover.

Lubricant (T158) (☛ p. 244)


- Screw on and tighten the screw cover.

Guideline

Screw cover on outer tube	M51x1.5	50 Nm (36.9 lbf ft)
---------------------------	---------	------------------------

Alternative 1

- Turn the adjusting screw of rebound damping **9** and the adjusting screw of compression damping **10** clockwise as far as possible.
- Turn back counterclockwise by the number of clicks corresponding to the fork type.



Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

Alternative 2

**Warning**

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
 - Only make adjustments within the recommended range.
 - After making adjustments, ride slowly at first to get the feel of the new ride behavior.
-
- Turn the adjusting screws to the position they were in before dismantling.
 - Mount protection cap **F**.

Assembling the fork legs (690 Enduro R)

**Info**

These operations are the same on both fork legs.



- Check the fork legs. (☞ p. 24)
- Assemble the cartridge. (☞ p. 26)
- Assemble the tap compression. (☞ p. 25)
- Clamp the inner tube with the axle clamp.
- Mount the special tool.

Protecting sleeve (T1401) (☞ p. 255)

- Grease and push on dust boot **1**.

Lubricant (T511) (☞ p. 244)

**Info**

Always replace the dust boot, the seal ring, the lock ring, and the support ring.

Mount the sealing lip with the spring expander facing downward.

- Push on lock ring **2**.
- Grease and push on seal ring **3**.

Lubricant (T511) (☞ p. 244)

**Info**

Sealing ring downward, open side upward.

- Push on support ring **4**.
- Remove the special tool.



- Sand the edges of the sliding bushes with 600-grit sandpaper, then clean and grease them.

Fork oil (SAE 5) (☛ p. 243)




- Push on the lower sliding bushing ⑤.
- Mount the upper sliding bushing ⑥.



Info

Without using a tool, carefully pull the stack apart by hand.



- Push on the outer tube.
- Heat up the outer tube in area A of the lower sliding bushings.

Guideline

50 °C (122 °F)

- Hold the lower sliding bushing with the longer side of the special tool.

Assembly tool (T1402S) (☛ p. 256)


- Press on the outer tube as far as it will go.



- Position the support ring.
- Hold the seal ring with the shorter side of the special tool.

Assembly tool (T1402S) (☛ p. 256)

- Press on the outer tube as far as it will go.




- Mount lock ring ②.




Info

The lock ring must engage audibly.



- Install dust boot ①.



- Mount adjusting tube 7 of the rebound damping in the cartridge.
- ✓ The adjusting tube protrudes 5 mm from the cartridge and can be pressed in against the resistance of the spring.
- ✗ The adjusting tube protrudes more than 7 mm from the cartridge and cannot be pressed in against the resistance of the spring.
- Screw on fluid barrier B as far as it will go.



Info

The fluid barrier must be tightened as much as possible. Do not use tools.


- Install the special tool on the cartridge.

Gripping tool (T14026S1) (☛ p. 256)



Info

The special tool must be used to prevent the adjusting tube being lifted and thus to prevent oil from reaching the piston rod.



- Slide the cartridge into the inner tube.
- Mount and tighten tap compression 8.

Guideline

Tap compression	M29x1	35 Nm (25.8 lbf ft)
-----------------	-------	------------------------



Info

If the cartridge itself turns, press the piston rod slightly to one side.




- Clamp the fork vertically.
- Fill it with fork oil.

Fork oil per fork leg	635 ml (21.47 fl. oz.)	Fork oil (SAE 5) (☛ p. 243)
-----------------------	---------------------------	-----------------------------



Info

Pull out and push in the piston rod completely a few times to remove air from the cartridge.



- Remove pin C of the special tool.

Gripping tool (T14026S1) (☛ p. 256)

- Pull out the piston rod. Mount the spring. Mount the spring again.



- Pull the spring downward. Mount the special tool on the hexagon.


Guideline

Spring rate	
Medium (standard)	5.2 N/mm (29.7 lb/in)

Open-end wrench (T14032) (☛ p. 256)

- Remove the special tool.

Gripping tool (T14026S1) (☛ p. 256)



- Clamp the special tool in the vise.
- Grease the thread of the piston rod.

Lubricant (T159) (☛ p. 244)

- Lubricate top edge **D** of the piston rod.

Lubricant (T158) (☛ p. 244)

- Screw the screw cover with the preload spacers on to the piston rod.



Info

The screw cover must be screwed to the stop before the piston rod starts to turn. If the thread of the piston rod is stiff, it must be held to prevent it from turning. If the screw cover is not screwed to the stop, the rebound adjustment will not work correctly.

- Tighten the screw cover.

Guideline

Screw cover on piston rod	M12x1	25 Nm (18.4 lbf ft)
---------------------------	-------	------------------------

- Release the special tool. Pull the spring downward and take off the special tool.



- Push the outer tube upward.
- Clamp the outer tube in the area of the lower triple clamp.

Clamping stand (T1403S) (☛ p. 257)

- Grease the O-ring of the screw cover.

Lubricant (T158) (☛ p. 244)

- Screw on and tighten the screw cover.

Guideline


Screw cover on outer tube	M51x1.5	50 Nm (36.9 lbf ft)
---------------------------	---------	------------------------

Alternative 1

- Turn the adjusting screw of rebound damping **9** and the adjusting screw of compression damping **10** clockwise as far as possible.
- Turn back counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks




Alternative 2



Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.

- Turn the adjusting screws to the position they were in before dismantling.
- Mount protection cap .

Checking the steering head bearing play



Warning


Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.


- Adjust the steering head bearing play without delay.




Info

If the bike is driven for a longer time with play in the steering head bearing, the bearing and the bearing seats in the frame can be damaged after time.





- Raise the motorcycle with the lift stand. ( p. 9)
- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.


No play should be noticeable in the steering head bearing.


- » If there is noticeable play present:
 - Adjust the play of the steering head bearing. ( p. 35)
- Move the handlebar to and fro over the entire steering range.

The handlebar must be able to move easily over the entire steering range. No resting locations should be noticeable.

- » If click positions are noticeable:
 - Adjust the play of the steering head bearing. ( p. 35)
 - Check the steering head bearing and change if necessary.
- Remove the motorcycle from the lift stand. ( p. 9)

Adjusting the play of the steering head bearing




- Raise the motorcycle with the lift stand. ( p. 9)
- (690 Enduro)**

- Loosen screw . Remove screw .
- Loosen and retighten screw .

Guideline

Screw, top steering head	M20x1.5	10 Nm (7.4 lbf ft)
--------------------------	---------	-----------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Fully tighten screws .


Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	------------------------

- Mount and tighten screw .

Guideline

Screw, steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
----------------------	----	------------------------	---------------

**(690 Enduro R)**

- Loosen screw ❶. Remove screw ❷.
- Loosen and retighten screw ❸.

Guideline

Screw, top steering head	M20x1.5	10 Nm (7.4 lbf ft)
--------------------------	---------	-----------------------

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
- Fully tighten screws ❶.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
-------------------------	----	------------------------


- Mount and tighten screw ❷.

Guideline

Screw, steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
----------------------	----	------------------------	----------------------

- Check the steering head bearing play. (🔧 p. 35)
- Remove the motorcycle from the lift stand. (🔧 p. 9)

Handlebar position



On the upper triple clamp, there are 2 holes at a distance **A** to each other.


Distance A between holes	15 mm (0.59 in)
---------------------------------	-----------------

The holes on the handlebar support are placed at a distance **B** from the center.

Distance B between holes	3.5 mm (0.138 in)
---------------------------------	-------------------

The handlebar can be mounted in 4 different positions. In this way, the handlebar can be installed in the position most comfortable for the rider.

Adjusting handlebar position



- Remove the four screws **1**. Remove the handlebar clamp. Remove the handlebar and lay it to one side.



Info

Protect the motorcycle and its attachments from damage by covering them. Do not bend the cables and lines.

- Remove the two screws **2**. Remove the handlebar support.
- Place the handlebar support in the required position. Fit and tighten the two screws **2**.

Guideline

Screw, handlebar support	M10	40 Nm (29.5 lbf ft)
--------------------------	-----	------------------------



Info

Position the left and right handlebar supports evenly.

- Position the handlebar.



Info


Make sure cables and wiring are positioned correctly.

- Position the handlebar clamp. Fit and evenly tighten the four screws **1**.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
------------------------	----	------------------------	---------------

Checking the play in the throttle cable



- Move the handlebar to the straight-ahead position. Move the throttle grip backwards and forwards to ascertain the play in the throttle cable.

Throttle cable play	3... 5 mm (0.12... 0.2 in)
---------------------	----------------------------

- » If the throttle cable play does not meet specifications:
 - Adjust the play in the throttle cable. (☛ p. 38)



Danger

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.


- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:

- Adjust the play in the throttle cable. (🔧 p. 38)

Adjusting the play in the throttle cable




- Move the handlebar to the straight-ahead position.
- Use the KTM diagnostics tool to set the motor drive to the basic position.
- Loosen counter nut ❶.
- Set the play in the throttle cable by turning the adjusting screw ❷.

Guideline

Throttle cable play	3... 5 mm (0.12... 0.2 in)
---------------------	----------------------------


- Tighten counter nut ❶.

Removing the engine guard



- Stand the motorcycle on its side stand on a horizontal surface.
- Remove screws ❶ on the left and right.
- Pull the engine guard forward out of the holders and set it down.

Installing the engine guard




- Slide the engine guard into holders ❶ at the rear.
- Position the engine guard. Mount and tighten screws.


Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

Adjusting the high-speed compression damping of the shock absorber


**Danger**
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**
The high-speed setting can be seen during the fast compression of the shock absorber.



- Turn adjusting screw ❶ all the way clockwise using a socket wrench.

**Info**
Do not loosen nut ❷!


- Turn back counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline
(690 Enduro)


Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn

(690 Enduro R)


Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn


**Info**
Turn clockwise to increase damping; turn counterclockwise to reduce damping.

Adjusting the low-speed compression damping of the shock absorber


**Danger**
Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**
The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn the adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

**Info**
Do not loosen nut ❷!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

(690 Enduro)

Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

(690 Enduro R)

Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

**Info**


Turn clockwise to increase damping; turn counterclockwise to reduce damping.

Adjusting the rebound damping of the shock absorber

**Danger**

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.



100247-10

- Turn adjusting screw ❶ clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

(690 Enduro)

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks


(690 Enduro R)

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

**Info**


Turn clockwise to increase damping; turn counterclockwise to reduce damping.

Measuring the unloaded rear wheel sag



- Raise the motorcycle with the lift stand. (🔧 p. 9)
- Measure the vertical distance between the rear axle and a fixed point such as a marking on the side cover.
- Note down the value as dimension **A**.
- Remove the motorcycle from the lift stand. (🔧 p. 9)

Checking the static sag of the shock absorber



- Measure distance **A** of rear wheel unloaded. (🔧 p. 42)
- Hold the motorcycle upright with the aid of an assistant.
- Measure the distance between the rear axle and the fixed point again.
- Note down the value as dimension **B**.



Info

The static sag is the difference between measurements **A** and **B**.

- Check the static sag.

(690 Enduro)


Static sag	25 mm (0.98 in)
------------	-----------------

(690 Enduro R)

Static sag	25 mm (0.98 in)
------------	-----------------

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber. (🔧 p. 43)

Checking the riding sag of the shock absorber



- Measure distance **A** of rear wheel unloaded. (🔧 p. 42)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person now measures the distance between the rear axle and a fixed point.
- Note down the value as dimension **C**.



Info

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

(690 Enduro)

Riding sag	70... 80 mm (2.76... 3.15 in)
------------	-------------------------------

(690 Enduro R)

Riding sag	70... 80 mm (2.76... 3.15 in)
------------	-------------------------------

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. (🔧 p. 43)

Adjusting the spring preload of the shock absorber


**Danger**

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.



- Remove the shock absorber. (☛ p. 44)
- After removing the shock absorber, clean it thoroughly.
- Loosen locking ring ❶.
- Turn adjusting ring ❷ until the spring is no longer under tension.

Hook wrench (T106S) (☛ p. 254)

- Measure the overall spring length without a load.
- Tension the spring by turning the adjusting ring ❷ to the prescribed value.

Guideline

(690 Enduro)

Spring preload	20 mm (0.79 in)
----------------	-----------------

(690 Enduro R)


Spring preload	20 mm (0.79 in)
----------------	-----------------

**Info**

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten locking ring ❶.
- Install the shock absorber. (☛ p. 45)

Adjusting the riding sag



- Remove the shock absorber. (☛ p. 44)
- After removing the shock absorber, clean it thoroughly.
- Choose and mount a suitable spring.

Guideline

(690 Enduro)

Spring rate	
Medium (standard)	80 N/mm (457 lb/in)

(690 Enduro R)


Spring rate	
Medium (standard)	80 N/mm (457 lb/in)

**Info**


The spring rate is shown on the outside of the spring.

- Install the shock absorber. (☛ p. 45)
- Check the static sag of the shock absorber. (☛ p. 42)
- Adjust the rebound damping of the shock absorber. (☛ p. 41)


Removing the shock absorber




- Raise the motorcycle with the work stand. (☛ p. 9)
- Remove screws ❶.





- Lift the rear fairing.
- Remove screws ❷.



- Remove screw ❸.
- Repeat the operation on the opposite side.




- Loosen screw ❹.
- Remove screw ❺.
- Remove screw ❹.




- Swing the rear end upwards.
- Lift shock absorber ❻ upwards and remove.

Installing the shock absorber



- Swing the rear end upwards and insert shock absorber ❶ from above.



- Mount screw ❷ but do not tighten yet.
- Mount and tighten screw ❸.



Guideline

Screw, bottom shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
------------------------------	-----	------------------------	---------------

- Tighten screw ❷.

Guideline

Screw, top shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
---------------------------	-----	------------------------	---------------




- Mount and tighten screw ❹.

Guideline

Screw, fuel tank, bottom	M8	20 Nm (14.8 lbf ft)	
--------------------------	----	------------------------	--


- Repeat the operation on the opposite side.



- Lift the rear fairing.
- Mount and tighten screws ❺.

Guideline

Screw, main silencer holder on fuel tank	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
--	----	------------------------	---------------



- Mount and tighten screws ❻.

Guideline

Screw, side cover	M5	2 Nm (1.5 lbf ft)	
-------------------	----	-------------------	--

- Mount the side cover. (🔧 p. 67)
- Remove the motorcycle from the work stand. (🔧 p. 10)

Servicing the shock absorber



Danger


Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

Condition

The shock absorber has been removed.

- Remove the spring. (☛ p. 46)
- Dismantle the damper. (☛ p. 47)
- Disassemble the piston rod. (☛ p. 48)
- Check the damper. (☛ p. 49)
- Remove the heim joint. (☛ p. 50)
- Install the heim joint. (☛ p. 51)
- Assemble the piston rod. (☛ p. 52)
- Assemble the damper. (☛ p. 53)
- Install the spring. (☛ p. 58)



Removing the spring


Condition

The shock absorber has been removed.

- Clamp the shock absorber in the vise using soft jaws for protection.
- Measure and note spring length in preloaded state.
- Loosen retaining ring ❶ and the adjusting ring with the special tool.


Hook wrench (T106S) (☛ p. 254)

- Turn the retaining ring and adjusting ring until the spring is fully relieved of tension.




- Remove spring retainer ❷.
- Take off spring ❸ with the retaining ring and adjusting ring ❹.

Dismantling the damper



- Remove the spring. (☛ p. 46)
- Establish and note the current state of the rebound damping and compression damping.
- Completely open the adjusters of the rebound and compression damping.
- Remove rubber cap ❶ of the reservoir.
- Open screw ❷ slowly.
✓ The pressurized nitrogen escapes.



- Remove locking cap ❸.




- Press in seal ring retainer ❹. Remove lock ring ❺.



Info


Do not scratch the inner surface.



- Remove screw ❻. Drain the oil.




- Remove the piston rod. Drain the remaining oil.




- Remove compression damping adjuster 7. Remove the spring, sleeve and piston.

Disassembling the piston rod



- Dismantle the damper. (☛ p. 47)
- Clamp the piston rod with the heim joint in a vise.
- Remove nut 1.



- Remove supporting plate 2 and rebound shim stack 3 together with piston 4.

Info


Thread the rebound shim set on a screwdriver and set the parts down together.




- Remove compression shim stack 6 with supporting plate 5.

Info

Thread the compression shim stack on a screwdriver and set the parts down together.



- Remove seal ring retainer 7.



- Remove locking cap 8 and rubber buffer 9.

Checking the damper



Condition

The damper has been disassembled.


- Measure the inside diameter at both ends and in the center of the damper cartridge.

Damper cartridge	
Minimum diameter	46.10 mm (1.815 in)

 - » If the measured value is greater than the specified value:
 - Change the damper cartridge.
- Check the damper cartridge for damage and wear.
 - » If there is damage or wear:
 - Change the damper cartridge.
- Measure the diameter of the piston rod.

Piston rod	
Diameter	≥ 17.95 mm (≥ 0.7067 in)


 - » If the specification is not reached:
 - Change the piston rod.



- Measure the run-out of the piston rod.

Piston rod	
Run-out	≤ 0.03 mm (≤ 0.0012 in)

 - » If the measured value is greater than the specified value:
 - Change the piston rod.
- Check the piston rod for damage and wear.
 - » If there is damage or wear:
 - Change the piston rod.



- Check the heim joint for damage and wear.
 - » If there is damage or wear:
 - Change the heim joint.

Removing the heim joint

Condition



The shock absorber has been removed.

- Clamp the shock absorber in the vise using soft jaws for protection.
- Remove collar bushing ❶ of the heim joint.


Pin (T120) (☛ p. 254)

- Turn over the shock absorber and remove collar bushing ❷ of the heim joint.


Pin (T120) (☛ p. 254)



- Remove seal rings ❸ on both sides.




- Remove lock rings ❹ on both sides.



- Place special tool ⑤ underneath and press out the heim joint with special tool ⑥.

Pressing tool (T1207S) (☛ p. 255)


Installing the heim joint




- Place special tool ① underneath and press in the heim joint as far as the center using special tool ②.

Pressing tool (T1206) (☛ p. 255)

Pressing tool (T129) (☛ p. 255)




- Mount lock rings ③ on both sides.




- Mount seal rings ④ on both sides and grease them.

Lubricant (T158) (☛ p. 244)




- Press in both collar sleeves ⑤ of the heim joint.

Assembling the piston rod



- Check the damper. (☛ p. 49)
- Clamp the piston rod with the heim joint in a vise.
- Mount rubber buffer 1 and locking cap 2.



- Position special tool 3 on the piston rod.
Mounting sleeve (T1515) (☛ p. 257)
- Grease the seal ring and push seal ring retainer 4 on to the piston rod.
Lubricant (T625) (☛ p. 245)
- Remove the special tool.




- Mount supporting plate 5 with the rounded side facing downward.
- Mount the compression shim stack 6 with the smaller shims facing downward.




- Sand both sides of the piston on a surface plate using 1200-grit sandpaper.
- Clean the piston.
- Assemble the piston.

Guideline

View A	Piston from above
View B	Piston from below



- Mount the rebound shim stack 7 with the smaller shims facing upward.
- Install supporting plate 8.



- Mount and tighten nut 9.

Guideline

Piston rod nut	M12x1	40 Nm (29.5 lbf ft)
----------------	-------	------------------------


Assembling the damper



- Assemble the piston rod. (☛ p. 52)
- Push the spring and sleeve onto the compression damping adjuster. Attach the piston.
- Mount and tighten the compression damping adjuster ①.

Guideline

Compression damping adjustment	M26x1	30 Nm (22.1 lbf ft)
--------------------------------	-------	------------------------



- Mount and tighten screw ②.

Guideline

Filling port screw	M10x1	14 Nm (10.3 lbf ft)
--------------------	-------	------------------------



- Fill the damper cartridge about half full.

Shock absorber oil (SAE 2,5) (50180342S1) (☛ p. 243)



- Grease O-ring ③ of the seal ring retainer.

Lubricant (T158) (☛ p. 244)

- Mount the piston rod carefully.



- Install the seal ring bearer ④ and push it under the ring groove.
- Mount lock ring ⑤.




Info

Do not scratch the inner surface.

- Pull out the piston rod so that the seal ring retainer rests against the lock ring.



- Mount locking cap ⑥ of the damper cartridge.
- Bleed and fill the damper. (☛ p. 55)
- Fill the damper with nitrogen. (☛ p. 57)



Alternative 1

- Turn adjusting screw ⑦ clockwise with a screwdriver up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

- Turn adjusting screw ⑧ all the way clockwise using a socket wrench.
- Turn back counterclockwise the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn

- Turn adjusting screw ⑨ clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks

Alternative 2



Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.


- Turn adjusting screws ⑦, ⑧ and ⑨ to the position determined during disassembly.
- Install the spring. (☛ p. 58)

Bleeding and filling the damper



Info

Before working with the vacuum pump, be sure to read the operating instructions carefully. Completely open the adjusters of the rebound and compression damping.



- Remove the screw of the filling port.
- Install adapter ① on the damper.



Info

Tighten only hand-tight, without the use of tools.

- Connect the adapter ① to connector ② of the vacuum pump.

Vacuum pump (T1240S) (☛ p. 255)

- Clamp the damper with soft jaws or hold it as shown in the photo.




Info

Clamp the damper only lightly.

The filling port must be at the highest point.

The piston rod slides in and out during filling - do not hold it tight with your hand!



- Place the control lever as shown in the photo.
- ✓ The **External tank** ③ control lever is on **Closed**, **Damper** ④ on **Vacuum**, and **Oil reservoir** ⑤ on **Vacuum**.
- Operate the **On/Off** switch ⑥.

✓ The vacuum pump process starts.

✓ Pressure gauge ⑦ falls to the specified value.

< 0 bar



✓ The vacuum gauge ⑧ falls to the specified value.

4 mbar

- Measure distance **A** between the floating piston and reservoir hole with the special tool.

Depth micrometer (T107S) (☛ p. 254)

✓ The floating piston is positioned all the way at the bottom.




- When the vacuum pressure gauge reaches the specified value, turn the **Oil reservoir** control lever ⑤ to **Equalize pressure**.

Guideline

4 mbar

✓ The pressure gauge rises to the specified value.

0 bar




- When the pressure gauge reaches the specified value, turn the **Damper** control lever **4** to **Pressure**.

Guideline

0 bar

- ✓ Oil is pumped into the damper.
- ✓ The pressure gauge rises to the specified value.

3 bar




- When the pressure gauge reaches the specified value, turn the **Damper** **4** control lever to **Vacuum**.

Guideline

3 bar

- ✓ The pressure gauge falls to the specified value.

0 bar




- When the pressure gauge reaches the specified value, turn the **Oil reservoir** **5** control lever to **Vacuum**.

Guideline

0 bar

- ✓ The vacuum gauge falls to the specified value.

4 mbar




- When the vacuum pressure gauge reaches the specified value, turn the **Oil reservoir** control lever **5** to **Equalize Pressure**.

Guideline

4 mbar

- ✓ The pressure gauge falls to the specified value.

0 bar




- When the pressure gauge reaches the specified value, turn the **Damper** control lever **4** to **Pressure**.

Guideline

0 bar

- ✓ Oil is pumped into the damper.
- ✓ The pressure gauge rises to the specified value.

3 bar



- When the pressure gauge reaches the specified value, turn the **Damper** **4** control lever to **Vacuum**.

Guideline

3 bar

- ✓ The pressure gauge falls to the specified value.


0 bar

- When the pressure gauge reaches the specified value, operate the **On/Off** switch.

Guideline

0 bar

- ✓ The vacuum pump is switched off.



- Slide O-ring **B** to the end of the special tool by the specified value (distance **A** minus specified value).

Guideline

10 mm

Depth micrometer (T107S) (☛ p. 254)

- Slide the floating piston into the reservoir to the shortened position using the special tool.



Info

The floating piston must be positioned at exactly this point when the rod is fully extended; otherwise, damage will occur during compression of the shock absorber.

- Remove the special tool.
- Remove adapter **1** from connection **2** of the vacuum pump.



Info

Hold the damper so that the filling port is at the highest point.


- Remove the adapter.
- Mount and tighten screw **9**.

Guideline


Filling port screw

M10x1

14 Nm
(10.3 lbf ft)



Filling the damper with nitrogen




- Screw in screw **1** by approx. 2 rotations but do not tighten.



Info

The piston rod is fully extended.



- Clamp special tool in the vise.

Nitrogen filling tool (T170S1) (☛ p. 257)

- Connect the special tool to the pressure regulator of the filling cylinder.

Filling gas - nitrogen

- Adjust pressure regulator.

Guideline

Gas pressure

10 bar (145 psi)

- Position the damper in the special tool.



The hexagonal part of the tap handle **A** engages in the hexagon socket of the filling port screw.

- Open filler tap **B**.
- Fill the damper for at least 15 seconds.

Guideline

Gas pressure

10 bar (145 psi)



Info

Watch the pressure regulator dial.
Make sure that the damper is filled to the specified pressure.

- Close the filling port screw using tap handle **A**.


- Close spigot ❸ and take the damper out of the special tool.
- Tighten the filling port screw.

Guideline

Screw, reservoir filling port	M5	3 Nm (2.2 lbf ft)
-------------------------------	----	-------------------

- Mount the rubber cap of the reservoir.

Installing the spring



- Clamp the damper in the vise using soft jaws.
- Install retaining ring ❶ and turn it down as far as possible.
 - ✓ The collar points to the adjusting ring.
- Mount adjusting ring ❷ and turn it down as far as possible.
 - ✓ The collar points to the spring.
- Measure the overall spring length without a load.
- Mount spring ❸.

Guideline

Spring rate	
Medium (standard)	80 N/mm (457 lb/in)

- Mount spring retainer ❹.
 - ✓ The open end is opposite the spring end.

Alternative 1

- Tension the spring to the prescribed amount by turning the adjusting ring.

Guideline

Spring preload	20 mm (0.79 in)
Hook wrench (T106S) (🔧 p. 254)	

Alternative 2



Warning


Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.

- Tension the spring to the amount measured during dismantling by turning adjusting ring ❷.

Hook wrench (T106S) (🔧 p. 254)

- Tighten lock nut ❶ and the adjusting ring.




Removing the exhaust manifold




Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down. Do not touch hot components.



- Remove the air filter box. (➔ p. 63)
- Unplug connector ① of the lambda sensor. Open the cable binder.



- Remove screws ②.
- Remove the heat shield.




- Remove nuts ③ of the manifold.




Info

Do not misplace the spacers.




- Loosen screw ④.
- Remove the manifold.

Installing exhaust manifold




- Position the manifold at the rear with the seals.



- Position the spacer.
- Position the manifold at the front with the seals.
- Mount and tighten nuts ❶.

Guideline


Nut, manifold on cylinder head	M8	25 Nm (18.4 lbf ft)	Copper paste
--------------------------------	----	---------------------	--------------




- Position the exhaust clamp.
- Tighten screw ❷.

Guideline

Screw, exhaust clamp on manifold	M8	25 Nm (18.4 lbf ft)	Copper paste
----------------------------------	----	---------------------	--------------



- Plug in the connector of the lambda sensor ❸. Secure the cable with the cable binders.




- Position the heat shield.
- Mount and tighten screws ❹.

Guideline


Screw, exhaust heat shield	M5	8 Nm (5.9 lbf ft)	
----------------------------	----	-------------------	--

- Install the air filter box. (➡ p. 64)


Removing the main silencer

**Warning**
Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down. Do not touch hot components.




- Remove screws ❶.
- Take off the exhaust heat shield.



- Loosen screw ❷.




- Remove screws ❸.
- Lift the rear fairing.




- Remove screws ❹.
- Remove the main silencer.

Installing the main silencer




- Position the main silencer.
- Mount and tighten screws ❶.

Guideline		
Screw, main silencer holder	M8	25 Nm (18.4 lbf ft)




- Position the exhaust clamp.
- Tighten screw ❷.

Guideline			
Screw, exhaust clamp on manifold	M8	25 Nm (18.4 lbf ft)	Copper paste



- Position the exhaust heat shield.
- Mount and tighten screws ❸.

Guideline		
Screw, exhaust heat shield	M5	8 Nm (5.9 lbf ft)





- Mount and tighten screws ④.

Guideline

Rear fairing screw	M5	2 Nm (1.5 lbf ft)
--------------------	----	-------------------

Removing the air filter





- Remove the seat. (☛ p. 66)
- Remove screws ❶. Remove filter box top ❷.

Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.
- Remove air filter ❸.

Installing the air filter



- Clean the air filter box.
- Mount air filter ❶.



Info

The air filter must lie flush against the air filter box along the entire sealing surface A.

If the air filter is not correctly mounted, dust and dirt can penetrate into the engine and can cause damage.


- Hook filter box top ❷ into the front of the air filter box and swing down.
- Mount and tighten screws ❸.

Guideline


Screw, air filter box top	M6	2 Nm (1.5 lbf ft)
---------------------------	----	-------------------

- Mount the seat. (☛ p. 66)


Removing the air filter box




- Take off the side cover. (☛ p. 67)
- Remove screws ❶.
- Take off the voltage regulator and hang it to the side in a de-energized state.
- Detach and expose hose ❷.




- Remove screws ③.



- Remove screws ④.



- Loosen hose clip ⑤.




- Raise the air filter box at the rear.
- Loosen the spring-loaded band-type clamp with the special tool and detach bleed hose ⑥.

Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 248)


- Detach connector ⑦ of the intake air temperature sensor.
- Take off the air filter box.

Installing the air filter box




- Attach connector ① of the intake air temperature sensor.
- Mount bleed hose ②. Mount the spring-loaded band-type clamp using the special tool.

Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 248)




- Position the air filter box.
- Mount and tighten hose clip ③.



- Mount and tighten screws ❹.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Mount and tighten screws ❺.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------



- Position the voltage regulator.
- Mount and tighten screws ❻.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Route and mount vent hose ❼ without kinking.
- Mount the side cover. (🔧 p. 67)

Opening filler cap



100227-10

- Lift the cover of the filler cap ❶ and insert the ignition key.
- Turn the ignition key 90° counterclockwise and remove the filler cap.



Info

The filler cap has a tank air vent system.

Closing filler cap



100228-01

- Put the filler cap back on and turn the ignition key 90° clockwise.
- Remove the ignition key and fold down the cover.


Removing the seat



100230-10

- Pull on strap ❶ and raise the rear of the seat at the same time.
- Pull back the seat and lift it off.


Mounting the seat



100276-10

(690 Enduro)

- Hook slot ❶ of the seat onto screw ❷, press the rear downward and at the same time push it forward.
- Push locking pin ❸ into lock housing ❹ and push the back of the seat down until the locking pin locks in place with an audible click.
- Finally, check that the seat is correctly mounted.




800096-10

(690 Enduro R)


- Hook slot ❶ of the seat onto screw ❷, press the rear downward and at the same time push it forward.
- Push locking pin ❸ into lock housing ❹ and push the back of the seat down until the locking pin locks in place with an audible click.
- Finally, check that the seat is correctly mounted.

Taking off the side cover



- Remove the seat. (🔧 p. 66)
- Remove screws ①.
- Pull off the side cover in area A and take off from above.
- Repeat the operation on the opposite side.

Mounting the side cover



- Attach the side cover in area A and engage it in area B.
- Mount and tighten screws ①.

Guideline

Screw, side cover	M5	2 Nm (1.5 lbf ft)
-------------------	----	-------------------

- Repeat the operation on the opposite side.
- Mount the seat. (🔧 p. 66)

Checking the fuel pressure



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.

Condition

The fuel tank is completely full.

The ignition is off.


The diagnostics tool is connected.


- Press on the metal plate and disconnect the fuel hose connection ①.



Info

Remaining fuel may run out of the fuel hose.





- Mount special tool ②.

Pressure testing tool (61029094000) (☞ p. 248)

- Mount special tool ③ with nozzle code 0,60.

Testing hose (61029093000) (☞ p. 248)

- Insert the hose end in a fuel canister.

Guideline

Minimum fuel canister capacity	10 l (2.6 US gal)
--------------------------------	-------------------

- Switch on the ignition.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Actuator test"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Fuel pump relay function test"**.
- Press **"Continue"**.
- In the KTM diagnostics tool, read the information page and start the actuator test with **"Continue"**.

Guideline

Maximum duration of actuator test	3 min
-----------------------------------	-------


- Check the fuel pressure with the filler cap closed.

Fuel pressure

When the fuel pump is active	3.3... 3.7 bar (48... 54 psi)
------------------------------	-------------------------------

» If the specification is not reached:

- Open the filler cap. (☞ p. 66)
- Check the tank air vent system.



- Check the fuel pressure with the filler cap open.

Fuel pressure

When the fuel pump is active	3.3... 3.7 bar (48... 54 psi)
------------------------------	-------------------------------

» If the specification is not reached:

- Check that the fuel line is clear.
- Change the fuel filter. (☞ p. 68)
- Replace the fuel pump.

- Stop the **"Function test of fuel pump control"** actuator test by pressing the **"Quit"** button.
- Dismantle the special tools.
- Connect the fuel hose connection.

Changing the fuel filter



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

**Warning**


Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.


**Warning**

Environmental hazard Improper handling of fuel is a danger to the environment.


- Do not allow fuel to get into the ground water, the ground, or the sewage system.




- Disconnect the battery. (🔌 p. 81)
- Drain the fuel from the fuel tank into a suitable container.
- Remove screws ❶.




- Lift the rear fairing.
- Remove screws ❷.




- Remove screw ❸.
- Repeat the operation on the opposite side.
- Swing the rear end upwards and secure it.




- Remove screws ❹.
- Pull out the fuel pump.




- Remove hose clamps ⑤.
- Remove fuel filter ⑥.



- Press lock ⑦.
- Remove fuel pump housing ⑧.




- Change fuel screen ⑨.
- Mount the fuel pump housing.




- Mount fuel filter ⑥.
- ✓ Arrow ④ points away from the fuel pump.
- Mount hose clamps ⑤.

Hose clamp pliers (60029057000) (☛ p. 248)



- Position the fuel pump.
- Mount and tighten screws ④.


Guideline		
Screw, fuel pump	M5	6 Nm (4.4 lbf ft)



- Position the rear end.
- Mount and tighten screw ③.

Guideline		
Screw, fuel tank, bottom	M8	20 Nm (14.8 lbf ft)


- Repeat the operation on the opposite side.



- Lift the rear fairing.
- Mount and tighten screws ❷.

Guideline

Screw, main silencer holder on fuel tank	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
--	----	---------------------	---------------



- Mount and tighten screws ❶.

Guideline


Screw, side cover	M5	2 Nm (1.5 lbf ft)	
-------------------	----	-------------------	--

- Disconnect the battery. (🔌 p. 82)

Removing the front wheel



- Raise the motorcycle with the lift stand. (🔧 p. 9)
- Press the brake caliper by hand on to the brake disc in order to press back the brake pistons.




- Remove screw ❶.
- Loosen screw ❷.



- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.

Info

Do not pull the hand brake lever when the front wheel is removed.
Always lay the wheel down in such a way that the brake disc is not damaged.



- Remove distance bushings ❸.


Installing the front wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Replace the wheel bearing.
- Clean and grease the shaft seal rings ❶ and bearing surface A of the distance bushings.

Long-life grease (🔧 p. 244)

- Insert the spacers.



- Lift the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw ❷.

Guideline

Screw, front wheel spindle	M24x1.5	40 Nm (29.5 lbf ft)
----------------------------	---------	------------------------

- Activate the hand brake lever multiple times until the brake linings are in contact with the brake disc.
- Remove the motorcycle from the lift stand. (🔧 p. 9)
- Pull the front wheel brake and push down hard on the fork several times to align the fork legs.
- Tighten screws ❸.

Guideline


Screw, fork stub	M8	15 Nm (11.1 lbf ft)
------------------	----	------------------------

Checking the tire air pressure



Info

Low tire air pressure leads to abnormal wear and overheating of the tire.
Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the dust cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure, offroad, single rider	
Front	1.5 bar (22 psi)
Rear	1.5 bar (22 psi)

Tire air pressure, road, solo	
Front	1.8 bar (26 psi)
Rear	1.8 bar (26 psi)

Tire air pressure with passenger / fully loaded	
Front	2.0 bar (29 psi)
Rear	2.2 bar (32 psi)

- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the dust cap.

Checking the tire condition



Warning

Danger of accidents Uncontrollable handling characteristic caused by a flat tire.

- For your own safety, have damaged tires changed immediately.



Warning

Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



Warning

Danger of accidents Uncontrollable handling characteristic due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.




Warning

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth rolling surface and therefore cannot provide full road grip. The entire rolling surface must be roughened in the first 200 kilometers (124.3 miles) by moderate riding at alternating angles. The full grip levels are not achieved until the tires have been run in.

i Info

The type, condition and air pressure of the tires all have a major impact on the handling of the motorcycle. Worn tires have a negative effect on riding behavior, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects and other damage.
 - » If the tires exhibit cuts, run-in objects or other damage:
 - Change the tires.
- Check the depth of the tread.

i Info

Note local national regulations concerning the minimum tread depth.

Minimum tread depth	$\geq 2 \text{ mm } (\geq 0.08 \text{ in})$
---------------------	---

- » If the tread depth is less than the minimum permissible depth:
 - Change the tires.
- Check the age of the tires.

i Info

The tire's date of manufacture is usually part of the tire markings and is indicated by the last four digits of the **DOT** marking. The first two digits refer to the week of manufacture and last two digits refer to the year of manufacture.

KTM recommends that the tires are changed regardless of the actual wear, at the latest after five years.


- » If a tire is more than five years old:
 - Change the tires.

Checking the brake discs

**Warning**

Danger of accidents Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay.



- Check the thickness of the front and rear brake discs in several places to ensure that it conforms to measurement **A**.



i Info

Wear reduces the thickness of the brake disc at the contact surface **1** of the brake disc.

Brake discs - wear limit	
Front	4.5 mm (0.177 in)
Rear	3.5 mm (0.138 in)

- » If the brake disc thickness is less than the specified value:
 - Replace the brake disc.
- Check the front and rear brake discs for damage, cracks, and deformation.
 - » If damage, cracks, or deformation are visible on the brake disc:
 - Replace the brake disc.

Removing rear wheel



- Raise the motorcycle with the lift stand. (🔧 p. 9)
- Press the brake caliper by hand on to the brake disc in order to press back the brake piston.
- Remove nut ❶. Remove chain adjuster ❷.
- Holding the rear wheel, withdraw the wheel spindle ❸.

- Push the rear wheel forwards as far as possible and take the chain off the rear sprocket.



Warning

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Take the rear wheel out of the swing arm.



Info

Do not operate the foot brake when the rear wheel is removed.

Installing the rear wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents No braking effect when operating the rear brake.

- After installing the rear wheel, always operate the foot brake until the pressure point is reached.



- Check the rear hub rubber dampers. (🔧 p. 79)
- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Replace the wheel bearing.
- Remove bushing ❶. Clean and grease the working surfaces of the bushing and shaft seal ring ❷.

Long-life grease (🔧 p. 244)


- Clean and grease the thread of the wheel spindle and nut ❸.

Long-life grease (🔧 p. 244)

- Install the rubber damper and rear sprocket carrier in the rear wheel.
- Place the rear wheel in the swingarm and bring the brake disc on the brake caliper into contact.
- Push the rear wheel forward as far as possible and lay the chain on the rear sprocket.
- Install the wheel spindle, the chain adjusters and the nut.

Guideline

In order that the rear wheel is correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to the reference marks A.



Info

Mount the left and right chain adjusters ❷ in the same position.

- Tighten nut ③.

Guideline

Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)
-------------------------	---------	------------------------

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Remove the motorcycle from the lift stand. (🔧 p. 9)


Checking the chain tension



Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.



- Lean the motorcycle on the side stand.
- Shift gear to neutral.
- Push the chain upward at a distance ② from the chain sliding guard and determine the chain tension ①.



Info

The upper chain section ③ must be taut.

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	5 mm (0.2 in)
Distance to chain sliding guard	30 mm (1.18 in)

- » If the chain tension does not meet specifications:
 - Adjust the chain tension. (🔧 p. 76)

Adjusting the chain tension




Warning

Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.

- Check the chain tension. (🔧 p. 76)



- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ on the left and right.

Guideline

Chain tension	5 mm (0.2 in)
Turn the left and right adjusting screws ③ so that the markings on the left and right chain adjusters ④ are in the same position relative to the reference marks ⑥. The rear wheel is then correctly aligned.	



Info

The upper chain section must be taut.
Chain wear is not always even, so you should check this setting at different chain positions.

- Tighten nuts ②.
- Make sure that the chain adjusters ④ are installed correctly on adjusting screws ③.
- Tighten nut ①.

Guideline


Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)
-------------------------	---------	------------------------



Info

The wide adjustment range of the chain adjusters (30 mm (1.18 in)) enables different secondary transmissions with the same chain length.
The chain adjusters ④ can be turned through 180°.

Adjusting chain guide



- Remove screws ① and ②. Take off the chain guide.

Condition

Number of teeth: ≤ 44 teeth

- Insert nut ③ in hole ④. Position the chain guide.
- Mount and tighten screws ① and ②.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

Condition


Number of teeth: ≥ 45 teeth

- Insert nut ③ in hole ⑤. Position the chain guide.
- Mount and tighten screws ① and ②.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

Checking the chain, rear sprocket and engine sprocket




- Check the rear sprocket and engine sprocket for wear.
 - » If the rear sprocket and engine sprocket are worn:
 - Replace the rear sprocket or engine sprocket.



Info

The engine sprocket, rear sprocket and chain should always be replaced together.



- Shift into neutral; pull the lower chain section with specified weight **A**.

Guideline

Weight of chain wear measurement	15 kg (33 lb.)
----------------------------------	----------------

- Measure distance **B** of 18 chain links in the lower chain section.



Info

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance B at the longest chain section	272 mm (10.71 in)
--	-------------------

- » If distance **B** is greater than the specified measurement:
 - Replace the chain.



Info

When the chain is replaced, the rear sprocket and engine sprocket should also be changed.

New chains wear out faster on old, worn sprockets.

For safety reasons, the chain has no chain joint.



- Check the chain sliding guard for wear.
 - » If the chain sliding guard is worn:
 - Replace the chain sliding guard.
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the chain sliding guard.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------



- Check the chain guide for wear.
 - » If the chain guide is worn:
 - Change the chain guide.
- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the chain guide.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	-----------------------

Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

The service life of the chain depends largely on its maintenance.



- Clean the chain regularly.
- Rinse off loose dirt with a soft jet of water.
- Remove old grease remains with chain cleaner.

Chain cleaner (☛ p. 244)

- After drying, apply chain spray.


Off-road chain spray (☛ p. 245)

Checking the rear hub rubber dampers




Info

The engine power is transmitted from the rear sprocket to the rear wheel via 6 rubber dampers. They eventually wear out during operation. If the rubber dampers are not changed in time, the rear sprocket carrier and the rear hub will be damaged.



- Remove the rear wheel. (☛ p. 75)
- Check bearing ❶.
 - » If the bearing is damaged or worn:
 - Replace the bearings.
- Check rubber dampers ❷ of the rear hub for damage and wear.
 - » If the rubber dampers of the rear hub are damaged or worn:
 - Change all rubber dampers in the rear hub.



- Lay the rear wheel on a workbench with the rear sprocket facing upwards and insert the wheel spindle in the hub.
- To check play A, hold the rear wheel tight and try to rotate the rear sprocket.



Info

Measure the play on the outside of the rear sprocket.

Play in rubber dampers, rear wheel	≤ 5 mm (≤ 0.2 in)
------------------------------------	-------------------

- » If play A is larger than the specified value:
 - Change all rubber dampers in the rear hub.
- Install the rear wheel. (☛ p. 75)

Checking the spoke tension



Warning


Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct.



Info

A loose spoke causes wheel imbalance and rapidly leads to more loose spokes. If the spokes are too tight, they can break due to local overload. Check the spoke tension regularly, especially on a new motorcycle.



- Briefly strike each spoke with a screwdriver blade.



Info

The frequency of the tone is a function of the spoke length and spoke diameter.

If you hear different tone frequencies from individual spokes of the same length and thickness, this is an indication of different spoke tensions.

You should hear a high note.


- » If the spoke tensions differ:
 - Correct the spoke tension.

Checking the rim run-out

Warning
Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct.

Info
A loose spoke can cause wheel imbalance, which leads to more loose spokes in a short time.
If the spokes are too tight, they can break due to local overload.
Check the spoke tension regularly, especially on a new motorcycle.



- Check the axial run-out and radial run-out of the rim.

Axial run-out	
outside of the rim joint	< 1.8 mm (< 0.071 in)

Radial run-out	
outside of the rim joint	< 1.8 mm (< 0.071 in)

- » If the measured value is greater than the specified value:
 - Center the rim.

Info
Center the rim by tightening the spoke nipple on the opposite side of the rim run-out. Change the rim if it is excessively deformed.

- Correct the spoke tension.


Removing the battery



Warning

Risk of injury Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- Flush with copious amounts of water in case of skin contact. If battery acid comes into contact with the eyes, flush the eyes with water for at least 15 minutes and consult a physician.




- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 66)
- Disconnect the negative (minus) cable of the battery.
- Pull off the plug connector ❶ upwards.
- Remove screws ❷.
- Pull the retaining bracket ❸ of the battery forward and remove it.
- Take off the positive pole cover ❹.
- Disconnect the positive (plus) cable of the battery.
- Push the wiring harness to the side and pull the battery out of the battery rack.



Info

Never operate the motorcycle with a discharged battery or without a battery. In both cases, electrical components and safety devices can be damaged. The vehicle is therefore no longer roadworthy.

Installing the battery



- Slide the battery into the battery rack.



Info

The battery terminals must be at the rear.


- Attach the positive cable and mount positive terminal cover ❶.
- Position retaining bracket ❷.
- Mount and tighten screws ❸.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Plug in connector ❹.
- Attach the minus cable .
- Mount the seat. (☛ p. 66)
- Set the clock. (☛ p. 96)

Disconnecting the battery




- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 66)
- Disconnect the negative (minus) cable ❶ of the battery.



Info

Never operate the motorcycle with a discharged battery or without a battery. In both cases, electrical components and safety equipment can be damaged. The vehicle is therefore no longer roadworthy.

Connecting the battery



300199-11

- Reconnect minus cable ❶.
- Mount the seat. (☛ p. 66)
- Set the clock. (☛ p. 96)

Recharging the battery



Warning

Risk of injury Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- Flush with copious amounts of water in case of skin contact. If battery acid comes into contact with the eyes, flush the eyes with water for at least 15 minutes and consult a physician.



Warning

Environmental hazard Battery parts and acid are harmful to the environment.

- Do not discard batteries with the household trash. Dispose of a defective battery in an environmentally compatible manner. Give the battery to your KTM dealer or to a recycling center that accepts used batteries.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Even when there is no load on the battery, it still loses power steadily.

The charge state and the type of charge are very important for the service life of the battery.

Rapid recharging with a high charging current shortens the battery's service life.

If the charging current, charging voltage and charging time are exceeded, electrolyte escapes through the safety valves. This reduces the battery capacity.

If the battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.

If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfate, destroying the battery.

The battery is maintenance-free, which means that the acid level does not need to be checked.

- Switch off all power consumers and switch off the engine.
- Remove the battery. (☛ p. 81)



- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (58429074000)

You can also use the battery charger to test rest potential and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery.



Info

Never remove lid ①.

Charge the battery with a maximum of 10% of the capacity specified on the battery housing ②.

- Switch off and disconnect the charger after charging.

Guideline

The charge current, charge voltage and charge time must not be exceeded.

Charge the battery regularly when the motorcycle is not in use	3 months
--	----------



- Install the battery. (☛ p. 81)

Checking the charging voltage

Condition

The battery must be fully functional and completely charged.

- Remove the seat. (☛ p. 66)
- Remove screws ①.
- Push the retaining bracket forward and take off the terminal cover.
- Start the motorcycle to make checks. (☛ p. 11)



- **V** Measure the voltage between the specified points.
Measuring point **Plus (+)** – Measuring point **Ground (-)**

Charging voltage

5,000 rpm	13.5... 15.0 V
-----------	----------------

- » If the displayed value is less than the specified value:
 - Check the plug-in connections from the alternator to the voltage regulator.
 - Check the plug-in connections from the voltage regulator to the wiring harness.
 - Check the stator winding of the alternator. (☛ p. 176)
- » If the displayed value is greater than the specified value:
 - Change the voltage regulator.

Changing the main fuse



Warning



Fire hazard The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.



Info

The main fuse protects all power consumers in the vehicle. It is in the housing of the starter relay next to the battery.



- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 66)
- Remove protection covers ❶.

- Remove a defective main fuse ❷ with needle nose pliers.
- Install a new main fuse.

Fuse (58011109130) (☛ p. 191)



Info

A reserve fuse ❸ is located in the starter relay.



- Check that the electrical equipment is functioning properly.
- Mount the protection covers.
- Mount the seat. (☛ p. 66)
- Set the clock. (☛ p. 96)

Changing fuses of individual power consumers



Info

The fuse box containing the fuses of individual power consumers is located under the seat.



- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 66)
- Open fuse box cover ❶.

- Remove the defective fuse.

Guideline

Fuse 1 - 10A - ignition, combination instrument
Fuse 2 - 10A - clock, ignition (EFI control unit)
Fuse 3 - 10A - throttle valve control unit
Fuse 4 - 10A - fuel pump
Fuse 5 - 10A - radiator fan
Fuse 6 - 10A - horn, brake light, turn signal
Fuse 7 - 15A - high beam, low beam, parking light, tail light, license plate lamp
Fuse 8 - 10A - for supplementary equipment (accessories connected with ignition switch)
Fuse 9 - 10A - for accessories (permanent positive)
Fuse 10 - not used
Fuse SPARE - 10A/15A - spare fuses



Info

A defective fuse is shown by a burned-out fuse wire A.

**Warning**

Fire hazard The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

- Replace with a spare fuse of the right rating.

Fuse (75011088010) (☛ p. 191)



Fuse (75011088015) (☛ p. 191)

**Tip**

Put a new spare fuse in the fuse box for future use if needed.

- Checking the function of power consumers.
- Close the fuse box cover.
- Mount the seat. (☛ p. 66)

Adjusting the engine characteristic



- Switch off the ignition by turning the ignition key to position **OFF** ☒.
- Remove the seat. (☛ p. 66)
- Pull the **Map-Select** switch and holder ❶ upward off of the retaining bracket.
- Pull the **Map-Select** switch out of the holder.

- Turn the adjusting wheel until the desired digit is next to marking ❷.

Set the Map-Select switch to Soft.

- Set the adjusting wheel to position 1.
- ✓ Soft – reduced homologated peak performance for better driveability.

Set the Map-Select switch to Advanced.

- Set the adjusting wheel to position 2.
- ✓ Advanced – homologated performance with extremely direct responsiveness.

Set the Map-Select switch to Standard.

- Set the adjusting wheel to position 3, 4, 5, 6, 7, 8 or 9.
- ✓ Standard – homologated performance with balanced responsiveness.

Set the Map-Select switch to poor fuel quality.

- Set the adjusting wheel to position 0.
- ✓ Poor fuel quality – homologated performance is reduced in accordance with the fuel quality, use for no more than 1 tank of fuel

- Position the **Map-Select** switch in the holder.
- Slide the **Map-Select** switch with the holder downward onto the retaining bracket.
- Mount the seat. (☛ p. 66)

Checking the front brake linings



Warning


Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately.

Note

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.



- Check the brake linings for minimum thickness **A**.

Minimum thickness A	$\geq 1 \text{ mm } (\geq 0.04 \text{ in})$
----------------------------	---

- » If the minimum thickness is less than specified:
 - Change the front brake linings. (☛ p. 86)
- Check the brake linings for damage and cracking.
 - » If there is wear or tearing:
 - Change the front brake linings. (☛ p. 86)

Changing the front brake linings



Warning

Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally.



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents Reduced braking efficiency due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!


Use only clean brake fluid from a sealed container.




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons. Make sure that no brake fluid escapes from the brake fluid reservoir. If it does, clean it up.

**Info**

Make sure when pushing back the brake pistons that you do not press the brake caliper against the spokes.




- Remove the safety clip ④, knock the pin ⑤ out to the right, and remove the brake linings.
- Clean brake caliper and brake caliper support.



- Check that leaf spring ⑥ in the brake caliper and sliding plate ⑦ in the brake caliper support are seated correctly.



- Insert the brake pads, insert the bolt and mount the split pin.
- Operate the hand brake lever repeatedly until the brake linings lie on the brake disc and there is a pressure point.



- Add brake fluid level to ①.

Guideline

Measurement of ①	5 mm (0.2 in)
------------------	---------------

Brake fluid DOT 4 / DOT 5.1 (☞ p. 242)
--

- Position the cover with the membrane. Mount and tighten the screws.

**Info**

Clean up overflowed or spilt brake fluid immediately with water.


Checking the free travel of the hand brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the hand brake lever, pressure builds up in the front brake circuit. The front brake can fail due to overheating. Adjust free travel on hand brake lever according to specifications.




- Push the hand brake to the handlebar and check free travel **A**.

Free travel of hand brake lever	$\geq 3 \text{ mm } (\geq 0.12 \text{ in})$
---------------------------------	---

- » If the free travel does not meet specifications:
 - Adjust the free travel of the hand brake lever. (☛ p. 88)

Adjusting the free travel of the hand brake lever



- Check the free travel of the hand brake lever. (☛ p. 88)
- Adjust the free travel of the hand brake lever with adjusting screw **1**.



Info

Turn the adjusting screw clockwise to reduce free travel. The pressure point moves away from the handlebar.

Turn the adjusting screw counterclockwise to increase free travel. The pressure point moves towards the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.

Do not make adjustments while riding.

Checking the front brake fluid level



Warning

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.



Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer **1**.
 - » If the brake fluid level is below the **MIN** mark:
 - Add front brake fluid. (☛ p. 89)

Adding front brake fluid

- Warning**
Danger of accidents Failure of the brake system.
- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.
- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Danger of accidents Reduced braking effect caused by old brake fluid.
- Change the brake fluid of the front and rear brake according to the service schedule.
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- i Info**
 Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
 Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
 Use only clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Add brake fluid to level A.

Guideline

Measurement of A	5 mm (0.2 in)
------------------	---------------

Brake fluid DOT 4 / DOT 5.1 (☞ p. 242)
--


- Position the cover with the membrane. Mount and tighten the screws.

- i Info**
 Clean up overflowed or spilt brake fluid immediately with water.

Changing the front brake fluid

- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


- i Info**
 Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
 Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
 Use only clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Draw the old brake fluid out of the brake fluid reservoir using a syringe and fill with fresh brake fluid.

Bleed syringe (50329050000) (🔧 p. 246)
--

Brake fluid DOT 4 / DOT 5.1 (🔧 p. 242)
--




- Pull off dust cap ❹ and connect a commercially available suction device (standard workshop equipment).
- Release bleeder screw ❺ and draw out the old brake fluid.

**Info**

During suction, ensure that the brake fluid reservoir is always filled with a sufficient amount of fresh brake fluid.

- Tighten the bleeder screw. Remove the suction device and mount the dust cap.



- Add brake fluid to level A.

Guideline

Level A	5 mm (0.2 in)
---------	---------------

Brake fluid DOT 4 / DOT 5.1 (🔧 p. 242)
--

- Position the cover with the membrane. Mount and tighten the screws.

**Info**

Clean up overflowed or spilt brake fluid immediately with water.

Checking the rear brake linings

**Warning**


Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately.

Note

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.



- Check the brake linings for minimum thickness A.

Minimum thickness A	≥ 1 mm (≥ 0.04 in)
---------------------	--------------------

» If the minimum thickness is less than specified:

- Change the rear brake linings. (🔧 p. 91)

- Check the brake linings for damage and cracking.

» If there is wear or tearing:

- Change the rear brake linings. (🔧 p. 91)

Changing rear brake linings

**Warning****Danger of accident** Brake system failure.

- Maintenance work and repairs must be carried out professionally.

**Warning****Skin irritation** Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

**Warning****Danger of accidents** Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.

**Warning****Danger of accidents** Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

**Warning****Danger of accidents** Reduced braking efficiency due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.

**Warning****Environmental hazard** Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!


Use only clean brake fluid from a sealed container.




- Stand the vehicle upright.
- Remove the screw cap ❶ with the membrane ❷.
- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons. Make sure that no brake fluid escapes from the brake fluid reservoir. If it does, clean it up.

**Info**


Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.



- Remove the safety clip ❸, knock the pin ❹ out to the left, and remove the brake linings.
- Clean brake caliper and brake caliper support.



- Check that leaf spring ⑤ in the brake caliper and sliding plate ⑥ in the brake caliper support are seated correctly.



- Insert the brake pads, insert the bolt and mount the split pin.
- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☛ p. 242)

- Mount the screw cap with the membrane.



Info

Clean up overflowed or spilt brake fluid immediately with water.


Checking the free travel of foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel ①.

Guideline

Free travel at foot brake lever	3... 5 mm (0.12... 0.2 in)
---------------------------------	----------------------------



Info

You will know that contact has been made with the foot brake cylinder piston when there is increased resistance when you activate the foot brake lever.

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. (☛ p. 92)


Adjusting the basic position of the foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Remove screws ③ on foot brake cylinder ④.
- To adjust the basic position of the foot brake lever individually, loosen nut ① and turn screw ② accordingly.

**Info**

The range of adjustment is limited. The screw must be screwed into the footrest bracket by at least four turns.

- Position foot brake cylinder ④ so that the foot brake lever has the necessary free travel. Hold screws ③ in place and tighten the nuts.

Guideline

Nut, foot brake cylinder screw	M6	10 Nm (7.4 lbf ft)
--------------------------------	----	--------------------

- Check the free travel of the foot brake lever. (☛ p. 92)
- Tighten nut ①.

Checking rear brake fluid level

**Warning**


Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.

**Warning**

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.



- Stand the vehicle upright.
- Check the brake fluid level in the brake fluid reservoir.
 - » If the fluid level reaches the **MIN** marking ①:
 - Add rear brake fluid. (☛ p. 93)

Adding rear brake fluid

**Warning**

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.

**Warning**

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

**Warning**

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.

**Warning**

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove screw cap ❶ with the washer and membrane ❷.
- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☞ p. 242)

- Mount the screw cap with the washer and membrane.

**Info**

Clean up overflowed or spilt brake fluid immediately with water.

Changing the rear brake fluid

**Warning**

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

**Warning**

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!


Use only clean brake fluid from a sealed container.



- Remove screw cap ❶ with washer ❸ and membrane ❷.
- Draw the old brake fluid out of the brake fluid reservoir using a syringe and fill with fresh brake fluid.

Bleed syringe (50329050000) (☞ p. 246)

Brake fluid DOT 4 / DOT 5.1 (☞ p. 242)



- Pull off dust cap ❹ and connect a commercially available suction device (standard workshop equipment).
- Release bleeder screw ❺ and draw out the old brake fluid.

**Info**

During suction, ensure that the brake fluid reservoir is always filled with a sufficient amount of fresh brake fluid.

- Tighten the bleeder screw. Remove the suction device and mount the dust cap.

- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☞ p. 242)

- Mount the screw cap with the washer and membrane.
- Activate the foot brake lever until there is a firm pressure point.

**Info**


Clean up overflowed or spilt brake fluid immediately with water.

Setting kilometers or miles



Info

If you change the unit, the value is retained and converted accordingly.
Making the setting according to the country.



700120-01



800083-15

Condition

The motorcycle is stationary.

(690 Enduro)

- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button pressed until the display mode changes from **km/h** to **mph** or from **mph** to **km/h**.

Guideline

Activation duration of MODE button	10 s
---	------

(690 Enduro R)

- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **M** button repeatedly until the **Odo** mode is active.
- Keep the **M** button pressed until the display mode changes from **km/h** to **mph** or from **mph** to **km/h**.

Guideline

Activation duration of M button	10 s
--	------

Setting the clock

Condition


The motorcycle is stationary.

(690 Enduro)

- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time display begins to flash.
- Press the **MODE** button to set the hour.
- Press the **SET** button to set the minute.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time is set.

(690 Enduro R)

- Switch on the ignition by turning the ignition key to position **ON** .
- Press the **M** button repeatedly until the **Odo** mode is active.
- Keep the **M** button and the **S** button pressed simultaneously.
 - ✓ The time display begins to flash.
- Press the **M** button to set the hour.
- Press the **S** button to set the minute.
- Keep the **M** button and the **S** button pressed simultaneously.
 - ✓ The time is set.



700115-10



800083-18


Combination instrument - setting/resetting TRIP 1



Info

The **TRIP 1** trip counter runs constantly and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



700121-01

(690 Enduro)

- Switch on the ignition by turning the ignition key to position **ON**
- Press the **MODE** button repeatedly until the **TRIP 1** mode is active.
- Keep the **SET** button pressed.

✓ The **TRIP 1** display is set to **0.0**.



800083-19

(690 Enduro R)

- Switch on the ignition by turning the ignition key to position **ON**
- Press the **M** button repeatedly until the **Trip 1** mode is active.
- Keep the **S** button pressed.

✓ The **Trip 1** display is set to **0.00**.


Combination instrument - setting/resetting TRIP 2



Info

The **TRIP 2** trip counter runs constantly and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



700122-01

(690 Enduro)

- Switch on the ignition by turning the ignition key to position **ON**
- Press the **MODE** button repeatedly until the **TRIP 2** mode is active.
- Keep the **SET** button pressed.

✓ The **TRIP 2** display is set to **0.0**.



800083-20

(690 Enduro R)



- Switch on the ignition by turning the ignition key to position **ON**
- Press the **M** button repeatedly until the **Trip 2** mode is active.
- Keep the **S** button pressed.

✓ The **Trip 2** display is set to **0.00**.

Combination instrument - setting the wheel circumference (690 Enduro)

Danger
Voiding of the government approval for road use and the insurance coverage The vehicle is only authorized for operation on public roads in the homologated version.

- If the vehicle is modified in any way, it may only be used on designated tracks away from public roads. Advise the vehicle owner and rider of this.
- If you undertake any modifications, please insist on receiving a signed workshop order from your customer in which you inform the customer in writing that these modifications are performed at the customer's own risk and that the vehicle will no longer be approved for use on public roads once modified.

**Condition**

The motorcycle is stationary.

- Switch off all power consumers and switch off the engine.
 - Remove the headlight mask with the headlight. (☛ p. 99)
 - Unplug connector **ED** from the combination instrument.
 - Unlock pin **18** **A** and remove it from connector **ED**.
 - Plug connector **ED** into the combination instrument.
 - Switch on the ignition by turning the ignition key to position **ON** **O**.
 - Press the **MODE** button repeatedly until the **TRIP 1** display mode is active.
 - Press and hold the **MODE** button for 10 seconds.
- ✓ The wheel circumference is displayed in millimeters.

Increasing the wheel circumference


- Press the **MODE** button **1**.

Reducing the wheel circumference

- Press the **SET** button **2**.

- Keep the **MODE** button and the **SET** button pressed simultaneously.
- ✓ The settings are saved and the Setup menu is closed.
- Switch off the ignition by turning the ignition key to position **OFF** **X**.
 - Unplug connector **ED** from the combination instrument.
 - Connect pin **18** to connector **ED**.
 - Plug connector **ED** into the combination instrument.
 - Install the headlight mask with the headlight. (☛ p. 100)

Checking the headlight setting



- Stand the vehicle upright on a horizontal surface in front of a light wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first mark.

Guideline

Distance B	5 cm (2 in)
-------------------	-------------

- Position the vehicle vertically at a distance **A** in front of the wall.

Guideline


Distance A	5 m (16 ft)
-------------------	-------------

- The rider, with luggage and a passenger if applicable, now sits down on the motorcycle.
- Switch on the low beam.
- Check the headlight setting.

For a ready-to-operate motorcycle with a rider, and with luggage and a passenger if applicable, the light-dark boundary must lie exactly on the lower mark.

- » If the boundary between light and dark does not meet specifications:
 - Adjust the headlight range. (☛ p. 99)

Adjusting the headlight range



800084-10

- Check the headlight setting. (☛ p. 98)

(690 Enduro)

- Turn adjusting screw ❶ to adjust the headlight range.

Guideline


For a motorcycle with rider, the light/dark boundary must be exactly on the lower mark (made in: Checking headlight adjustment).



Info

Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.

If you have a heavy payload, you will need to correct the headlight range.



800101-10

(690 Enduro R)

- Loosen screw ❶.
- Adjust the light range by swiveling the headlight.

Guideline

For a motorcycle with rider, the light/dark boundary must be exactly on the lower mark (made in: Checking headlight adjustment).



Info

If you have a heavy payload, you will need to correct the headlight range.

- Tighten screw ❶.

Removing the headlight mask with the headlight




100296-11

- Switch off all power consumers and switch off the engine.


(690 Enduro)

- Cover the fender with a cloth to protect it from damage.
- Remove screws ❶ on the left and right.
- Tip the headlight mask forward and pull it off in an upward direction.




100294-10

- Disconnect the connectors of turn signals ❷ and headlight ❸.
- Put down the headlight mask.




(690 Enduro R)

- Remove screw ❶ and take off the clamp.
- Release rubber band ❷. Slide the headlight mask upward and tilt it forward.




- Disconnect the electrical plug-in connection ❸ and remove the headlight mask with the headlight.

Installing the headlight mask with the headlight




(690 Enduro)

- Connect the connectors of headlight ❶ and turn signal lights ❷.
- Check lighting function.




- Remove the cloth from the fender, attach the headlight mask to points ❸ on the fender and swing it up to the steering head.




- Position brake-hose guide ❹. Mount and tighten screws ❺.

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)



(690 Enduro R)

- Connect the electrical plug-in connection ①.



- Position the headlight mask and fix it with rubber band ②.



Info

Make sure that the holding lugs engage in the fender.

- Position the brake line and wiring harness. Position the clamp, and mount and tighten screw ③.




Changing the parking light bulb

Note

Damage to reflector Reduced luminance.


- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the headlight mask with the headlight. (☞ p. 99)

(690 Enduro)


- Remove rubber cap ①.



- Pull bulb socket ② out of the reflector.
- Pull parking light bulb ③ out of the bulb socket.
- Insert a new parking light bulb in the bulb socket.

Parking light (W5W / socket W2.1x9.5d) (☞ p. 192)

- Insert the bulb socket in the reflector.
- Insert the rubber cap.

**(690 Enduro R)**

- Pull bulb socket ① out of the reflector.
- Pull parking light bulb ② out of the bulb socket.
- Insert a new parking light bulb in the bulb socket.


Parking light (W5W / socket W2.1x9.5d) (☛ p. 192)

- Insert the bulb socket in the reflector.
- Install the headlight mask with the headlight. (☛ p. 100)

Changing the headlight bulb**Note**

Damage to reflector Reduced luminance.


- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the headlight mask with the headlight. (☛ p. 99)

(690 Enduro)


- Pull off connector ①.
- Take off rubber cap ② of the headlight bulb.




- Detach spring bar ③.
- Remove headlight bulb ④.
- Insert a new headlight bulb into the headlight housing.

Headlight (H4 / socket P43t) (☛ p. 192)

- Fix the headlight bulb in the headlight using the spring bar.
- Replace the rubber cap. Attach the connector.

**(690 Enduro R)**

- Pull off connectors ①, ② and ③.
- Take off rubber cap ④ of the headlight bulb.



- Turn holder ⑤ about 30° counterclockwise and remove it.
- Remove headlight bulb.
- Insert a headlight bulb in the holder.

Headlight (S2 / socket BA20d)


- Insert the holder into the headlight housing and fix it by turning it approx. 30° clockwise.
- Replace the rubber cap. Attach the connector.
- Install the headlight mask with the headlight. (☛ p. 100)

Changing the turn signal bulb

Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



(690 Enduro, 690 Enduro R EU, 690 Enduro R AUS/UK)

- Remove the screw on the rear of the turn signal housing.
- Tilt headlamp diffuser ❶ forward carefully and take it off.
- Lightly squeeze the orange plug ❷ in the area of the holding lugs and take it off.
- Press the turn signal bulb carefully into the socket, turn it counterclockwise by about 30°, and take it out of the socket.



Info

Do not touch the reflector with your fingers, and keep it free from grease.

- Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (R10W / socket BA15s) (☛ p. 192)

- Mount the orange plug.
- Position the diffuser.
- Insert the screw and turn it counterclockwise first until it engages in the thread. Tighten the screw slightly.

(690 Enduro R USA)

- Remove the screw on the rear of the turn signal housing.
- Tilt headlamp diffuser ❶ forward carefully and take it off.
- Press the turn signal bulb carefully into the socket, turn it counterclockwise by about 30°, and take it out of the socket.



Info

Do not touch the reflector with your fingers, and keep it free from grease.


- Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (RY10W / socket BAU15s)

- Position the diffuser.
- Insert the screw and turn it counterclockwise first until it engages in the thread. Tighten the screw slightly.
- Check that the turn signal system is functioning properly.




Removing the engine




- Raise the motorcycle with the work stand. (☛ p. 9)
- Disconnect the battery. (☛ p. 81)
- Remove the exhaust manifold. (☛ p. 59)
- Drain the coolant. (☛ p. 167)
- Loosen the spring-loaded band-type clamp **1** using the special tool. Detach the radiator hoses.


Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 248)




- Remove screws **2**.



- Remove screws **3**.
- Take off the engine sprocket cover.
- Remove screw **4**.
- Take off the shift lever.



- Have an assistant operate the rear brake.
- Bend up the lock washer.
- Remove the nut of the engine sprocket with the lock washer.
- Remove screws **5**.



- Remove nut **6**. Remove the chain adjuster.
- Pull out the wheel spindle only far enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible and take the chain off the rear sprocket.



Info

The rear wheel must be fully removed.


- Take off the engine sprocket.
- Take off the clutch slave cylinder and hang it to the side.




Info

Do not bend the clutch line.


Do not operate the clutch when the clutch slave cylinder is removed.




- Take off the clutch push rod.
- Unscrew the electrical connection 7 from the starter motor.
- Remove ground wire 8 from the starter motor.




- Loosen hose clip 9.
- Pull off the throttle valve body from the rear.



- Disconnect plug-in connections 10 of the gear position sensor, the crankshaft position sensor and the alternator.
- Remove the cable binders and release the cables.




- Pull of the spark plug connector.
- Unplug the connector of the engine coolant temperature sensor 11.




- Loosen the spring-loaded band-type clamp 12 from the breather, SLS and oil return line with the special tool.

Pliers for spring-loaded band-type clamp (60029057100) (p. 248)




- Remove screws 13. Remove the engine bearer.




- Position the floor jack under the engine and fix it using the special tool.

Floor jack attachment (75029055000) (☛ p. 252)



- Remove nut 14 of the lower engine bracket. Remove the screw.



- Remove screw 15 of the swingarm pivot.
- Remove the swingarm pivot.




- Lower the engine.



Info

You should have an assistant for this step.
Make sure that the engine is sufficiently secured against falling over.
Protect the frame and attachments from damage.


Installing the engine




- Raise the engine onto the special tool and fix it.

Floor jack attachment (75029055000) (☛ p. 252)

- Position the engine in the frame.
- Mount swingarm pivot 1.
- Mount the screw of the swingarm pivot but do not tighten yet.




- Install the screw and nut 2 of the lower engine bracket, but do not tighten them yet.



- Remove the floor jack with the special tool.

Floor jack attachment (75029055000) (☛ p. 252)



- Position the engine bearer.
- Mount and tighten screws 3.

Guideline

Screw, engine bearer on frame	M10	45 Nm (33.2 lbf ft)
-------------------------------	-----	------------------------

- Mount and tighten screw 4 with nut.

Guideline

Engine carrying screw	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
-----------------------	-----	------------------------	---------------

- Tighten the swingarm pivot.


Guideline

Screw, swingarm pivot	M12x1.75	80 Nm (59 lbf ft)
-----------------------	----------	-------------------

- Tighten the lower engine bracket.


Guideline

Engine carrying screw	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
-----------------------	-----	------------------------	---------------




- Position the hoses of the engine breather, the SLS and the oil return line. Mount the spring-loaded band-type clamp 5 using the special tool.


Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 248)




- Attach the spark plug connector.
- Plug in the connector of the engine coolant temperature sensor 6.



- Reconnect plug connectors 7 of the gear position sensor, the crankshaft position sensor and the alternator.



- Position the throttle valve body.
- Position and tighten hose clip 8.




- Position the electrical connection 9 on the starter motor. Mount and tighten screw.

Screw, starter cable on starter	M5	3 Nm (2.2 lbf ft)
---------------------------------	----	-------------------

- Position the ground wire on the starter motor. Mount and tighten screw 10.

Guideline


Screw, starter motor	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
----------------------	----	--------------------	---------------



- Insert the clutch push rod.
- Position the clutch slave cylinder.
- Mount and tighten screws 11.

Guideline


Screw, clutch slave cylinder	M6x20	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch slave cylinder	M6x35	10 Nm (7.4 lbf ft)	–



- Mount the engine sprocket with the chain.
- Position the new lock washer and mount nut 12 but do not tighten yet.
- Position the rear wheel.
- Mount the chain adjuster and nut.
- Push the rear wheel forward so that the chain adjusters are on the tensioning screws, and tighten the nut 13.

Guideline

Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)
-------------------------	---------	---------------------




- Have an assistant operate the rear brake.
- Tighten the engine sprocket nut.

Guideline

Nut, engine sprocket	M20x1.5	60 Nm (44.3 lbf ft)	Loctite® 243™
----------------------	---------	---------------------	---------------

- Secure the nut with the lock washer.



- Position the rear sprocket cover.
- Mount and tighten screw 15.

Guideline

Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)
---------------------------	----	------------------------

- Mount and tighten screw 16.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Position the shift lever.
- Mount and tighten screw 17.



Guideline

Screw, shift lever	M6	10 Nm (7.4 lbf ft)	Loctite® 222
--------------------	----	-----------------------	---------------------


- Mount and tighten screws 18.

Guideline

Screw, radiator bracket	M6	5 Nm (3.7 lbf ft)
-------------------------	----	-------------------



- Position the radiator hoses. Install the spring-loaded band-type clamps 19.
- Install the exhaust manifold. (☛ p. 59)
- Disconnect the battery. (☛ p. 82)




- Remove the oil filler plug with O-ring 20 from the clutch cover and fill up with engine oil.

Engine oil	1.70 l (1.8 qt.)	Engine oil (SAE 10W/60) (00062010035) (☛ p. 242)	
		Alternative engine oil	Engine oil (SAE 10W/50) (☛ p. 242)

- Install and tighten the oil filler plug with O-ring 20.
- Fill the cooling system. (☛ p. 167)
- Remove the motorcycle from the work stand. (☛ p. 10)
- Take a short test ride.
- Read out the fault memory using the KTM diagnostics tool.
- Check the engine for leakage.
- Check the engine oil level. (☛ p. 170)
- Check the coolant level. (☛ p. 169)

Clamping engine into engine work stand



- Mount special tool ❶ on engine work stand ❷.

Engine work stand (61229001000) (☞ p. 249)

Support for engine work stand (75012001060) (☞ p. 249)

Holder for engine work stand (75012001070) (☞ p. 249)


- Mount the engine on special tool ❶.




Info

Have an assistant help you or use a crane.

Draining the engine oil




- Remove the oil drain plug ❶ with the magnet and seal ring.
- Remove plug ❷ with oil screen and the O-rings.




- Remove plug ❸ with oil screen ❹ and the O-rings.
- Completely drain the engine oil.

Removing starter motor




- Remove screws ❶. Take off the starter motor.

Removing valve cover




- Remove screws ❶. Take off the valve cover with the valve cover seal.

Removing the alternator cover




- Remove screws ❶. Take off the alternator cover.
- Remove dowels.

Removing spacer




- Remove the spacer ❶ of the countershaft.

Removing gear position sensor




- Remove screws. Remove the gear position sensor ❶.




- Remove O-ring ❷.
- Remove contact pin ❸ and the contact springs ❹.

Removing oil filter



- Remove screws. Remove the oil filter cover ❶ with the O-ring.
- Pull the oil filter element ❷ out of the oil filter case.


Circlip pliers reverse (51012011000) (☛ p. 246)



- Remove screws. Remove the oil filter cover ③ with the O-ring.
- Pull the oil filter element ④ out of the oil filter case.


Circlip pliers reverse (51012011000) (☞ p. 246)

Removing thermostat




- Remove screws. Take off the thermostat case ① with the radiator hose.
- Pull out the thermostat ②.

Setting engine to ignition top dead center



- Turn the crankshaft counterclockwise until markings ① of the camshafts are flush with the marks of the camshaft support plate.



- Remove screw ②.




Info

Look through the hole to check that the position hole of the balancer shaft is visible.


- Screw in special tool ③.

Engine blocking screw (77329010000) (☞ p. 253)

Removing water pump wheel



- Remove screws ①. Take off the water pump cover.




- Remove screw ②. Take off the water pump wheel ③.
- Take off the water pump cover seal.




Info

Do not lose the centering pins.




- Remove the shaped washer ④.

Removing clutch cover




- Remove screws ①. Take off the clutch cover.
- Take off the dowels. Remove the clutch cover seal.

Removing spacer and spring



- Remove the spacer ① and spring ② of the shift shaft.


Removing spark plug



- Remove the spark plug using the special tool ①.


Spark plug wrench (75029172000) (☛ p. 253)

Removing timing chain tensioner




- Remove screw ❶. Take off the seal ring.
- Pull out timing chain tensioner ❷.

Removing camshafts




- Remove screw ❶. Take off the camshaft support plate ❷.




- Pull the camshaft out of the bearing seats. Take the timing chain off the camshaft gear. Remove the camshaft.

Removing cylinder head



- Remove screws ❶.
- Alternately loosen screws ❷ and remove them.
- Take off the cylinder head.

Removing piston




- Take off the cylinder head gasket ❶.
- Remove screw ❷.
- Push the cylinder upward.



Info

Push the cylinder upward only far enough to allow removal of the piston pin. Ensure that the two grooved pins remain in place.



- Remove piston pin retainer ③.
- Remove the piston pin.
- Take off the cylinder with the piston.
- Push the piston upward out of the cylinder.


**Info**

If no other work is required on the cylinder and the piston, you can leave the piston in the cylinder.

- Take off the cylinder base gasket.


**Info**

Ensure that the two grooved pins remain in place.

Removing rotor

- Remove special tool ①.

Engine blocking screw (77329010000) (☞ p. 253)




- Use the special tool to hold the rotor tight.

Holding spanner (75029091000) (☞ p. 253)

- Loosen the nut ① of the rotor and remove it with the tab washer.

**Info**


The crankshaft must not be blocked.



- Install the special tool ② on the rotor. Hold it tight using the special tool and pull off the rotor by turning the screw in.

Extractor (58429009000) (☞ p. 246)

- Remove the special tool.


Removing timing chain rails

- Remove screws ①.
- Pull the timing chain guide rails ② out of the timing chain securing guide ③.

**Info**


The support bushing is plugged through the timing chain guide rails into the timing chain securing guide.

- Take out the timing chain guide rails upwards through the chain shaft.



- Hold the timing chain securing guide tight and pull the timing chain tensioning rail ④ out of the timing chain securing guide.
- Take out the timing chain tensioning rail upwards through the chain shaft.
- Remove the timing chain securing guide ③.

Removing timing chain and timing chain sprocket




- Unthread the timing chain.



Info

Mark the direction of travel.


- Take off the lock ring ①.



- Pull of the timing chain sprocket with the special tool ②.


Extractor (59029033000) (☛ p. 247)

Removing crankshaft position sensor



- Remove the screws of crankshaft position sensor ①.
- Pull cable support sleeve ② out of the engine case. Take off the crankshaft position sensor.

Removing clutch cage




- Compress the antihopping clutch with the special tool ①.

Assembly screws (75029033000) (☛ p. 250)




Info


Apply the special tool with the hand only, do not use another tool.



- Loosen the screws 2 diagonally and remove them with their spring retainers and clutch springs.
- Remove the pressure cap 3.



- Remove the pressure piece 4.
- Bend up the lock washer 5.



- Hold the clutch cage using the special tool and remove the nut 6 of the inner clutch hub.

Gear segment (75029081000) (p. 252)



Info


Make sure that the crankshaft is not blocked.

- Remove the nut 7 of the primary gear.




Info

Left-handed thread!




- Take off the stepped washer and remove the half-washers 8.
- Take off the clutch cage.



- Remove needle bearing 9 and supporting plate 10.

Removing primary gear



- Plug the special tool into the crankshaft.


Protection cover (75029090000) (☞ p. 253)

- Screw the special tool **1** on to the primary gear **2**.


Extractor (75029021000) (☞ p. 250)

- Hold it using the special tool and pull off the primary gear by turning the screw in.
- Remove the special tools.

Removing starter drive




- Remove the lock ring of the starter idler gear **1** and the torque limiter **2**.
- Take off the starter idler gear **1** with the washers.
- Remove the torque limiter **2** with the washers and needle bearing.




- Take off the free-wheel gear **3**.
- Remove the woodruff key **4** and both needle bearings **5**.

Removing shift shaft




- Push sliding plate **1** away from the shift drum locating **2**. Remove shift shaft **3** with the washer.

Removing shift drum locating




- Remove screw **1**.
- Press locking lever **2** away from shift drum locating **3** and take off the shift drum locating.
- Release the locking lever.

Removing locking lever




- Remove screw ❶.
- Take off locking lever ❷ with the sleeve and spring.


Removing oil pumps



- Remove the lock washers ❶ and normal washers ❷ from both oil pumps.
- Take off the oil pump toothed wheels ❸.




- Remove the pins ❹ and washers ❺.
- Remove screws. Take off the oil pump cover ❻.




- Remove both oil pump shafts ❷ with internal rotors ❸.
- Take the external rotors out of the engine case.

Removing left engine case



- Remove screws ❶.
- Swing the left engine case up and remove the nut or screw of the engine holder.



- Install the special tool ② with suitable screws.

Extractor (75029048000) (☛ p. 251)



Info

Use the **750** drill hole.

- Pull off the section of the engine case.




Info


Do not tension the section of the engine case.

The balancer shaft and the main shaft have a stop disk, these usually stick to the bearing.

- Take off the left section of the engine case.
- Remove the special tool.
- Remove dowels.
- Remove O-ring ③.




Removing crankshaft and balancer shaft




- Remove the crankshaft ① and the balancer shaft ②.


Removing transmission shafts



- Remove the shift rail ①.




- Swing shift forks ② to one side.
- Remove shift drum ③.




- Remove shift forks ②.

**Info**

Ensure that the pins remain in place.



- Remove the lock ring ④ and the stop disk.




- Pull both transmission shafts ⑤ out of the bearing seats together.

**Info**

The stop disk of the countershaft usually sticks to the bearing.

- Take the O-ring off the countershaft ⑥.

Work on the right section of the engine case



- Remove oil jet ❶.
- Remove bearing locks of the main shaft bearing ❸, of the countershaft bearing ❹, and of the shift drum bearing ❺.
- Remove any sealing mass remnants and clean the engine case section thoroughly.
- Pull the dowels out of the housing.
- Warm the engine case section in an oven.

Guideline


150 °C (302 °F)

- Knock the engine case section against a level wooden plate. This will cause the bearings to drop out of the bearing seats.



Info

Any bearings that remain in the engine case section must be removed using a suitable tool.



- Remove oil jet ❷.
- Remove the cover plate ❻ for the oil return line.
- Press out the shaft seal ring ❼ of the crankshaft from the inside to the outside.
- Remove the shaft seal rings ❸ of the water pump.
- Press in the shaft seal ring ❼ of the crankshaft from the outside to the inside with the open side facing in.



Info

The shaft seal ring must be flush on the outside.

- Press in the shaft seal rings of the water pump with the open side facing out so that it is flush.
- Warm the engine case section again.

Guideline

150 °C (302 °F)

- Insert the new cold bearings into the bearing seats of the hot engine case section and, if necessary, use a suitable press drift to push the bearing from the inside to the outside, all the way to the stop or so it is flush.



Info

The shift shaft bearing ❹ must be pressed in from the outside to the inside until it is flush.

When pressing the bearing in, ensure that the engine case section is level to prevent damage.

Only press the bearings in via the outer ring; otherwise, the bearings will be damaged when they are pressed in.

- After the engine case section has cooled, check that the bearings are firmly seated.



Info

If the bearings are not firmly seated after cooling, it is likely that they will rotate in the engine case when warm. In this case, the engine case must be renewed.

- Position all bearing locks. Mount and tighten the screws.

Guideline


Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
---------------------------	----	----------------------	---------------

- Mount and tighten the oil jet ❶.

Guideline

Oil jet, piston cooling	M6x0.75	4 Nm (3 lbf ft)	Loctite® 243™
-------------------------	---------	--------------------	---------------

- Mount and tighten the oil jet ❷.



Guideline

Oil jet, conrod lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
-----------------------------	----	----------------------	---------------


- Blow compressed air through all oil holes and check that they are clear.
- Position the cover plate ⑥. Mount and tighten the screws.

Guideline

Screw, cover plate for oil return line	M5	6 Nm (4.4 lbf ft)
--	----	-------------------

- Reinstall the dowels.

Work on the left section of the engine case





- Remove all dowels.
- Remove oil jet ①.
- Remove the shaft seal ring of the countershaft ② and the shift shaft ③.



Info

The shaft seal ring ④ of the crankshaft cannot be removed before the crankshaft bearing.

- Screw off the membrane support plate ⑤ and remove it together with the membrane ⑥.



- Remove the plug ⑦ and take the pressure spring ⑧ with the piston valve ⑨ out of the drill hole.
- Remove any sealing mass remnants and clean the engine case section thoroughly.
- Warm the engine case section in an oven.

Guideline

150 °C (302 °F)

- Knock the engine case section against a level wooden plate. This will cause the bearings to drop out of the bearing seats.



Info

Any bearings that remain in the engine case section must be removed using a suitable tool.

- Press out the shaft seal ring of the crankshaft from the outside to the inside.
- Press in the shaft seal ring of the crankshaft from the inside to the outside with the open side facing out.



Info

The shaft seal ring must be flush on the outside.

- Warm the engine case section again.

Guideline

150 °C (302 °F)

- Insert the new cold bearings into the bearing seats of the hot engine case section and, if necessary, use a suitable press drift to push the bearing, all the way to the stop or so that it is flush.

**Info**

When pressing the bearing in, ensure that the engine case section is level to prevent damage.

Only press the bearings in via the outer ring; otherwise, the bearings will be damaged when they are pressed in.

- After the engine case section has cooled, check that the bearings are firmly seated.

**Info**

If the bearings are not firmly seated after cooling, it is likely that they will rotate in the engine case when warm. In this case, the engine case must be renewed.

- Press in the shaft seal ring of the countershaft ② and the shift shaft ③ with the open side facing inwards so that it is flush.
- Mount and tighten the oil jet ①.

Guideline

Oil jet, piston cooling	M6x0.75	4 Nm (3 lbf ft)	Loctite® 243™
-------------------------	---------	--------------------	---------------

- Mount the dowels.
- Blow compressed air through all oil holes and check that they are clear.
- Measure the spring length of the oil pressure regulator valve.

Oil pressure regulator valve - minimum spring length	27.5 mm (1.083 in)
--	--------------------

» If the measured value does not equal the specified value:

- Change the spring.

- Check the piston valve for damage and wear.

» If there is damage or wear:

- Replace the piston valve.

- Lubricate the piston valve ⑨ and mount it with the pressure spring ⑧. Mount and tighten plug ⑦ with the new seal ring.

Guideline

Oil pressure regulator valve plug	M12x1.5	20 Nm (14.8 lbf ft)
-----------------------------------	---------	------------------------

- Position the membrane support plate ⑤ with the membrane ⑥. Mount and tighten the screws.

Guideline




Screw, membrane fixation	M3	2.5 Nm (1.84 lbf ft)	Loctite® 243™
--------------------------	----	-------------------------	---------------

**Info**

The membrane support plate is curved and must point away from the membrane.

An incorrectly installed membrane support plate results in loss of performance and increased oil consumption or leaks.

Do not apply thread locking material between the membrane and the membrane support plate since this would badly affect the functioning.

**Work on the clutch cover**


- Remove the shaft seal ring ① of the crankshaft.
- Press in a new shaft seal ring with the open side facing inward until it stops.

**Info**

Support the clutch cover sufficiently when pressing in.

- Blow compressed air through the oil channel and check that it is clear.


Removing crankshaft bearing inner ring



- Fix the crankshaft with special tools ❶ and ❷ in the vise.

Upper part, pressing-out tool (75029047050) (☞ p. 251)

Under part, pressing-out tool (75029047051) (☞ p. 251)



- Heat the special tool ❸.


Guideline

150 °C (302 °F)

Tool for inner bearing race (58429037043) (☞ p. 247)


- Push the heated special tool ❸ on to the inner bearing race, press them hard together, and pull them together off the crankshaft.
- Take off the compensation shim.
- Repeat the operation on the opposite side.

Removing balancer shaft drive wheel



- Remove the crankshaft bearing inner ring. (☞ p. 125)
- Screw in 2 M6 screws ❶ in the threads. Tighten the two screws evenly to pull the drive wheel ❷ off the crankshaft.

Changing the conrod bearing



- Remove the drive wheel of the balancer shaft. (☞ p. 125)
- Position the crankshaft with the special tool ❶ in the press.

Under part, pressing-out tool (75029047051) (☞ p. 251)

- Position the special tool ❷ between the crankwebs.

Upper part, pressing-out tool (75029047050) (☞ p. 251)

- Press the crank pin with the push-out drift of the special tool out of the upper crankweb.


Pressing device for crankshaft, complete (75029047000) (☞ p. 251)




Info

Hold the lower crankweb.

- Take off the connecting rod and bearing.
- Press the crank pin out of the crankweb.






- Press in the new crank pin ③ as far as possible.

**Info**

The crank pin must be pressed in so that oil hole ④ is aligned with oil hole ⑤.

If the oil holes are not correctly aligned, the conrod bearing will not be supplied with oil.


- Blow compressed air through the oil passage to check that it is clear.



- Install the bearing ④ and the connecting rod ⑤.

**Info**


Lubricate the bearing thoroughly.



- Position special tool ⑥ on the press.

Pressing device for crankshaft, complete (75029047000) (☛ p. 251)

- Place the crankweb in with the connecting rod and the bearing. Position the second crankweb.



- Position the special tool ⑦ with the heel at the bottom.

Pressing device for crankshaft, complete (75029047000) (☛ p. 251)

- Press the upper crankweb in as far as possible.

**Info**

The press mandrel must be applied above the crank pin.

- Take the crankshaft out of the special tool, and check the connecting rod for freedom of movement.

- Measure the axial clearance between the connecting rod and the crankwebs using the special tool ⑧.

Feeler gauge (59029041100) (☛ p. 248)


Connecting rod - axial clearance of lower conrod bearing	0.40... 0.60 mm (0.0157... 0.0236 in)
--	---------------------------------------

» If the specified value is not met:


- Correct until it complies with the specified value.

- Check the crankshaft run-out at the bearing pin. (☛ p. 127)

- Install the drive wheel of the balancer shaft. (☛ p. 127)



Checking crankshaft run-out at bearing pin




- Position the crankshaft on a roller block.
- Rotate the crankshaft slowly.
- Check the crankshaft run-out at both bearing pins.

Crankshaft run-out at bearing pin	$\leq 0.10 \text{ mm}$ ($\leq 0.0039 \text{ in}$)
-----------------------------------	---

- » If the crankshaft run-out at the bearing pin is greater than the specified value:
 - Align the crankshaft.

Installing balancer shaft drive wheel



- Fix the crankshaft with special tools ❶ and ❷ in the vise.


Upper part, pressing-out tool (75029047050) (☛ p. 251)
--

Under part, pressing-out tool (75029047051) (☛ p. 251)
--


- Warm the drive wheel.

Guideline


100 °C (212 °F)



- Place the drive wheel on the crankshaft.
 - ✓ The dowel of the crankshaft must fit in the drill hole ❹.
 - ✓ The side of the drive wheel with the punch mark ❸ must be visible after assembly, and the side with the bevel ❷ must be in contact with the crankweb.
- Install the crankshaft bearing inner ring. (☛ p. 127)



Installing crankshaft bearing inner ring



- Fix the crankshaft with special tools ❶ and ❷ in the vise.

Upper part, pressing-out tool (75029047050) (☛ p. 251)
--

Under part, pressing-out tool (75029047051) (☛ p. 251)
--

- Push on the compensation shim.
- Heat the special tool. Install the inner bearing race.

Guideline

120 °C (248 °F)


- Repeat the operation on the opposite side.
- Make sure that the new inner ring is flush installed.



Info

After changing the crankshaft bearing, measure the axial clearance of the crankshaft.

Measuring axial clearance of crankshaft and balancer shaft



- Insert the crankshaft and balancer shaft in the right engine casing.

**Info**

Do not forget the dowels.

- Mount the left engine casing.
- Mount and tighten the screws.

Guideline

Screw, engine case	M6	10 Nm (7.4 lbf ft)
--------------------	----	--------------------

- Mount the dial gauge support on the engine case and measure and note the axial clearance of the crankshaft.

Guideline

Crankshaft - axial clearance	0.15... 0.25 mm (0.0059... 0.0098 in)
------------------------------	---------------------------------------

- » If the measured value does not equal the specified value:
 - Remove the crankshaft.
 - Remove the crankshaft bearing inner ring. (☛ p. 125)
 - Calculate the thickness of the compensation shims.
 - Add or remove compensation shims equally on both sides.

**Info**

If the axial clearance is too small, remove compensation shims.
If the axial clearance is too large, add compensation shims.

- Install the crankshaft bearing inner ring. (☛ p. 127)

- Mount the dial gauge support on the engine case and measure and note the axial clearance of the balancer shaft.

Guideline

Balancer shaft axial clearance	0.05... 0.20 mm (0.002... 0.0079 in)
--------------------------------	--------------------------------------

- » If the measured value does not equal the specified value:
 - Remove the balancer shaft.
 - Calculate the thickness of the compensation shims.
 - Add compensation shims to the ignition side only.

**Info**

If the axial clearance is too small, remove compensation shims.
If the axial clearance is too large, add compensation shims.




Cylinder - Nikasil® coating



Nikasil® is a surface protection layer for a coating method developed by the Mahle company. The name is derived from the two materials used in this method - a layer of nickel, in which silicon carbide (a particularly hard substance) is embedded. The most important advantages of the **Nikasil®** coating are the excellent heat conductivity resulting in better performance, less wear, and low cylinder weight.

Checking/measuring the cylinder




- Check the O-ring of the chain adjuster for damage and wear.
 - » If there is damage or wear:
 - Replace the O-ring.
- Check the cylinder bearing surface for damage.
 - » If the cylinder bearing surface is damaged:
 - Change the cylinder and piston.
- Measure the cylinder diameter at several places in the **x** and **y** axes using a micrometer to check for oval wear.
- To determine the size, measure the cylinder at a distance **B** from the top edge of the cylinder.

Guideline

Distance B	55 mm (2.17 in)
Cylinder - bore diameter	
Size I	102.000... 102.012 mm (4.01574... 4.01621 in)
Size II	102.013... 102.025 mm (4.01625... 4.01672 in)



- The cylinder size **1** is marked on the side of the cylinder.




- Check the sealing area of the cylinder head for distortion using a straight edge and the special tool.

Feeler gauge (59029041100) (☛ p. 248)	
Cylinder/cylinder head - sealing area distortion	≤ 0.10 mm (≤ 0.0039 in)

- » If the measured value does not equal the specified value:
 - Change the cylinder.

Checking/measuring the piston



- Use the special tool to measure clearance **A** of the piston rings in the piston ring groove.

Guideline

Piston ring - groove clearance	≤ 0.08 mm (≤ 0.0031 in)
Feeler gauge (59029041100) (☛ p. 248)	

- » If clearance **A** is larger than the specified value:
 - Change the piston and piston rings.
 - Check/measure the cylinder. (☛ p. 129)



- Check the piston bearing surface for damage.
 - » If the piston bearing surface is damaged:
 - Change the piston and, if necessary, the cylinder.
- Check that the piston rings can move easily in the piston ring grooves.
 - » If the piston ring is stiff:

- Clean the piston ring groove.

**Tip**

Use an old piston ring to clean the piston ring groove.

- Check the piston rings for damage.
 - » If the piston ring is damaged:
 - Change the piston ring.


**Info**

Mount the piston ring with the marking facing upward.

- Check the piston pin for discoloration or signs of wear.
 - » If the piston pin has strong discoloration/signs of wear:
 - Change the piston pin.
- Insert the piston pin into the connecting rod and check the bearing for play.
 - » If the piston pin bearing has too much play:
 - Change the connecting rod and the piston pin.
- Measure the piston at the piston skirt, at right angles to the piston pin, at a distance ❷.


Guideline

Distance ❷	31.5 mm (1.24 in)
Piston - diameter	
Size I	101.955... 101.965 mm (4.01397... 4.01436 in)
Size II	101.965... 101.975 mm (4.01436... 4.01476 in)

**Info**

Piston size ❶ is marked on the piston head.

Checking piston ring end gap



- Remove the piston ring from the piston.
- Place the piston ring in the cylinder and align it with the piston.

Guideline

Under the upper edge of the cylinder	10 mm (0.39 in)
--------------------------------------	-----------------

- Measure the end gap with a feeler gauge ❶.

Guideline

Piston ring end gap	
Compression rings	≤ 0.80 mm (≤ 0.0315 in)
Oil scraper ring	≤ 1.00 mm (≤ 0.0394 in)

- » If the end gap is more than the specified value:
 - Check/measure the cylinder. (➡ p. 129)
- » If the cylinder wear is within the tolerance range:
 - Change the piston ring.
- Mount the piston ring with the marking facing toward the piston head.

Checking piston/cylinder mounting clearance

- Check/measure the cylinder. (☛ p. 129)
- Check/measure the piston. (☛ p. 129)
- The smallest piston/cylinder mounting clearance is the result of the smallest cylinder bore diameter minus the largest piston diameter. The largest piston/cylinder mounting clearance is the result of the largest cylinder bore diameter minus the smallest piston diameter.

Guideline


Piston/cylinder - mounting clearance	
New condition	0.035... 0.060 mm (0.00138... 0.00236 in)
Wear limit	0.10 mm (0.0039 in)

Checking oil pumps for wear



Info

The oil pump wear check shown here is on the suction pump but it applies to all oil pumps.




- Use a feeler gauge ❶ to measure the play between the external rotor and the engine case as well as between the external rotor and the internal rotor.


Oil pump	
Clearance between external rotor and engine case	≤ 0.20 mm (≤ 0.0079 in)
Clearance between external rotor and internal rotor	≤ 0.20 mm (≤ 0.0079 in)
Axial clearance	0.04... 0.08 mm (0.0016... 0.0031 in)

- » If the measured value does not meet specifications:
 - Change the oil pump and, if necessary, the engine case.


Replacing autodecompressor




- Take the lock ring ❶ off the autodecompression shaft and dispose of it.



- Pull the autodecompression shaft ❷ from the camshaft.



- Disconnect the autodecompression spring. Loosen the screw ❸ and remove it together with the autodecompression spring and the autodecompression weight ❹.



- When assembling, first connect the autodecompression spring and then insert the screw through the autodecompression weight.
 - ✓ The arm of the autodecompression spring ❸ is long enough to pass right through the autodecompression weight.
- Position the autodecompression weight. Mount and tighten screw ❸. Reconnect the autodecompression spring.

Guideline

Screw, autodecompression	M6	3... 4 Nm (2.2... 3 lbf ft)	Loctite® 243™
--------------------------	----	--------------------------------	---------------

- Mount the autodecompression shaft in the camshaft. Install a new lock ring.
- Check the functioning.
 - » If the autodecompression spring does not completely retract the autodecompression shaft:
 - Replace the autodecompression spring.

Preparing timing chain tensioner for installation



- Fully compress the timing chain tensioner.



Info

This requires considerable force since the oil has to be pressed out.

- Release the timing chain tensioner.
 - ✓ Without pressure, the timing chain tensioner expands fully.



- Place two spacing washers or similar aids next to the piston of the timing chain tensioner. This should ensure that when pushed down, the piston does not fully withdraw.

Guideline

Thickness of spacers	2... 2.5 mm (0.08... 0.098 in)
----------------------	--------------------------------

- Release the timing chain tensioner.
 - ✓ The latching system locks and the piston stops moving.


End position of piston after latching	3 mm (0.12 in)
---------------------------------------	----------------



Info


This position is necessary for installation.
If the timing chain tensioner is now pressed in once more (while it is installed) and then pulled out no more than halfway (preventing it from coming out fully), the latching system locks and the timing chain tensioner can no longer be compacted; this function is necessary to ensure sufficient tension of the timing chain, even at low oil pressure.

Checking timing assembly




- Clean all parts well.
- Check the timing chain gear / timing chain sprocket ❶ for damage and wear.
 - » If there is damage or wear:
 - Replace the timing chain gear / timing chain sprocket.
- Check timing chain tensioning rail ❷ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain tensioning rail.
- Check timing chain guide rail ❸ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain guide rail.
- Check timing chain securing guide ❹ for damage and wear.
 - » If there is damage or wear:
 - Replace the timing chain securing guide.
- Check timing chain ❺ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain.
- Check that the timing chain links move easily. Let the timing chain hang down freely.
 - » If the chain links no longer straighten out:
 - Change the timing chain.

Removing rocker arm




- Remove screws ❶.



- Screw a suitable screw ❸ into the rocker arm shafts ❷. Pull out the rocker arm shafts.
- Take off the rocker arm ❹.


Changing camshaft bearing



- Remove the rocker arm. (☛ p. 133)
- Clamp the cylinder head.

Clamping plate (75029050000) (☛ p. 252)
- Remove the large camshaft bearing using the special tool ❶.


Push-out drift (75029051000) (☛ p. 252)



- Remove the small camshaft bearing ❷ using the special tool.


Insert for bearing puller (15112018100) (☛ p. 246)

Bearing puller (15112017000) (☛ p. 246)



- Press in the small camshaft bearing as far as possible using the special tool ❸.

Push-in drift (75029044020) (☛ p. 251)




- Press in the large camshaft bearing as far as possible using the special tool ❹.


Push-in drift (75029044010) (☛ p. 250)

- Install the rocker arm. (☛ p. 137)

Removing valves



- Take the shims ❶ out of the valve spring retainers and lay them to one side according to their normal built-in position.




- Pretension the valve springs using the special tool.

Valve spring compressor (59029019000) (☛ p. 247)

Valve spring mounting device (78029060000) (☛ p. 254)

- Remove valve keys and release tension on the valve springs.
- Remove spring retainers and spring.
- Pull the valve down and out of the valve guide, remove the valve stem seal and valve spring retainer.

- Mark the valves according to their normal built-in position.



Info

Place the valve into a box according to the installation position and label the box.


Checking valves



- Check the run-out at the valve plate.

Valve - run-out	
On the valve plate	$\leq 0.05 \text{ mm } (\leq 0.002 \text{ in})$

- » If the measured value does not equal the specified value:
 - Change the valve.



- Check the sealing seat **A** on the valve.

Valve - sealing seat width	
Intake	1.60 mm (0.063 in)

Valve - sealing seat width	
Exhaust	2.00 mm (0.0787 in)

- » If the sealing area is not in the center of the valve seat or deviates from the specified value:
 - Machine the valve seat.

Checking valve springs



- Check the valve springs for fractures and wear (visual check).
 - » If the valve spring is fractured or worn:
 - Change the valve spring.
- Measure the valve spring lengths.

Valve spring	
Minimum length (without valve spring cap)	42.3 mm (1.665 in)

- » If the measured value does not equal the specified value:
 - Change the valve spring.

Checking valve spring retainer




- Check the valve spring retainer for fractures and wear (visual check).
 - » If the valve spring retainer is fractured or worn:
 - Change the valve spring retainer.
- Measure the thickness of the valve spring retainer.

Valve spring cap - thickness	2.4... 2.5 mm (0.094... 0.098 in)
------------------------------	-----------------------------------

- » If the measured value does not equal the specified value:
 - Change the valve spring retainer.


Checking cylinder head



- Check the valve guides using the special tool **1**.

Limit plug gauge (59029026006) (☞ p. 247)

- » If the special tool is easy to insert into the valve guide:
 - Change the valve guide and valve.
- Check the sealing area of the spark plug thread and the valve seats for damage and tearing.
 - » If there is wear or tearing:
 - Change the cylinder head.




- Check the sealing area of the cylinder for distortion using a straight edge and the special tool.

Feeler gauge (59029041100) (☛ p. 248)

Cylinder/cylinder head - sealing area distortion	≤ 0.10 mm (≤ 0.0039 in)
--	-------------------------

- » If the measured value does not equal the specified value:
 - Change the cylinder head.



- Check sealing seat **A** of the valves.

Valve - sealing seat width


Intake	1.60 mm (0.063 in)
--------	--------------------

Valve - sealing seat width


Exhaust	2.00 mm (0.0787 in)
---------	---------------------

- » If the measured value does not equal the specified value:
 - Machine the valve seat.
- Blow compressed air through all oil holes and check that they are clear.

Installing valves




- Position the valve spring cap **1**. Install new valve stem seals **2**.
- Install the valves **3** according to their normal built-in position.
- Install the valve springs **4** and the spring retainers.



- Pretension the valve springs using the special tool.

Valve spring compressor (59029019000) (☛ p. 247)

Valve spring mounting device (78029060000) (☛ p. 254)



- Mount valve keys.




Info

When mounting the valve keys, check that they are seated correctly; preferably, fix the valve keys to the valve with a little grease.

- Place shims **5** into the valve spring retainers according to the installation position.

Installing rocker arm




- Position the rocker arm ❶ and push in the rocker arm shafts ❷.

**Info**

Make sure that the tapped hole of the rocker arm shaft is positioned facing outwards.

The small drill hole and the flat surface must point upwards.




- Install and tighten the screws ❸ of the rocker arm shafts.

Guideline

Screw, rocker arm shaft	M6	12 Nm (8.9 lbf ft)
-------------------------	----	--------------------

Dismantling antihopping clutch




- Clamp the clutch ❶ in a vise.


**Info**

Use soft jaws.

- Carefully loosen and gradually remove the special tool ❷.




- Take the clutch out of the vise and lay it on a clean workbench with the outer clutch hub ❸ facing down.
- Take the inner clutch hub ❹ and release springs ❺ out of the outer clutch hub ❸.



- Take off the clutch disks ❻ from the inner clutch hub.
- Remove pretension ring ❼ and support ring ❸.
- Clean all parts well.
- Check the clutch. (☛ p. 138)

Checking the clutch

- Dismantle the antihopping clutch. (☛ p. 137)



300123-01

- Check pressure piece **1** for damage and wear.
 - » If there is damage or wear:
 - Replace the pressure piece.
- Check axial bearing **2** for damage and wear.
 - » If there is damage or wear:
 - Change the axial bearing.
- Place push rod **3** on a level surface and check it for run-out.
 - » If there is run-out:
 - Change the push rod.
- Check the length of clutch springs **4**.

Clutch spring - length	31.5... 33.5 mm (1.24... 1.319 in)
------------------------	------------------------------------

- » If the clutch spring length is less than the specified value:
 - Change all clutch springs.
- Check the contact surface of pressure cap **5** for damage and wear.
 - » If there is damage or wear:
 - Change the pressure cap.
- Check the contact surfaces of the clutch facing discs in the outer clutch hub **6** for wear.

Clutch cage - contact surface of clutch facing discs	≤ 0.5 mm (≤ 0.02 in)
--	----------------------


- » If the contact surface is very worn:
 - Change the clutch facing discs and the outer clutch hub.
- Check needle bearing **7** and supporting plate **8** for damage and wear.
 - » If there is damage or wear:
 - Replace the needle bearing and supporting plate.
- Check intermediate discs **9** for damage and wear.

- » If the intermediate discs are not level or are pitted:
 - Replace all intermediate discs.
- Check clutch facing discs ⑩ for discoloration and scoring.
 - » If there is discoloration or scoring:
 - Change all clutch facing discs.
- Check the thickness of clutch facing discs ⑩.

Clutch facing disc - thickness	≥ 2.5 mm (≥ 0.098 in)
--------------------------------	-----------------------

- » If the clutch facing disc does not meet specifications:
 - Change all clutch facing discs.
- Check stepped washer ⑪ for damage and wear.
 - » If there is damage or wear:
 - Replace the stepped washer.
- Check half washers ⑫ for damage and wear.
 - » If there is damage or wear:
 - Replace the half washers.
- Check inner clutch hub ⑬ for damage and wear.
 - » If there is damage or wear:
 - Replace the inner clutch hub.
- Check the outer clutch hub ⑭ for damage and wear.
 - » If there is damage or wear:
 - Replace the outer clutch hub.
- Preassemble the antihopping clutch. (🔧 p. 139)

Preassembling antihopping clutch




- Lubricate the clutch discs thoroughly.
- Push the support ring ① and the pretension ring ② on to the outer clutch hub.




Info

The pretension ring must be installed so that it is flush with the inner edge A on the support ring.



- Position the trimmed clutch facing disc with the notch for the pretension ring on the outer clutch hub.
- Beginning with a clutch disc, position all further clutch facing discs and clutch discs alternately.
- Position the release springs ③.



- Push on the outer clutch hub ④ and pay attention to the markings.
 - ✓ The arrow ⑥ of the outer clutch hub must point to the notch ⑤ of the inner clutch hub.
- Push the two clutch hubs firmly together and have an assistant screw in the special tool.


Assembly screws (75029033000) (🔧 p. 250)



Info

Apply the special tool with the hand only, do not use another tool. Apply the special tool only firmly enough to all the clutch discs to be turned against each other since they still have to be aligned for mounting in the clutch cage.


Checking shift mechanism




- Check the shift forks **1** (see **A**) for damage and wear (visual check).
 - » If there is damage or wear:
 - Change the shift fork and the idler/fixed gear pair.
- Check shift grooves **B** of shift drum **2** for wear.
 - » If the shift groove is worn:
 - Change the shift roller.
- Check the seat of the shift drum in the bearings **3**.
 - » If the shift roller is not seated correctly:
 - Replace the shift drum and/or the bearing.
- Check bearing **3** for stiffness and wear.
 - » If the bearings do not move freely or are worn:
 - Replace the bearings.
- Check the needle bushing **4** for stiffness and wear.
 - » If the needle bushing does not move freely or is worn:
 - Replace the needle bushing.
- Check the shift rail **5** on a flat surface for run-out.
 - » If there is run-out:
 - Change the shift rail.
- Check the shift rail for scoring, signs of corrosion and stiffness in the shift forks.
 - » If there is scoring or corrosion, or if the shift fork is stiff:
 - Change the shift rail.
- Check sliding plate **6** in contact areas **C** for wear.
 - » If the sliding plate is worn:
 - Change the sliding plate.
- Check return surface **D** on the sliding plate for wear.
 - » If deep notches are present:
 - Change the sliding plate.
- Check guide pin **E** for looseness and wear.
 - » If the guide pin is loose and/or worn:
 - Change the sliding plate.
- Preassemble the shift shaft. (☛ p. 140)
- Check the clearance **F** between the sliding plate and the shift quadrant.

Shift shaft - play in sliding plate/shift quadrant	0.40... 0.80 mm (0.0157... 0.0315 in)
--	---------------------------------------


- » If the measured value does not equal the specified value:
 - Change the sliding plate.



Preassembling shift shaft



- Fix the short end of the shift shaft in a vise.
- Guideline
- | |
|----------------|
| Use soft jaws. |
|----------------|
- Mount sliding plate **1** with the guide pin facing down and attach the guide pin to the shift quadrant.
 - Mount preload spring **2**.
 - Push on spring guide **3**, push return spring **4** over the spring guide with the offset end facing upward and lift the offset end over abutment bolt **5**.
 - Mount stop disk **6**.

Disassembling the main shaft**(690 Enduro EU)**


- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws.

- Remove stop disk ① and second-gear fixed gear ②.
- Remove the sixth-gear idler gear ③.
- Remove the split needle bearing ④ and stop disk ⑤.
- Remove lock ring ⑥.
- Remove the third/fourth-gear sliding gear ⑦.
- Remove lock ring ⑧.
- Remove stop disk ⑨ and the fifth-gear idler gear ⑩.
- Remove the split needle bearing ⑪.

(690 Enduro R)




- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws.

- Remove stop disk ① and second-gear fixed gear ②.
- Remove the sixth-gear idler gear ③.
- Remove the split needle bearing ④ and stop disk ⑤.
- Remove lock ring ⑥.
- Remove the third/fourth-gear sliding gear ⑦.
- Remove lock ring ⑧.
- Remove stop disk ⑨ and the fifth-gear idler gear ⑩.
- Remove bearing bush ⑪.

Dismantling countershaft



- Fix the countershaft in the vise with the geared end facing downward.

Guideline

Use soft jaws


- Remove stop disk ① and the first-gear idler gear ②.

- Remove needle bearing ③ and stop disk ④.
- Remove the fifth-gear sliding gear ⑤ and lock ring ⑥.
- Remove stop disk ⑦ and the third-gear idler gear ⑨.
- Remove the needle bearing ⑧ and the fourth-gear idler gear ⑩.
- Remove needle bearing ⑩ and stop disk ⑫.
- Remove lock ring ⑬ and the sixth-gear sliding gear ⑭.
- Remove lock ring ⑮ and stop disk ⑯.
- Remove the second-gear idler gear ⑰ and needle bearing ⑱.

Checking the transmission

- Disassemble the main shaft. (☛ p. 141)
- Dismantle the countershaft. (☛ p. 142)


(690 Enduro EU)



- Check needle bearing ① for damage and wear.
 - » If there is damage or wear:
 - Change the needle bearing.
- Check the pivot points of main shaft ② and countershaft ③ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the tooth profiles of main shaft ② and countershaft ③ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the pivot points of idler gears ④ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the shift dogs of idler gears ④ and fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth faces of idler gears ④ and fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth profiles of fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check fixed gears ⑤ for smooth operation in the profile of main shaft ②.

- » If the fixed gear does not move easily:
 - Change the fixed gear or the main shaft.
- Check fixed gears ⑤ for smooth operation in the profile of countershaft ③.
- » If the fixed gear does not move easily:
 - Change the fixed gear or the countershaft.
- Check stop disks ⑥ for damage and wear.
 - » If there is damage or wear:
 - Change the stop disk.
- Use new lock rings ⑦ in every repair job.

(690 Enduro R)



- Check needle bearing ① for damage and wear.
 - » If there is damage or wear:
 - Change the needle bearing.
- Check the pivot points of main shaft ② and countershaft ③ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the tooth profiles of main shaft ② and countershaft ③ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the pivot points of idler gears ④ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the shift dogs of idler gears ④ and fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth faces of idler gears ④ and fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth profiles of fixed gears ⑤ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check fixed gears ⑤ for smooth operation in the profile of main shaft ②.
 - » If the fixed gear does not move easily:
 - Change the fixed gear or the main shaft.
- Check fixed gears ⑤ for smooth operation in the profile of countershaft ③.

- » If the fixed gear does not move easily:
 - Change the fixed gear or the countershaft.
- Check stop disks ⑥ for damage and wear.
 - » If there is damage or wear:
 - Change the stop disk.
- Use new lock rings ⑦ in every repair job.
- Check bearing bush ⑧ for damage and wear.
 - » If there is damage or wear:
 - Change the bearing bush.
- Assemble the countershaft. (☛ p. 146)
- Assemble the main shaft. (☛ p. 145)

Assembling the main shaft




Info

Use new lock rings in every repair job.

- Oil all parts carefully before assembling.
- Check the transmission. (☛ p. 143)

(690 Enduro EU)




- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws

- Mount split needle bearing ① and put on the fifth-gear idler gear ② with the shift dogs facing upward.
- Mount stop disk ③ and lock ring ④.
- Push on the third/fourth-gear sliding gear ⑤ with the small gear wheel pointing downward, and mount lock ring ⑥.
- Push on stop disk ⑦ and split needle bearing ⑧.
- Put on the sixth-gear idler gear ⑨ with the shifting claws facing downward.
- Mount the second-gear fixed gear ⑩ with the collar facing downward and mount stop disk ⑪.
- Finally, check all gear wheels for smooth operation.

(690 Enduro R)



- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws

- Lubricate and mount bearing bush ①.

Long-life grease (☛ p. 244)

- Put on the fifth-gear idler gear ② with the shifting claws facing upward.
- Mount stop disk ③ and lock ring ④.
- Push on the third/fourth-gear sliding gear ⑤ with the small gear wheel pointing downward, and mount lock ring ⑥.
- Push on stop disk ⑦ and split needle bearing ⑧.
- Put on the sixth-gear idler gear ⑨ with the shifting claws facing downward.
- Mount the second-gear fixed gear ⑩ with the collar facing downward and mount stop disk ⑪.
- Finally, check all gear wheels for smooth operation.


Assembling countershaft



Info

Use new lock rings in every repair job.

- Oil all parts carefully before assembling.
- Check the transmission. (☛ p. 143)



300128-02


- Fix the countershaft in the vise with the geared end facing downward.

Guideline

Use soft jaws

- Mount needle bearing ① and the second-gear idler gear ② on the countershaft with the protruding collar facing downward.
- Mount stop disk ③ and lock ring ④.
- Mount the sixth-gear sliding gear ⑤ with the shift groove facing upward.
- Install lock ring ⑥ and stop disk ⑦.
- Mount needle bearing ⑧ and the fourth-gear idler gear ⑨ with the collar facing upward.
- Mount needle bearing ⑩ and the third-gear idler gear ⑪ with the collar facing downward.
- Install stop disk ⑫ and lock ring ⑬.
- Mount the fifth-gear sliding gear ⑭ with the shift groove facing downward and stop disk ⑮.
- Mount needle bearing ⑯, first-gear idler gear ⑰ with the groove facing downward and stop disk ⑱.
- Finally, check all gear wheels for smooth operation.

Checking electric starter drive




300129-01

- Check the teeth and seating of the starter idler gear ① for damage and wear.
 - » If there is damage or wear:

- Replace the starter idler gear and/or needle bushing.
- Check the teeth and seating of the torque limiter ❷ for damage and wear.
 - » If there is damage or wear:
 - Replace the torque limiter and/or needle bushing.
- Check freewheel gear ❸ and bearing when removed for damage and wear.
 - » If there is damage or wear:
 - Replace the freewheel gear and/or the bearing.
- Check the freewheel ❹ when removed for damage and wear.
 - » If there is damage or wear:
 - Replace the freewheel.
- Check the toothing of the starter motor ❺ for damage and wear.
 - » If there is damage or wear:
 - Replace the starter motor.
- Clamp the minus (negative) cable of a 12 Volt power supply to the starter motor housing. Briefly connect the plus (positive) cable of the power supply to the starter motor connection.
 - » If the starter motor does not turn when you close the power circuit:
 - Replace the starter motor.
- Replace the O-ring ❻ of the starter motor.

Removing freewheel




- Extract the lock ring ❶ from the groove using suitable pliers.



- Compress the expansion ring ❷ and remove it, using suitable pliers.
- Take the freewheel ❸ out of the primary gear.

Checking freewheel



- Insert the freewheel gear ❶ in the primary gear ❷, turning the primary gear clockwise; do not twist!
- Check the locking action of the freewheel gear ❶.
 - » If the primary gear does not turn clockwise or if it does not lock counterclockwise:
 - Remove the freewheel. (🔧 p. 148)
 - Turn the freewheel 180°.
 - Install the freewheel. (🔧 p. 149)


Installing freewheel




- Lubricate all parts thoroughly.
- Push the freewheel ❶ into the primary gear.

**Info**

Note the direction of rotation.




- Install the expansion ring ❷.



- Make sure that all lugs of the expansion ring locate in the slits ❸ of the freewheel.


**Info**

If necessary, use a screwdriver to ease them in.



- Insert the lock ring ❸ into the groove with suitable pliers and check that it is seated correctly.

Installing transmission shafts




- Clamp the right section of the engine case.

Holder for engine work stand (75012001070) (☛ p. 249)


Support for engine work stand (75012001060) (☛ p. 249)
--

Engine work stand (61229001000) (☛ p. 249)
--

- Make sure that both stop disks 1 are installed.
- Mount the inner bearing race 2 on the countershaft.




- Lubricate all bearings.
- Assemble the two transmission shafts and slide them into the bearing seats together.




- Mount the upper shift fork 3, the middle shift fork 4, and the lower shift fork 5.

**Info**


For the assembly of the middle shift fork 4, the sliding gear of the third/fourth gear must be lifted.



- Insert shift drum 6 into the bearing seat.
- Hang the shift forks into the shift drum.




- Install the shift rail 7.
- Check the transmission for smooth operation.



- Install the shim 8 and lock ring of the countershaft.

Installing crankshaft and balancer shaft




- Mount the special tool ❶ on the alternator side of the crankshaft.

Mounting sleeve (75029080000) (☛ p. 252)


- Mount the special tool ❷ on the balancer shaft.

Mounting sleeve (58529005000) (☛ p. 247)




- Push the crankshaft into the bearing seat and take off the special tool.
- Grease the shaft seal rings of the balancer shaft.
- Push the balancer shaft ❸ into the bearing seat and take off the special tool.
- ✓ Align marks A and B.
- Mount stop disk ❹.

Installing left engine case



- Mount the dowels.
- Mount the O-ring ❶.
- Degrease the sealing area. Apply the sealing compound to the left engine case half.

Loctite® 5910



- Put on the left engine case half. If necessary, tap lightly with a rubber mallet and turn the transmission shafts.

**Info**

Do not tighten the engine case sections using the screws.

- Install the screws ❷ and tighten them diagonally.


Guideline

Screw, engine case	M6	10 Nm (7.4 lbf ft)
--------------------	----	--------------------


**Info**

Install the screw in the oil filter housing with a new copper washer.

Installing oil pumps



- Install pins and internal rotors on both oil pump shafts.
- Mount external rotors in the engine case.
 - ✓ The marking is not visible after mounting.
- Mount the oil pump shafts ① with internal rotors ②.
 - ✓ The marking A is visible after mounting.
- Oil the parts.




- Position both oil pump covers ③. Mount and tighten the screws.

Guideline


Screw, oil pump cover	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
-----------------------	----	----------------------	---------------

- Install washers ④ and pins ⑤.



- Mount the oil pump gears ⑥, washers ⑦ and lock washers ⑧.

Installing locking lever




- Position locking lever ① with sleeve and spring ②.
- Mount and tighten screw ③.

Guideline

Screw, locking lever	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
----------------------	----	-----------------------	---------------

Installing shift drum locating




- Press locking lever ① down and position shift drum locating.



Info

The flat surfaces A of the shift drum locating are not symmetric.




300067-11

- Release the locking lever.
- Mount and tighten screw ②.

Guideline

Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
----------------------------	----	-----------------------	---------------


Installing shift shaft



300066-11


- Slide shift shaft ① with the washer into the bearing seat.
- Push sliding plate ② away from the shift drum locating ③. Insert the shift shaft all the way.
- Let the sliding plate engage in the shift drum locating.
- Shift through the transmission.

Installing starter drive



300065-11


- Install the two needle bearings ① and the woodruff key ②.
- Push on the freewheel gear ③.



300064-11

- Push on the starter idler gear ④ with washer. Mount lock ring.
- Push on the needle bearing and torque limiter ⑤ with washer. Mount lock ring.

Installing primary gear



300063-10


- Ensure that the spring washer is seated properly.
- Mount primary gear ①.




Info

Turn the freewheel gear backwards and forwards to ease meshing.

Installing clutch cage



- Install supporting plate ❶ and needle bearing ❷.



- Install the clutch cage ❸.



Info
Turn the clutch cage and oil pump gear wheels backwards and forwards slightly to help them mesh more easily.

- Mount the half washers with the sharp edge facing outward.




Info
Grease the half washers to ease assembly.

- Position the stepped washer with the cut-out towards the half washers.
- Insert the clutch package ❹ in the clutch cage.



Info
If necessary, turn the main shaft a little to ease access.
Make sure that the upper clutch disc is offset by one notch.



- Position a new lock washer and install the nut ❺.
 - Lock the clutch cage and primary gear using the special tool, and tighten the nut.
- Guideline

Nut, inner clutch hub	M20x1.5	100 Nm (73.8 lbf ft)	Loctite® 243™
-----------------------	---------	-------------------------	---------------

Gear segment (75029081000) (☛ p. 252)



Info
Make sure that the crankshaft is not blocked.



- Secure the nut with the lock washer ❻.
- Lock the clutch cage and primary gear using the special tool.


Gear segment (75029081000) (☛ p. 252)

- Mount and tighten the nut ❼.


Guideline

Nut, primary gear	M20LHx1.5	90 Nm (66.4 lbf ft)	Loctite® 243™
-------------------	-----------	------------------------	---------------





- Insert the pressure piece 8.




- Place the pressure cap on.
- Install and tighten the screws 9 with the spring retainers and clutch springs.

Guideline

Screw, clutch spring	M5	6 Nm (4.4 lbf ft)
----------------------	----	-------------------

- Remove the special tool.

Installing crankshaft position sensor




- Position the crankshaft position sensor 1.
- Mount screws but do not tighten them yet.

Guideline

Screw, ignition pulse generator	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
---------------------------------	----	--------------------	---------------

- Position the cable and push the cable support sleeve 2 into the engine case.

Installing timing chain and timing chain sprocket




- Heat the timing chain sprocket and push it immediately on to the crankshaft.

Guideline

100 °C (212 °F)

- Mount lock ring 1.




- Thread the timing chain 2 in and lay it over the timing chain sprocket.



Info

If the timing chain is not new, pay attention to the direction of travel.

Installing timing chain rails




- Position the timing chain securing guide ❶.



Info

The cable of the crankshaft position sensor must be laid in the cable channel of the timing chain securing guide.

- Thread in the timing chain tensioning rail ❷ from above. Insert the support bushing into the timing chain securing guide.



- Thread in the timing chain guide rail ❸ from above. Insert the support bushing into the timing chain securing guide.
- Mount and tighten screws ❹.

Guideline

Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain tensioning rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™




Info

Ensure that there is no thread locking material at the collar of the screw; otherwise, the timing chain tension rail could lock and break.

- Check both timing chain rails for freedom of motion.

Installing rotor



- Ensure that the spring washer ❶ is seated properly.
- Degrease the cone of the crankshaft and the rotor.
- Mount the rotor.




Info

Make sure that the crankshaft is not blocked.

- Use the special tool to hold the rotor tight.

Holding spanner (75029091000) (☞ p. 253)




- Mount the tab washer and the nut ❷. Tighten nut.

Guideline

Rotor nut	M18x1.5	100 Nm (73.8 lbf ft)
-----------	---------	-------------------------

Adjusting crankshaft position sensor distance



- Adjust the distance between the crankshaft position sensor ❶ and the conductive element of the rotor using the special tool ❷.

Guideline

Crankshaft position sensor/rotor - distance	0.70 mm (0.0276 in)
---	---------------------


Feeler gauge (59029041100) (☞ p. 248)

- Fully tighten screws ❸.

Guideline

Screw, ignition pulse generator	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
---------------------------------	----	-----------------------	---------------


Setting engine to top dead center



- Set the crankshaft to top dead center and lock it with the special tool ❶.


Engine blocking screw (77329010000) (☞ p. 253)

Installing piston




- Shift the joint of the piston rings by 120°.
- Push the oiled piston into the special tool.


Piston assembly ring (75029015102) (☞ p. 249)



- Position the piston on the cylinder using the special tool.
- Push the piston carefully into the cylinder from above.
- ✓ The piston rings should not become caught; otherwise, they may be damaged.



- Ensure that piston marking ❶ faces the outfeed side.



- Apply a thin layer of sealing compound in area ❶.


Loctite® 5910

- Place the cylinder base gasket on.



Info

Make sure the grooved pins are seated correctly.




- Cover the engine case opening with a cloth. Thread the timing chain through the chain shaft. Mount the piston pin.




Info

For clarity, the following steps are illustrated using a disassembled piston.




- Position the piston pin retainer.



- Insert the special tool and firmly press it toward the piston.
- Turn the special tool counterclockwise, thereby pressing the piston pin retainer into the groove.


Piston pin lock ring insert (75029035000) (☛ p. 250)

- Make sure that the piston pin retainer is seated correctly on both sides.



- Remove the cloth.
- Keep the timing chain tensioned. Push the cylinder down carefully and let the grooved pins engage.

Installing cylinder head



- Put on the cylinder head gasket.



Info

Make sure the grooved pins are seated correctly.

- Mount the cylinder head. Mount and tighten cylinder head screw ❶ with the washers.

Guideline

Cylinder head screw	M10	Tightening sequence: Tighten diagonally, beginning with the rear screw on the chain shaft. Step 1 15 Nm (11.1 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 45 Nm (33.2 lbf ft) Step 4 60 Nm (44.3 lbf ft)	Lubricated with engine oil
---------------------	-----	---	----------------------------

**Info**


Always use new cylinder head screws.

- Mount and tighten screws ②.

Guideline

Screw, cylinder head	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
----------------------	----	--------------------	---------------


Installing camshafts



- Lay the timing chain over the camshaft. Push the timing chain into the bearing seats. The middle drill hole of the camshaft ① and the drill hole of the cylinder head ② must be aligned.

**Info**

Make sure that the crankshaft is at top dead center.




- Position the camshaft support plate ③. Mount and tighten screw ④.

Guideline

Screw, camshaft support plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
-------------------------------	----	--------------------	---------------


Installing timing chain tensioner



- Insert the timing chain tensioner ①.
- Mount and tighten plug ② with the new seal ring.

Guideline

Plug, timing chain tensioner	M20x1.5	25 Nm (18.4 lbf ft)
------------------------------	---------	---------------------




- Remove screw 3 and use the special tool to push the timing chain tensioner toward the timing chain.
- Release device for timing chain tensioner (77329051000) (☞ p. 254)


- ✓ The timing chain tensioner unlocks.
- Mount and tighten screw 3.

Guideline		
Screw, unlocking of timing chain tensioner	M10x1	10 Nm (7.4 lbf ft)

Checking valve clearance



- Remove special tool 1.
- Crank the engine several times.
- Set the engine to ignition top dead center. (☞ p. 112)




- Check the valve clearance on all valves between the valve and the rocker arm using the special tool 2.


Guideline	
Valve play, cold	0.07... 0.13 mm (0.0028... 0.0051 in)
Feeler gauge (59029041100) (☞ p. 248)	

- » If valve clearance does not meet specifications:
 - Adjust the valve clearance. (☞ p. 160)


Adjusting valve clearance




- Remove screws 1.

 **Info**


Make sure that the crankshaft is at top dead center.




- Screw suitable screws 2 into the rocker arm shafts 3. Pull out the rocker arm shafts.
- Take off the rocker arm.



- Remove shims ❹ and set them down according to the installation position.
- Correct the shims as indicated by the results of the valve clearance check.
- Insert suitable shims.
- Position the rocker arms and push in the rocker arm shafts.

**Info**

Make sure that the tapped hole of the rocker arm shaft is positioned facing outwards.
The small drill hole and the flat surface must point upwards.




- Install and tighten the screws ❺ of the rocker arm shafts.

Guideline

Screw, rocker arm shaft	M6	12 Nm (8.9 lbf ft)
-------------------------	----	--------------------

- Check the valve clearance. (🔧 p. 160)

Installing spark plug




- Mount and tighten the spark plug ❶ using the special tool.

Guideline

Spark plug	M12x1.25	17 Nm (12.5 lbf ft)
------------	----------	------------------------


Spark plug wrench (75029172000) (🔧 p. 253)

Installing spacer and spring



- Install the spacer ❶ and spring ❷ of the shift shaft.

Installing clutch cover




- Mount the dowels. Put on the clutch cover seal.
- Position the clutch cover. Mount and tighten screws ❶.


Guideline

Screw, clutch cover	M6	10 Nm (7.4 lbf ft)
---------------------	----	--------------------

Mounting water pump cover



- Push on the shaped washer ❶.




- Attach the water pump wheel ❷. Mount and tighten screw ❸

Guideline

Screw, water pump wheel	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
-------------------------	----	-----------------------	---------------

Loctite® 243™			
---------------	--	--	--

- Lay on the water pump cover seal ❹.




- Put on the water pump cover ❺. Mount and tighten screws.

Guideline

Screw, water pump wheel	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
-------------------------	----	-----------------------	---------------

Installing thermostat




- Position the thermostat ❶ with the gasket.
✓ The drill hole A must face upward.
- Install the thermostat case ❷ with the radiator hose.
- Mount and tighten the screws.

Guideline

Screw, thermostat housing	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
---------------------------	----	-----------------------	---------------


Installing the oil filter



- Insert the oil filter ❶.
- Lubricate the O-ring of the oil filter cover. Install the oil filter cover ❷.
- Mount and tighten the screws.

Guideline

Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)	
-------------------------	----	-------------------	--




- Insert the oil filter ③.
- Lubricate the O-ring of the oil filter cover. Install the oil filter cover ④.
- Mount and tighten the screws.


Guideline

Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)
-------------------------	----	-------------------

Installing gear position sensor



- Mount the contact springs ① and contact bolt ②.
- ✓ The contact bolts are mounted with the flat side forward; the pointed sides face the sensor.
- Position O-ring ③.




- Install the gear position sensor ④.
- Position the ground wire ⑤.
- Mount and tighten the screws.

Guideline

Screw, gear sensor	M5	5 Nm (3.7 lbf ft)	Loctite® 243™
--------------------	----	-------------------	---------------


Installing the spacer



- Grease spacer ① in area A and O-ring ② before mounting.

Long-life grease (☛ p. 244)

- Position the O-ring in the cut-out of the spacer.




- Grease the shaft seal ring.


Long-life grease (☛ p. 244)

- Slide the spacer with the O-ring onto the countershaft with a twisting motion.
- ✓ The cut-out with the O-ring faces inward.
- ✓ The shaft seal ring rests against the spacer along its entire circumference.

Installing oil screens



- Push the oil screen with O-rings on to a pin wrench. Push the pin wrench through the opening into the drill hole of the opposite engine case wall and push the oil screen as far as possible into the engine case.



- Install the oil drain plug with magnet ❶ and a new seal ring and tighten it.


Guideline

Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
----------------------------	---------	------------------------

- Install and tighten the plug ❷ with O-rings.

Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------



- Position the oil screen ❸ with O-rings.
- Install and tighten the plug ❹ with O-rings.


Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------

Installing alternator cover



- Apply sealing compound lightly in the area of the cable support sleeve.
- Install the dowel ❶. Put on the alternator cover seal.



- Position the alternator cover.
- Mount and tighten screws ❷.


Guideline

Screw in alternator cover	M6	10 Nm (7.4 lbf ft)
---------------------------	----	--------------------

- Mount and tighten screw ❸.

Guideline

Screw, alternator cover (chain shaft through-hole)	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
---	----	-----------------------	---------------



- Remove special tool ④.


Engine blocking screw (77329010000) (☛ p. 253)

- Mount and tighten screw ⑤.

Guideline

Plug, crankshaft location	M8	20 Nm (14.8 lbf ft)
---------------------------	----	------------------------

Installing starter motor



- Grease O-ring. Mount the starter motor.


Long-life grease (☛ p. 244)

- Mount and tighten screws ①.

Guideline

Screw, starter motor	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
----------------------	----	-----------------------	---------------

Installing valve cover




- Put the valve cover in place with the seal. Mount and tighten screws ①.

Guideline

Screw, valve cover	M6	10 Nm (7.4 lbf ft)
--------------------	----	--------------------

Taking engine off universal mounting rack



- Remove the screw ① or the nut ②.
- Take the engine off the universal mounting rack.



Info


Have an assistant help you or use a crane.

Checking/rectifying the fluid level of the hydraulic clutch



Info

The fluid level rises with increasing wear of the clutch lining disc.
Do not use brake fluid.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.

Fluid level under top level of container	4 mm (0.16 in)
--	----------------



» If the level of the coolant does not meet specifications:


- Correct the fluid level of the hydraulic clutch.

Hydraulic fluid (15) (🔧 p. 243)

- Position the cover with the membrane. Mount and tighten the screws.

Draining the coolant

- **Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.




- Remove the engine guard. (🔧 p. 39)
- Stand the motorcycle upright.
- Place a suitable container under the engine.
- Remove screw ❶. Remove the radiator cap.
- Completely drain the coolant.
- Mount the screw ❶ with a new seal ring and tighten it.

Guideline

Plug, drain hole of water pump	M10x1	15 Nm (11.1 lbf ft)
--------------------------------	-------	------------------------


- Install the engine guard. (🔧 p. 39)

Filling the cooling system

- **Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Stand the motorcycle on its side stand on a horizontal surface.
- Remove radiator cap ❶.



- Refill the coolant.


Alternative 1

Coolant (🔧 p. 242)

Alternative 2

Coolant (mixed ready to use) (🔧 p. 242)

- Fill the radiator completely with coolant. Mount radiator cap ❶.



- Remove the cap from compensating tank ❷ and add coolant to the level shown in the figure.
- Mount the cap of the compensating tank.



Danger

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and run it until the 5th bar of the temperature indicator lights up.
- Switch off the engine and allow it to cool down.
- After the engine has cooled down, check the coolant level in the radiator and in the compensating tank again and add more coolant if necessary.

Checking the antifreeze and coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.



Warning

Danger of poisoning Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

Condition

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Remove the cap of the compensating tank ❶.
- Check antifreeze of coolant.

–25... –45 °C (–13... –49 °F)

- » If the antifreeze of the coolant does not meet specifications:
 - Correct the antifreeze of the coolant.

- Check the coolant level in the compensating tank.

The coolant level must be within the range shown in the figure.

- » If the coolant level does not meet specifications:
 - Correct the coolant level.

Alternative 1

Coolant (☞ p. 242)

Alternative 2

Coolant (mixed ready to use) (☞ p. 242)

- Mount the cap of the compensating tank.
- Screw off the radiator cap ❷.
- Check antifreeze of coolant.


–25... –45 °C (–13... –49 °F)

- » If the antifreeze of the coolant does not meet specifications:
 - Correct the antifreeze of the coolant.

- Check the coolant level in the radiator.

The radiator must be completely filled.

- » If the coolant level does not meet specifications:



- Correct the coolant level and find out the cause of the loss.

Alternative 1

Coolant (☛ p. 242)

Alternative 2

Coolant (mixed ready to use) (☛ p. 242)

- Mount the radiator cap.

Checking the coolant level**Warning**

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

**Warning**

Danger of poisoning Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.

Condition

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Check the coolant level in the compensating tank ❶.

The coolant level must be within the range shown in the figure.

- » If the coolant level does not meet specifications:
 - Correct the coolant level.

Alternative 1

Coolant (☛ p. 242)

Alternative 2

Coolant (mixed ready to use) (☛ p. 242)

- Screw off the radiator cap ❷ and check the coolant level in the radiator.

The radiator must be completely filled.

- » If the coolant level does not meet specifications:
 - Correct the coolant level and find out the cause of the loss.


Alternative 1

Coolant (☛ p. 242)


Alternative 2

Coolant (mixed ready to use) (☛ p. 242)

- Mount the radiator cap.



Oil circuit



400500-60

- | | |
|----|------------------------------|
| 1 | Oil screen |
| 2 | Force pump |
| 3 | Oil filter |
| 4 | Oil pressure regulator valve |
| 5 | Timing chain tensioner |
| 6 | Rocker arm shaft |
| 7 | Transmission |
| 8 | Clutch |
| 9 | Oil jet for piston cooling |
| 10 | Oil filter |
| 11 | Crankshaft |
| 12 | Oil screen |
| 13 | Suction pump |
| 7 | Transmission |

Checking the engine oil level




Info

The engine oil level must be checked when the engine is warm.

Condition

The engine is at operating temperature.

- Stand the motorcycle upright on a horizontal surface.



- Check the engine oil level.

**Info**

After switching off the engine, wait one minute before checking the level.

The engine oil must be between the lower and upper edge of the oil level viewer.

- » If the engine oil level is not at the specified level:
 - Add the engine oil. (☛ p. 175)

Checking the engine oil pressure

**Warning**

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.


**Warning**

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Remove screw ❶.



- Position the banjo bolt with the connector and sealing rings. Mount and tighten the banjo bolt.

Guideline

Banjo bolt	M10x1	8 Nm (5.9 lbf ft)
------------	-------	-------------------

Oil pressure adapter (77329006000) (☛ p. 253)

- Connect the pressure tester to the special tool without the T-plate.

Pressure testing tool (61029094000) (☛ p. 248)

- Check the engine oil level. (☛ p. 170)

**Danger**

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and let it run warm.

- Check the engine oil pressure.

Engine oil pressure	
Coolant temperature: $\geq 70^{\circ}\text{C}$ ($\geq 158^{\circ}\text{F}$) Engine speed: 1,500 rpm	≥ 0.4 bar (≥ 6 psi)
Coolant temperature: $\geq 70^{\circ}\text{C}$ ($\geq 158^{\circ}\text{F}$) Engine speed: 5,000 rpm	≥ 1.5 bar (≥ 22 psi)

- » If the specification is not reached:

- Change the oil filter. Check oil pumps for wear. Check that all oil holes are clear.
- Switch off the engine.



Warning

Danger of burns Some vehicle components get very hot when the machine is driven.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

- Remove the special tools.
- Mount and tighten screw ❶.

Guideline

Screw, unlocking of timing chain tensioner	M10x1	10 Nm (7.4 lbf ft)
--	-------	--------------------

- Check the engine oil level. (🔧 p. 170)

Changing the engine oil and filter, cleaning the oil screens



- Drain the engine oil. (🔧 p. 172)
- Remove the oil filter. (🔧 p. 173)
- Clean the oil screens. (🔧 p. 174)
- Install the oil filter. (🔧 p. 173)
- Fill up with engine oil. (🔧 p. 175)

Draining the engine oil



Warning

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

Drain the engine oil only when the engine is warm.



- Remove the engine guard. (🔧 p. 39)
- Place a suitable container under the engine.
- Remove the oil drain plug ❶ with the magnet and seal ring.
- Completely drain the engine oil.




- Thoroughly clean the oil drain plug with a magnet.
- Mount the oil drain plug with the magnet and seal ring and tighten it.

Guideline


Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
----------------------------	---------	------------------------

Removing the oil filter

**Warning**


Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

**Warning**


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Place a suitable container under the engine.
- Remove screws ❶. Remove the oil filter cover ❷ with the O-ring.
- Pull oil filter ❸ out of the oil filter housing.

Circlip pliers reverse (51012011000) (👉 p. 246)




- Remove screws ❹. Remove oil filter ❺ with the O-ring.
- Pull oil filter ❻ out of the oil filter housing.

Circlip pliers reverse (51012011000) (👉 p. 246)

- Completely drain the engine oil.
- Thoroughly clean the parts and sealing area.

Installing the oil filter






- Insert oil filters ❶ and ❷.
- Oil the O-rings of the oil filter cover. Fit the oil filter covers ❸ and ❹.
- Mount and tighten the screws.

Guideline


Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)
-------------------------	----	-------------------

Cleaning the oil screens


- **Warning**
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.
 - Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.
- **Warning**
Environmental hazard Hazardous substances cause environmental damage.
 - Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Place a suitable container under the engine.
- Remove plug 1 with oil screen 2 and the O-rings.




- Remove plug 3 with oil screen 4 and the O-rings.
- Completely drain the remaining engine oil.
- Thoroughly clean the parts and sealing area.



- Position oil screen 2 with the O-rings.
- Mount and tighten plug 1 with the O-ring.

Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------




- Position oil screen 4 with the O-rings.
- Mount and tighten plug 3 with the O-ring.

Guideline

Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
------------------	---------	------------------------

Filling up with engine oil

i Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove filler plug with O-ring ❶ from the clutch cover and add engine oil.

Engine oil	1.70 l (1.8 qt.)	Engine oil (SAE 10W/60) (00062010035) (☛ p. 242)	
		Alternative engine oil	Engine oil (SAE 10W/50) (☛ p. 242)

- Refit plug with O-ring ❶ and tighten it.


! Danger
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Install the engine guard. (☛ p. 39)
- Check the engine oil level. (☛ p. 170)

Adding engine oil

i Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove the oil filler plug with O-ring ❶ from the clutch cover and fill up with engine oil.

Engine oil (SAE 10W/60) (00062010035) (☛ p. 242)
Engine oil (SAE 10W/50) (☛ p. 242)

i Info
For optimal performance of the engine oil, do not mix different types of engine oil.
If appropriate, change the engine oil.


- Install and tighten the oil filler plug with O-ring ❶.

! Danger
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Check the engine oil level. (☛ p. 170)

Alternator - checking the stator winding



Condition
The stator is disconnected.
– Reinstall the fuel tank.

Stator winding, measurement I - check the resistance
– Measure the resistance between the specified points.
Stator, connector **EN** pin **1** – Stator, connector **EN** pin **2**



Alternator	
Resistance of stator winding at: 20 °C (68 °F)	≤ 1 Ω

- » If the displayed value is not equal to the setpoint value:
– Replace the stator.

Stator winding, measurement II - check the resistance
– Measure the resistance between the specified points.
Stator, connector **EN** pin **1** – Stator, connector **EN** pin **3**

Alternator	
Resistance of stator winding at: 20 °C (68 °F)	≤ 1 Ω

- » If the displayed value is not equal to the setpoint value:
– Replace the stator.




Stator winding - check for a short circuit to ground (terminal 31)
– Measure the resistance between the specified points.
Stator, connector **EN** pin **1** – Measuring point **Ground (-)**

Resistance	∞ Ω
------------	-----

- » If the displayed value is not equal to the setpoint value:
– Replace the stator.

Checking the spark plug connector



Condition
Spark plug connector cylinder 1 has been removed.
– Measure the resistance between the specified points.
Measuring point 1 – Measuring point 2

Spark plug connector	
Resistance at: 20 °C (68 °F)	4.3... 5.7 kΩ

- » If the specification is not reached:
– Change the spark plug connector.


Ignition coil - checking the secondary winding


Condition

Ignition coil cylinder 1 is disconnected.
Spark plug connector cylinder 1 has been removed.

- Remove the fuel tank.

Ignition coil cylinder 1 - check the secondary winding resistance


-  Measure the resistance between the specified points.
Ignition coil pin 2 (+) – Ignition coil pin 3



Ignition coil	
Resistance of secondary winding at: 20 °C (68 °F)	10.4... 15.6 kΩ

- » If the displayed value is not equal to the setpoint value:
 - Replace the ignition coil.

Checking the basic setting of the motor drive



Condition

The diagnostics tool is connected.

- Ensure that the locking cap ❶ was not opened.



Info

Sealing varnish ❷ on the screws should not be damaged.

- » If the sealing varnish is damaged:
 - Contact customer service.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Adjustment"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Checking the basic setting of the motor drive"**.
- Press **"Continue"**.
- Read the information page in the KTM diagnostics tool and use **"Continue"** to open the **"Check the throttle position sensor circuit A position"** menu.
- ✓ The motor drive moves the throttle valve to the basic position (completely closed).
- Determine the voltage value via the **"Test"** button.





Info

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

Basic position - voltage "THAD"	0.50... 0.54 V
--	----------------

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.
 - Adjust the basic setting of the motor drive. (🔧 p. 179)



- Use **"Continue"** to start the **"Checking the emergency position of the throttle valve"** menu.
- ✓ The motor drive moves the throttle valve to the emergency running position.
- Check the voltage value.




Info

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

Emergency running position - voltage "THAD"	0.70... 0.74 V
--	----------------

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.



- Adjust the basic setting of the motor drive. (☛ p. 179)
- Use **"Continue"** to start the **"Checking the position of the throttle grip sensor"** menu.
- ✓ The motor drive keeps the throttle valve in the emergency running position.
- Check the voltage value.

**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.



Throttle grip sensor	
Voltage "APAD"	0.70... 0.74 V

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.
 - Adjust the basic setting of the motor drive. (☛ p. 179)
- Close the menu with **"Continue"**.


Adjusting the basic setting of the motor drive

Condition

The diagnostics tool is connected.



- Remove the air filter box. (☛ p. 63)
- Disconnect the connector of the motor drive **DR 1**.
- Switch on the ignition by turning the ignition key to position **ON** ☉.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Adjustment"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Adjusting the basic setting of the motor drive"**.
- Press **"Continue"**.
- Read the information page in the KTM diagnostics tool and use **"Continue"** to open the **"Adjusting the position of the throttle position sensor in circuit A"** menu.



- Carefully close the throttle valve with your finger and hold it.
- Check the voltage value.

**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

Basic position - voltage "THAD"	0.50... 0.54 V
--	----------------

- » If the displayed value is not equal to the setpoint value:
 - Loosen screw ②.
 - Adjust the throttle position sensor circuit A ③ by turning to the specified value.
 - Tighten screws ②.
- Press **"Continue"**.
- Release the throttle valve.
- Open and close the throttle grip fully ten times.
- ✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Carefully close the throttle valve again with your finger and hold it.
- Check the voltage value.


**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

Basic position - voltage "THAD"	0.50... 0.54 V
--	----------------

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.
- Use **"Continue"** to start the **"Adjusting the emergency position of the throttle valve"** menu.
- Release the throttle valve.
- Fix screws ② with locking varnish.



- Check the voltage value.


**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

Emergency running position - voltage "THAD"	0.70... 0.74 V
--	----------------

- » If the displayed value is not equal to the setpoint value:
 - Screw off fuse cover ④.
 - Loosen nut ⑤.
 - Adjust the emergency running position by turning screw ⑥ to the specified value.
 - Tighten nut ⑤.
 - Mount and tighten fuse cover ④.



Loctite® 648™



Info
Tighten by hand only, do not use a tool.

- Press **"Continue"**.
- Open and close the throttle grip fully ten times.
✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A	
Emergency running position - voltage "THAD"	0.70... 0.74 V

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.
- Fix fuse cover ④ with locking varnish.



- Use **"Continue"** to start the **"Adjusting the position of the throttle grip sensor"** menu.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle grip sensor	
Voltage "APAD"	0.70... 0.74 V

- » If the displayed value is not equal to the setpoint value:
 - Loosen screws ⑦.
 - Adjust the accelerator position sensor ⑧ by turning to the specified value.
 - Tighten screws ⑦.
- Press **"Continue"**.
- Open and close the throttle grip fully ten times.
✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle grip sensor	
Voltage "APAD"	0.70... 0.74 V

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.



601136-10

- Fix screws ⑦ with locking varnish.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and, using **"Continue"**, start the **"ECU Reset"** menu.
 - ✓ The control unit is reset.
- Complete the procedure with **"Continue"**.
- Switch off the ignition by turning the ignition key to position **OFF** ⓧ.
- Plug in the connector of the motor drive **DR** ①.
- Switch to the main menu.
- Switch on the ignition by turning the ignition key to position **ON** ○.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- **"Read trouble code"** selected.
- Complete the procedure with **"Back"**.
- Select **"Delete trouble codes"**.
- Complete the procedure with **"Back"**.

**Danger**

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and perform an initialization run.

Guideline

Initialization run	15 min
--------------------	--------

Flashing the EFI control unit and/or the EPT control unit

Condition

The ignition is on.

The diagnostics tool is connected and running.

EFI control unit

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"ECU Flashing"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the safety instructions and create the necessary preliminary conditions.
- Confirm the instructions by clicking on **"OK"**.
- Press **"Select file"** and select a new mapping.

**Info****"The BLZ file and the exhaust system must match!"**

- Press the **"ECU flash process"** button.
- Read the prompt and confirm with **"OK"**.
 - ✓ The new mapping is loaded.
- Switch to the main menu.

EPT control unit

- Select model.



400687-60

- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"ECU Flashing"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the safety instructions and create the necessary preliminary conditions.
- Confirm the instructions by clicking on **"OK"**.
- Press **"Select file"** and select a new mapping.

**Info**

"The BLZ file and the exhaust system must match!"

- Press the **"ECU flash process"** button.
- Read the prompt and confirm with **"OK"**.
- ✓ The new mapping is loaded.

**Info**

Start the engine and perform an initialization run.

Requesting the enabling code

**Condition**

The changed EFI control unit and/or the EPT control unit is connected.
 The ignition is on.
 The diagnostics tool is connected and running.
 Flashing of the EFI control unit and/or the EPT control unit is completed.

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Change VIN - New identity"**.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and, using **"Continue"**, start the coding process.
- Overwrite the entry under **"Please enter VIN:"** with the new chassis number.

**Info**

For used control units, the chassis number programmed last is displayed.

- Press **"Continue"**.
- Select **"Code form"**.
- Press **"Print"**.
- ✓ The protocol is being printed out.
- Fill out the protocol and send to **"diagnostic@ktm.com"**.
- ✓ A response mail containing the enabling code arrives.

Coding the EFI control unit and/or EPT control unit

**Condition**

The ignition is on.

The diagnostics tool is connected and running.

Flashing of the EFI control unit and/or EPT control unit is completed.

For a used control unit

- Request the enabling code. (☛ p. 183)

EFI control unit

- Switch to the main menu.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Change VIN - New identity"**.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and using **"Continue"** start the coding process.
- Under **"Please enter VIN:"** enter the new VIN.

**Info**

For new control units, a sample VIN is displayed.

For used control units, the last programmed VIN is displayed.

- Press **"Continue"**.
- Select **"Code entry"**.
- **"Please enter the code"**
- Press **"Continue"**.
- ✓ The new VIN is written to the EFI control unit.
- Switch to the main menu.
- Select **"Show identification"**.
- Compare the old VIN to the new VIN.
- ✓ The new VIN is shown.

EPT control unit

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and using **"Continue"** start the coding process.
- Under **"Please enter VIN:"** enter the new VIN.

**Info**

For new control units, a sample VIN is displayed.

For used control units, the last programmed VIN is displayed.

- Press **"Continue"**.
- Select **"Code entry"**.
- **"Please enter the code"**
- Press **"Continue"**.
- ✓ The new VIN is transferred to the EPT control unit.

- Switch to the main menu.
- Select **"Show identification"**.
- Compare the old VIN to the new VIN.
 - ✓ The new VIN is shown.

Design	1-cylinder 4-stroke engine, water-cooled		
Displacement	654 cm ³ (39.91 cu in)		
Stroke	80 mm (3.15 in)		
Bore	102 mm (4.02 in)		
Compression ratio	11.8:1		
Control	OHC, 4 valves controlled via rocker arm, chain drive		
Valve diameter, intake	40 mm (1.57 in)		
Valve diameter, exhaust	34 mm (1.34 in)		
Valve play, cold	0.07... 0.13 mm (0.0028... 0.0051 in)		
Crankshaft bearing	2 roller bearings		
Conrod bearing	Needle bearing		
Piston pin bearing	Bronze bush		
Pistons	Forged light alloy		
Piston rings	1 L-ring, 1 tapered compression piston ring, 1 oil scraper ring		
Engine lubrication	Semi-dry sump lubrication with two rotor pumps		
Primary transmission	36:79		
Clutch	APTC™ Antihopping clutch in oil bath / hydraulically operated		
Gearbox	6-gears, claw-shifted		
Transmission ratio			
1st gear	14:35		
2nd gear	16:28		
3rd gear	21:28		
4th gear	21:23		
5th gear	23:22		
6th gear	23:20		
Mixture preparation	Electronic fuel injection		
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment		
Alternator	12 V, 224 W		
Spark plug	NGK LKAR 8AI - 9		
Spark plug electrode gap	0.9 mm (0.035 in)		
Cooling	Water cooling, permanent circulation of coolant by water pump		
Idle speed			
Coolant temperature: ≥ 70 °C (≥ 158 °F)	1,550... 1,650 rpm		
Starting aid	Electric starter, automatic decompressor		

Capacity - engine oil

Engine oil	1.70 l (1.8 qt.)	Engine oil (SAE 10W/60) (00062010035) (☞ p. 242)	
		Alternative engine oil	Engine oil (SAE 10W/50) (☞ p. 242)

Capacity - coolant

Coolant	1.20 l (1.27 qt.)	Coolant (☞ p. 242)	
		Coolant (mixed ready to use) (☞ p. 242)	

Camshafts - diameter, bearing pin	
Next to exhaust cam	≥ 39.95 mm (≥ 1.5728 in)
Next to inlet cam	≥ 17.96 mm (≥ 0.7071 in)
Valve spring	
Minimum length (without valve spring cap)	42.3 mm (1.665 in)
Valve spring cap - thickness	2.4... 2.5 mm (0.094... 0.098 in)
Valve - valve stem diameter	
Exhaust	≥ 5.93 mm (≥ 0.2335 in)
Intake	≥ 5.93 mm (≥ 0.2335 in)
Valve guide - diameter	
New condition	6.004... 6.016 mm (0.23638... 0.23685 in)
Wear limit	6.050 mm (0.23819 in)
Valve - sealing seat width	
Intake	1.60 mm (0.063 in)
Exhaust	2.00 mm (0.0787 in)
Valve - run-out	
On the valve plate	≤ 0.05 mm (≤ 0.002 in)
On the valve stem	≤ 0.05 mm (≤ 0.002 in)
Cylinder/cylinder head - sealing area distortion	≤ 0.10 mm (≤ 0.0039 in)
Cylinder - bore diameter	
Size I	102.000... 102.012 mm (4.01574... 4.01621 in)
Size II	102.013... 102.025 mm (4.01625... 4.01672 in)
Piston - diameter	
Size I	101.955... 101.965 mm (4.01397... 4.01436 in)
Size II	101.965... 101.975 mm (4.01436... 4.01476 in)
Piston/cylinder - mounting clearance	
New condition	0.035... 0.060 mm (0.00138... 0.00236 in)
Wear limit	0.10 mm (0.0039 in)
Piston ring - groove clearance	≤ 0.08 mm (≤ 0.0031 in)
Piston ring end gap	
Compression rings	≤ 0.80 mm (≤ 0.0315 in)
Oil scraper ring	≤ 1.00 mm (≤ 0.0394 in)
Piston - piston pin hole diameter	20.010... 20.020 mm (0.78779... 0.78819 in)
Piston pin - diameter	19.995... 20.004 mm (0.7872... 0.78756 in)
Connecting rod - axial clearance of lower conrod bearing	0.40... 0.60 mm (0.0157... 0.0236 in)
Connecting rod - radial clearance of lower conrod bearing	0.05 mm (0.002 in)
Crankshaft - axial clearance	0.15... 0.25 mm (0.0059... 0.0098 in)
Crankshaft run-out at bearing pin	≤ 0.10 mm (≤ 0.0039 in)
Balancer shaft axial clearance	0.05... 0.20 mm (0.002... 0.0079 in)
Clutch facing disc - thickness	≥ 2.5 mm (≥ 0.098 in)
Intermediate disk - thickness	≥ 1.35 mm (≥ 0.0531 in)
Clutch spring - length	31.5... 33.5 mm (1.24... 1.319 in)
Clutch cage - contact surface of clutch facing discs	≤ 0.5 mm (≤ 0.02 in)
Oil pressure regulator valve - minimum spring length	27.5 mm (1.083 in)
Oil pump	
Clearance between external rotor and engine case	≤ 0.20 mm (≤ 0.0079 in)
Clearance between external rotor and internal rotor	≤ 0.20 mm (≤ 0.0079 in)
Axial clearance	0.04... 0.08 mm (0.0016... 0.0031 in)
Engine oil pressure	
Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 1,500 rpm	≥ 0.4 bar (≥ 6 psi)
Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 5,000 rpm	≥ 1.5 bar (≥ 22 psi)

Main shaft axial clearance	0.10... 0.40 mm (0.0039... 0.0157 in)
Transmission shaft run-out	≤ 0.025 mm (≤ 0.00098 in)
Shift shaft - play in sliding plate/shift quadrant	0.40... 0.80 mm (0.0157... 0.0315 in)
Fuel pressure	
Under every load condition	3.3... 3.7 bar (48... 54 psi)

Oil hole plug	self-tapping	9 Nm (6.6 lbf ft)	Loctite® 243™
Screw, membrane fixation	M3	2.5 Nm (1.84 lbf ft)	Loctite® 243™
Hose clamp, intake flange	M4	1.5 Nm (1.11 lbf ft)	–
Oil jet, conrod lubrication	M4	2 Nm (1.5 lbf ft)	Loctite® 243™
Locking screw for bearing	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Screw, breather cover on valve cover	M5	3 Nm (2.2 lbf ft)	Loctite® 243™
Screw, clutch spring	M5	6 Nm (4.4 lbf ft)	–
Screw, cover plate for oil return line	M5	6 Nm (4.4 lbf ft)	–
Screw, gear sensor	M5	5 Nm (3.7 lbf ft)	Loctite® 243™
Screw, oil filter cover	M5	6 Nm (4.4 lbf ft)	–
Screw, oil pump cover	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Plug, vacuum connection	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw in alternator cover	M6	10 Nm (7.4 lbf ft)	–
Screw, alternator cover (chain shaft through-hole)	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, autodecompression	M6	3... 4 Nm (2.2... 3 lbf ft)	Loctite® 243™
Screw, axial lock of camshaft	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, camshaft support plate	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)	–
Screw, clutch slave cylinder	M6x20	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, clutch slave cylinder	M6x35	10 Nm (7.4 lbf ft)	–
Screw, cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, cylinder head	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, engine case	M6	10 Nm (7.4 lbf ft)	–
Screw, ignition pulse generator	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, locking lever	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, rocker arm shaft	M6	12 Nm (8.9 lbf ft)	–
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, shift lever	M6	10 Nm (7.4 lbf ft)	Loctite® 222
Screw, starter motor	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, stator bracket	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, thermostat housing	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, timing chain tensioning rail	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, valve cover	M6	10 Nm (7.4 lbf ft)	–
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)	–
Screw, water pump wheel	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Oil jet, piston cooling	M6x0.75	4 Nm (3 lbf ft)	Loctite® 243™
Plug, crankshaft location	M8	20 Nm (14.8 lbf ft)	–
Stud, exhaust flange	M8	10 Nm (7.4 lbf ft)	Loctite® 243™
Cylinder head screw	M10	Tightening sequence: Tighten diagonally, beginning with the rear screw on the chain shaft. Step 1 15 Nm (11.1 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 45 Nm (33.2 lbf ft) Step 4 60 Nm (44.3 lbf ft)	Lubricated with engine oil
Oil hole plug	M10x1	15 Nm (11.1 lbf ft)	Loctite® 243™
Plug, drain hole of water pump	M10x1	15 Nm (11.1 lbf ft)	–

Plug, oil bore for oil radiator	M10x1	15 Nm (11.1 lbf ft)	–
Screw, unlocking of timing chain tensioner	M10x1	10 Nm (7.4 lbf ft)	–
Spark plug	M12x1.25	17 Nm (12.5 lbf ft)	–
Coolant temperature sensor on cylinder head	M12x1.5	12 Nm (8.9 lbf ft)	–
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)	–
Oil pressure regulator valve plug	M12x1.5	20 Nm (14.8 lbf ft)	–
Plug, oil bore	M14x1.5	15 Nm (11.1 lbf ft)	Loctite® 243™
Engine case stud	M16x1.5	25 Nm (18.4 lbf ft)	Loctite® 243™
Rotor nut	M18x1.5	100 Nm (73.8 lbf ft)	–
Nut, engine sprocket	M20x1.5	60 Nm (44.3 lbf ft)	Loctite® 243™
Nut, inner clutch hub	M20x1.5	100 Nm (73.8 lbf ft)	Loctite® 243™
Nut, primary gear	M20LHx1.5	90 Nm (66.4 lbf ft)	Loctite® 243™
Plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)	–
Plug, timing chain tensioner	M20x1.5	25 Nm (18.4 lbf ft)	–
Plug, oil thermostat	M24x1.5	15 Nm (11.1 lbf ft)	–
Screw in alternator cover	M24x1.5	8 Nm (5.9 lbf ft)	–

Frame	Lattice frame made of chrome molybdenum steel tubing, powder-coated	
Fork	WP Suspension 4860 MXMA	
Shock absorber	WP Suspension 4618 with Pro-Lever deflector	
Suspension travel (690 Enduro)		
Front	250 mm (9.84 in)	
Rear	250 mm (9.84 in)	
Suspension travel (690 Enduro R)		
Front	275 mm (10.83 in)	
Rear	275 mm (10.83 in)	
Brake system		
Front	Disc brake with dual-piston brake caliper, floating	
Rear	Disc brake with single-piston brake caliper, floating	
Brake discs - diameter		
Front	300 mm (11.81 in)	
Rear	240 mm (9.45 in)	
Brake discs - wear limit		
Front	4.5 mm (0.177 in)	
Rear	3.5 mm (0.138 in)	
Tire air pressure, road, solo		
Front	1.8 bar (26 psi)	
Rear	1.8 bar (26 psi)	
Tire air pressure with passenger / fully loaded		
Front	2.0 bar (29 psi)	
Rear	2.2 bar (32 psi)	
Tire air pressure, offroad, single rider		
Front	1.5 bar (22 psi)	
Rear	1.5 bar (22 psi)	
Secondary drive ratio	15:45	
Chain	5/8 x 1/4" X-ring	
Steering head angle	63°	
Wheelbase (690 Enduro)	1,498±15 mm (58.98±0.59 in)	
Seat height unloaded (690 Enduro)	910 mm (35.83 in)	
Seat height unloaded (690 Enduro R)	930 mm (36.61 in)	
Ground clearance unloaded (690 Enduro)	300 mm (11.81 in)	
Ground clearance unloaded (690 Enduro R)	320 mm (12.6 in)	
Weight without fuel approx.	138.5 kg (305.3 lb.)	
Maximum permissible front axle load	150 kg (331 lb.)	
Maximum permissible rear axle load	200 kg (441 lb.)	
Maximum permissible overall weight	350 kg (772 lb.)	
Battery	YTZ10S	Battery voltage: 12 V Nominal capacity: 8.6 Ah maintenance-free
Fuse	58011109130	30 A
Fuse	75011088015	15 A
Fuse	75011088010	10 A

Lighting equipment

Headlight (690 Enduro)	H4 / socket P43t	12 V 60/55 W
Parking light	W5W / socket W2.1x9.5d	12 V 5 W
Instrument lights and indicator lamps	LED	
Turn signal	R10W / socket BA15s	12 V 10 W
Brake/tail light (690 Enduro, 690 Enduro R EU, 690 Enduro R AUS/UK)	LED	
Brake/tail light (690 Enduro R USA)	P21/5W / socket BAY15d	12 V 21/5 W
License plate lamp	W5W / socket W2.1x9.5d	12 V 5 W

Validity	Front tire	Rear tire
(690 Enduro)	90/90 - 21 M/C 54H TL Metzeler Enduro 3 Sahara	140/80 - 18 M/C 70H TL Metzeler Enduro 3 Sahara
(690 Enduro R USA)	90/90 - 21 M/C 54R TT Pirelli MT 21 RALLYCROSS	140/80 - 18 M/C 70R TT Pirelli MT 21 RALLYCROSS
Additional information is available in the Service section under: http://www.ktm.com		

Capacity - fuel

Total fuel tank capacity, approx.	12 l (3.2 US gal)	Super unleaded (ROZ 95 / RON 95 / PON 91) (☛ p. 243)
Fuel reserve, approx.	2.5 l (2.6 qt.)	

690 Enduro

Fork part number	14.18.7E.11
Fork	WP Suspension 4860 MXMA
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring length with preload spacer(s)	472 mm (18.58 in)
Spring rate	
Soft	5.2 N/mm (29.7 lb/in)
Medium (standard)	5.4 N/mm (30.8 lb/in)
Hard	5.6 N/mm (32 lb/in)
Air chamber length	120±20 mm (4.72±0.79 in)
Fork length	890 mm (35.04 in)
Fork oil per fork leg	620 ml (20.96 fl. oz.)
Fork oil (SAE 5) (☛ p. 243)	

690 Enduro R

Fork part number	14.18.7E.41
Fork	WP Suspension 4860 MXMA
Compression damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring length with preload spacer(s)	495 mm (19.49 in)
Spring rate	
Medium (standard)	5.2 N/mm (29.7 lb/in)
Air chamber length	100 ⁺⁰ ₋₂₀ mm (3.94 ⁺⁰ _{-0.79} in)
Fork length	915 mm (36.02 in)
Fork oil per fork leg	635 ml (21.47 fl. oz.)
Fork oil (SAE 5) (☛ p. 243)	

690 Enduro

Shock absorber part number	15.18.7E.11
Shock absorber	WP Suspension 4618 with Pro-Lever deflector
Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn
Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring preload	20 mm (0.79 in)
Spring rate	
Medium (standard)	80 N/mm (457 lb/in)
Spring length	220 mm (8.66 in)
Gas pressure	10 bar (145 psi)
Static sag	25 mm (0.98 in)
Riding sag	70... 80 mm (2.76... 3.15 in)
Fitted length	395 mm (15.55 in)
Shock absorber fluid	Shock absorber oil (SAE 2,5) (50180342S1) (☛ p. 243)

690 Enduro R

Shock absorber part number	15.18.7E.41
Shock absorber	WP Suspension 4618 with Pro-Lever deflector
Compression damping, high-speed	
Comfort	2 turns
Standard	1.5 turns
Sport	1 turn
Full payload	1 turn
Compression damping, low-speed	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Rebound damping	
Comfort	20 clicks
Standard	15 clicks
Sport	10 clicks
Full payload	10 clicks
Spring preload	20 mm (0.79 in)
Spring rate	
Medium (standard)	80 N/mm (457 lb/in)
Spring length	220 mm (8.66 in)
Gas pressure	10 bar (145 psi)

Static sag	25 mm (0.98 in)
Riding sag	70... 80 mm (2.76... 3.15 in)
Fitted length	405 mm (15.94 in)
Shock absorber fluid	Shock absorber oil (SAE 2,5) (50180342S1) (🔍 p. 243)

Screw, combination instrument	EJOT	1 Nm (0.7 lbf ft)	–
Screw, combination instrument holder	EJOT	1 Nm (0.7 lbf ft)	–
Screw, license plate holder, bottom	EJOT	3 Nm (2.2 lbf ft)	–
Screw, SLS valve	EJOT	2 Nm (1.5 lbf ft)	–
Remaining screws, chassis	M4	4 Nm (3 lbf ft)	–
Spoke nipple, front wheel	M4.5	5 Nm (3.7 lbf ft)	–
Bolt, foot brake lever stub	M5	6 Nm (4.4 lbf ft)	Loctite® 243™
Rear fairing screw	M5	2 Nm (1.5 lbf ft)	–
Remaining screws, chassis	M5	4 Nm (3 lbf ft)	–
Screw, electrical holder	M5	3 Nm (2.2 lbf ft)	–
Screw, exhaust heat shield	M5	8 Nm (5.9 lbf ft)	–
Screw, fuel level sensor	M5	3 Nm (2.2 lbf ft)	–
Screw, fuel pump	M5	6 Nm (4.4 lbf ft)	–
Screw, headlight mask	M5	5 Nm (3.7 lbf ft)	–
Screw, seat lock	M5	3 Nm (2.2 lbf ft)	Loctite® 222
Screw, side cover	M5	2 Nm (1.5 lbf ft)	–
Screw, side stand switch	M5	3 Nm (2.2 lbf ft)	–
Screw, starter cable on starter	M5	3 Nm (2.2 lbf ft)	–
Spoke nipple, rear wheel	M5	4 Nm (3 lbf ft)	–
Nut, foot brake cylinder screw	M6	10 Nm (7.4 lbf ft)	–
Remaining nuts, chassis	M6	15 Nm (11.1 lbf ft)	–
Remaining screws on fuel tank	M6	6 Nm (4.4 lbf ft)	–
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)	–
Screw, ball joint of push rod on foot brake cylinder	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, brake fluid reservoir of rear brake	M6	5 Nm (3.7 lbf ft)	–
Screw, front brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, ignition lock	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, magnetic holder on side stand	M6	10 Nm (7.4 lbf ft)	Loctite® 243™
Screw, radiator bracket	M6	5 Nm (3.7 lbf ft)	–
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)	Loctite® 243™
Screw, voltage regulator	M6	8 Nm (5.9 lbf ft)	–
Nut, manifold on cylinder head	M8	25 Nm (18.4 lbf ft)	Copper paste
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)	Loctite® 243™
Remaining nuts, chassis	M8	30 Nm (22.1 lbf ft)	–
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)	–
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)	–
Screw, connection lever on frame	M8	30 Nm (22.1 lbf ft)	–
Screw, exhaust clamp on main silencer	M8	25 Nm (18.4 lbf ft)	–
Screw, fork stub	M8	15 Nm (11.1 lbf ft)	–
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, front footrest bracket	M8	25 Nm (18.4 lbf ft)	–
Screw, fuel tank, bottom	M8	20 Nm (14.8 lbf ft)	–
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, handrail	M8	20 Nm (14.8 lbf ft)	–
Screw, license plate holder, top	M8	20 Nm (14.8 lbf ft)	–
Screw, main silencer holder	M8	25 Nm (18.4 lbf ft)	–
Screw, main silencer holder on fuel tank	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, rear footrest bracket	M8x16	25 Nm (18.4 lbf ft)	–
Screw, side stand bracket	M8	25 Nm (18.4 lbf ft)	–

Screw, spring holder on side stand bracket	M8	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, steering stem	M8	20 Nm (14.8 lbf ft)	Loctite® 243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)	–
Upper fuel tank screw	M8	20 Nm (14.8 lbf ft)	–
Engine carrying screw	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Remaining nuts, chassis	M10	50 Nm (36.9 lbf ft)	–
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)	–
Screw, bottom shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Screw, engine bearer on frame	M10	45 Nm (33.2 lbf ft)	–
Screw, foot brake lever	M10LH	25 Nm (18.4 lbf ft)	Loctite® 243™
Screw, handlebar support	M10	40 Nm (29.5 lbf ft)	–
Screw, side stand	M10	35 Nm (25.8 lbf ft)	Loctite® 243™
Screw, top shock absorber	M10	45 Nm (33.2 lbf ft)	Loctite® 243™
Lambda sensor	M12x1.25	24.5 Nm (18.07 lbf ft)	Copper paste
Screw, swingarm pivot	M12x1.75	80 Nm (59 lbf ft)	–
Nut, linkage lever on swingarm	M14x1.5	100 Nm (73.8 lbf ft)	–
Nut, linkage lever to rocker arm	M14x1.5	100 Nm (73.8 lbf ft)	–
Screw, bottom steering head	M20x1.5	60 Nm (44.3 lbf ft)	Loctite® 243™
Screw, top steering head	M20x1.5	10 Nm (7.4 lbf ft)	–
Screw, front wheel spindle	M24x1.5	40 Nm (29.5 lbf ft)	–
Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft)	–

Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- Never clean the vehicle with high-pressure cleaning equipment or a strong water-jet. The excessive pressure can penetrate electrical components, socket connects, throttle cables, and bearings, etc., and can damage or destroy these parts.

**Warning**

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period.
Avoid direct sunshine on the motorcycle during cleaning.

- Seal the exhaust system to keep water out.
- First remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a brush.

Motorcycle cleaner (☛ p. 245)

**Info**

Clean the vehicle using a soft sponge and warm water containing normal motorcycle cleaner.
If the vehicle was operated in road salt, clean it with cold water. Warm water enhances the corrosive effects of salt.

- After the motorcycle has been thoroughly cleaned with a gentle spray of water, it should be dried with compressed air and a cloth.

**Warning**

Danger of accidents Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

- After cleaning, ride the vehicle a short distance until the engine is warm, applying the brakes occasionally.

**Info**

The heat produced causes water at inaccessible locations in the engine and the brakes to evaporate.

- Push back the protection covers of the handlebar controls to allow any water that has penetrated to evaporate.
- After the motorcycle has cooled off, oil or grease all moving parts and bearings.
- Clean the chain. (☛ p. 78)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Cleaning and preserving materials for metal, rubber and plastic (☛ p. 244)

- Treat all painted parts with a mild paint polish.

High-luster polish for paint (☛ p. 244)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care agent.

Paint cleaner and polish for high-gloss and matte finishes, bare metal and plastic surfaces (☛ p. 245)

- To prevent electrical problems, treat electric contacts and switches with contact spray.

Contact spray (☛ p. 244)

- Oil the ignition/steering lock.

Universal oil spray (☛ p. 245)

Protective treatment for winter operation



Info

If you use the motorcycle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

If the vehicle was operated in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.

-
- Clean the motorcycle. (🔧 p. 198)
 - Treat the engine, the swingarm, and all other bare or galvanized parts (except brake discs) with a wax-based anti-corrosion substance.



Info

To prevent serious reduction of the braking efficiency, make sure no anti-corrosion substance gets on to the brake discs. After use on salted roads, clean the motorcycle thoroughly with cold water and dry it properly.

-
- Clean the chain. (🔧 p. 78)

Storage



Info

If you want to garage the motorcycle for a longer period, take the following actions.

Before storing the motorcycle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.

- Make sure the tank is as empty as possible so that you can fill up with fresh fuel when you put the motorcycle back into operation.
- Clean the motorcycle. (🔧 p. 198)
- Change the engine oil and filter, clean the oil screens. (🔧 p. 172)
- Check the antifreeze and coolant level. (🔧 p. 168)
- Check the tire air pressure. (🔧 p. 73)
- Remove the battery. (🔧 p. 81)
- Recharge the battery. (🔧 p. 82)

Guideline

Storage temperature of battery without direct sunshine.	0... 35 °C (32... 95 °F)
---	--------------------------

- The storage place should be dry and not subject to large temperature differences.



Info

KTM recommends jacking up the motorcycle.

- Raise the motorcycle with the lift stand. (🔧 p. 9)
- Cover the motorcycle with a porous sheet or blanket.



Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and exhaust system to rust.

Putting into operation after storage

- Remove the motorcycle from the lift stand. (🔧 p. 9)
- Recharge the battery. (🔧 p. 82)
- Install the battery. (🔧 p. 81)
- Set the clock. (🔧 p. 96)
- Refuel.
- Carry out checks before putting into operation.
- Make a test ride.

Service schedule


	K10N	K50A	K100A	K300A
Check that the electrical equipment is functioning correctly.	•	•	•	•
Read out the fault memory using the KTM diagnostics tool.	•	•	•	•
Change the engine oil and filter, clean the oil screens. (🔧 p. 172)	•	•	•	•
Check the front brake linings. (🔧 p. 86)	•	•	•	•
Check the rear brake linings. (🔧 p. 90)	•	•	•	•
Check the brake discs. (🔧 p. 74)	•	•	•	•
Check the brake lines for damage and leakage.	•	•	•	•
Check the rear brake fluid level. (🔧 p. 93)	•	•	•	•
Check the free travel of the foot brake lever. (🔧 p. 92)	•	•	•	•
Lubricate the linkage of the rear wheel suspension.				•
Check that the shock absorber and fork are leak tight. If necessary and depending on use, service the fork and shock absorber.	•	•	•	•
Check the swingarm bearing.		•	•	•
Check the wheel bearing for play.		•	•	•
Check the tire condition. (🔧 p. 73)	•	•	•	•
Check the tire air pressure. (🔧 p. 73)	•	•	•	•
Check the spoke tension. (🔧 p. 79)	•	•	•	•
Check for rim run-out.	•	•	•	•
Check the chain, rear sprocket and engine sprocket. (🔧 p. 77)		•	•	•
Check the chain tension. (🔧 p. 76)	•	•	•	•
Grease all moving parts (e.g. side stand, hand lever, chain, ...) and check for smooth operation.	•	•	•	•
Clean the dust boots of the fork legs. (🔧 p. 13)		•	•	•
Check the front brake fluid level. (🔧 p. 88)	•	•	•	•
Bleed the fork legs. (🔧 p. 13)		•	•	•
Check the steering head bearing play. (🔧 p. 35)	•	•	•	•
Change the spark plug.			•	•
Check the valve clearance.			•	•
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and bellows for cracking, leaks, and correct routing.			•	•
Check the antifreeze and coolant level. (🔧 p. 168)	•	•	•	•
Check the cables for damage and routing without sharp bends.		•	•	•
Check that the throttle cables are undamaged, routed without sharp bends and set correctly.	•	•	•	•
Change the air filter. Clean the air filter box.		•	•	•
Check/rectify the fluid level of the hydraulic clutch. (🔧 p. 166)		•	•	•
Check the screws and nuts for tightness.	•	•	•	•
Change the coolant.				•
Change the front brake fluid. (🔧 p. 89)			•	•
Change the rear brake fluid. (🔧 p. 94)			•	•
Check the clutch.			•	•
Check the headlight setting. (🔧 p. 98)	•	•	•	•
Check that the radiator fan is functioning properly.	•	•	•	•
Final check: Check the vehicle for roadworthiness and take a test ride.	•	•	•	•
Read out the fault memory using the KTM diagnostics tool after a test ride.	•	•	•	•
Make the service entry in KTM DEALER.NET and in the service record.	•	•	•	•

K10N: Once after 1,000 km (621.4 mi)


K50A: Every 5,000 km (3,107 mi) or annually

K100A: Every 10,000 km (6,214 mi) or every 2 years


K300A: Every 30,000 km (18,641 mi) or every 4 years




A11	EFI control unit
F9	Fuse
G10	Battery
G20	Generator
K10	Starter relay with main fuse
K11	Start auxiliary relay
M10	Starter motor
T20	Voltage regulator
X291	Connector for accessory ground (terminal 31) ACC 1 (not assigned)
X292	Connector for accessory plus (terminal 30) ACC 1 (not assigned)




A11	EFI control unit
A12	EPT control unit
F1	Fuse
K12	Light relay
K30	Power relay
P10	Combination instrument
S11	Ignition/steering lock
S23	Emergency OFF switch, electric starter button
X295	Diagnostics connector




E13	Low beam, high beam
F6	Fuse
F7	Fuse
P10	Combination instrument
P15	Horn
P35	Parking light
S29	High beam/low beam switch, horn button, turn signal switch




B76	Front brake light switch
B77	Brake light switch, rear
E60	License plate lamp
P36	Brake/tail light



K20	Turn signal relay
P10	Combination instrument
P41	Turn signal, front left
P42	Turn signal, front right
P45	Turn signal, rear left
P46	Turn signal, rear right
S29	High beam/low beam switch, horn button, turn signal switch




B33	Temperature switch for radiator fan
F5	Fuse
F8	Fuse
M14	Radiator fan
X293	Connector for accessory ground (terminal 31) ACC 2 (not assigned)
X294	Connector for accessory plus (terminal 15) ACC 2 (not assigned)




A11	EFI control unit
A12	EPT control unit
F2	Fuse
F3	Fuse
F4	Fuse
M13	Fuel pump
M60	Motor drive
P10	Combination instrument
X295	Diagnostics connector

A11	EFI control unit
B51	Lambda sensor (cylinder 1)
B70	Front wheel speed sensor
M20	Fuel evaporation valve (USA version only)
M21	Secondary air valve
M51	Injector (cylinder 1)
P10	Combination instrument
R51	Ignition coil (cylinder 1)




A11	EFI control unit
B10	Throttle position sensor circuit A
B12	Intake air temperature sensor
B26	Rollover sensor
B30	Side stand switch
B31	Accelerator position sensor
B34	Gear position sensor
P10	Combination instrument


A11	EFI control unit
B13	Ambient air pressure sensor
B21	Engine coolant temperature sensor (cylinder 1)
B32	Fuel level indicator
B37	Crankshaft position sensor
B38	Clutch switch
B41	Manifold absolute pressure sensor (cylinder 1)
P10	Combination instrument
S55	Map-Select Switch
bl	Black
br	Brown
bu	Blue
gn	Green
gr	Gray
lbu	Light blue
or	Orange
pk	Pink
pu	Violet
rd	Red
wh	White
ye	Yellow




A11	EFI control unit
F9	Fuse
G10	Battery
G20	Generator
K10	Starter relay with main fuse
K11	Start auxiliary relay
M10	Starter motor
T20	Voltage regulator
X291	Connector for accessory ground (terminal 31) ACC 1 (not assigned)
X292	Connector for accessory plus (terminal 30) ACC 1 (not assigned)




A11	EFI control unit
A12	EPT control unit
F1	Fuse
K12	Light relay
K30	Power relay
P10	Combination instrument
S11	Ignition/steering lock
S23	Emergency OFF switch, electric starter button
X295	Diagnostics connector




E13	Low beam, high beam
F6	Fuse
F7	Fuse
P10	Combination instrument
P15	Horn
P35	Parking light
S29	High beam/low beam switch, horn button, turn signal switch
S36	Tripmaster switch (optional)




B76	Front brake light switch
B77	Brake light switch, rear
E60	License plate lamp
P36	Brake/tail light




K20	Turn signal relay
P10	Combination instrument
P41	Turn signal, front left
P42	Turn signal, front right
P45	Turn signal, rear left
P46	Turn signal, rear right
S29	High beam/low beam switch, horn button, turn signal switch



B33	Temperature switch for radiator fan
F5	Fuse
F8	Fuse
M14	Radiator fan
X293	Connector for accessory ground (terminal 31) ACC 2 (not assigned)
X294	Connector for accessory plus (terminal 15) ACC 2 (not assigned)




A11	EFI control unit
A12	EPT control unit
F2	Fuse
F3	Fuse
F4	Fuse
M13	Fuel pump
M60	Motor drive
P10	Combination instrument
X295	Diagnostics connector




690 Enduro R 09/10

A11	EFI control unit
B51	Lambda sensor (cylinder 1)
B70	Front wheel speed sensor
M20	Fuel evaporation valve (USA version only)
M21	Secondary air valve
M51	Injector (cylinder 1)
P10	Combination instrument
R51	Ignition coil (cylinder 1)



A11	EFI control unit
B10	Throttle position sensor circuit A
B12	Intake air temperature sensor
B26	Rollover sensor
B30	Side stand switch
B31	Accelerator position sensor
B34	Gear position sensor
P10	Combination instrument



A11	EFI control unit
B13	Ambient air pressure sensor
B21	Engine coolant temperature sensor (cylinder 1)
B32	Fuel level indicator
B37	Crankshaft position sensor
B38	Clutch switch
B41	Manifold absolute pressure sensor (cylinder 1)
P10	Combination instrument
S55	Map-Select Switch
bl	Black
br	Brown
bu	Blue
gn	Green
gr	Gray
lbu	Light blue
or	Orange
pk	Pink
pu	Violet
rd	Red
wh	White
ye	Yellow

Brake fluid DOT 4 / DOT 5.1**According to**

- DOT

Guideline

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Castrol** and **Motorex®** products.

Supplier**Castrol**

- **RESPONSE BRAKE FLUID SUPER DOT 4**

Motorex®

- **Brake Fluid DOT 5.1**

Coolant**Guideline**

- Use only suitable coolant (also in countries with high temperatures). Use of low-quality antifreeze can lead to corrosion and foaming. KTM recommends **Motorex®** products.

Mixture ratio

Antifreeze protection: -25... -45 °C (-13... -49 °F)	50 % corrosion inhibitor/antifreeze 50 % distilled water
--	---

Coolant (mixed ready to use)

Antifreeze	-40 °C (-40 °F)
------------	-----------------

Supplier**Motorex®**

- **Anti Freeze**

Engine oil (SAE 10W/60) (00062010035)**According to**

- JASO T903 MA (☛ p. 258)
- SAE (☛ p. 258) (SAE 10W/60)
- KTM LC4 2007+

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Synthetic engine oil

Supplier**Motorex®**

- **Motorex® KTM Cross Power 4T**

Engine oil (SAE 10W/50)**According to**

- JASO T903 MA (☛ p. 258)
- SAE (☛ p. 258) (SAE 10W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Fully synthetic engine oil

Supplier**Motorex®**

- **Power Synt 4T**

Fork oil (SAE 5)**According to**

- SAE (🔊 p. 258) (SAE 5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Racing Fork Oil**

Hydraulic fluid (15)**According to**

- ISO VG (15)

Guideline

- Use only hydraulic oil that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Hydraulic Fluid 75**

Shock absorber oil (SAE 2,5) (50180342S1)**According to**

- SAE (🔊 p. 258) (SAE 2,5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Super unleaded (ROZ 95 / RON 95 / PON 91)**According to**

- DIN EN 228 (ROZ 95 / RON 95 / PON 91)

Chain cleaner**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Chain Clean 611**

Cleaning and preserving materials for metal, rubber and plastic**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Protect & Shine 645**

Contact spray**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Accu Contact**

High-luster polish for paint**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Moto Polish**

Long-life grease**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Fett 2000**

Lubricant (T158)**Guideline**

- KTM recommends **Lubcon®** products.

Supplier**Lubcon®**

- **Turmogrease® PP 300**

Lubricant (T511)**Guideline**

- KTM recommends **Lubcon®** products.

Supplier**Lubcon®**

- **Turmsilon® GTI 300 P**

Lubricant (T159)**Guideline**

- KTM recommends **Bel-Ray®** products.

Supplier**Bel-Ray®**

- **MC-11®**

Lubricant (T625)**Guideline**

- KTM recommends **Molykote®** products.

Supplier

Molykote®

- **33 Medium**

Motorcycle cleaner**Guideline**

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Moto Clean 900**

Off-road chain spray**Guideline**

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Chain Lube 622**

Paint cleaner and polish for high-gloss and matte finishes, bare metal and plastic surfaces**Guideline**

- KTM recommends **Motorex®** products.

Supplier

Motorex®

- **Clean & Polish**


Universal oil spray**Guideline**

- KTM recommends **Motorex®** products.

Supplier


Motorex®

- **Joker 440 Universal**

Bearing puller

400037-01

Art. no.: 15112017000


Insert for bearing puller

400125-01

Art. no.: 15112018100


Feature

18... 23 mm (0.71... 0.91 in)

Bleed syringe


400058-01

Art. no.: 50329050000

Circlip pliers reverse

400059-01


Art. no.: 51012011000

Extractor

400073-01


Art. no.: 58429009000

Tool for inner bearing race




Art. no.: 58429037043

Mounting sleeve




Art. no.: 58529005000

Valve spring compressor




Art. no.: 59029019000

Limit plug gauge




Art. no.: 59029026006

Extractor




Art. no.: 59029033000

Feeler gauge




Art. no.: 59029041100

Hose clamp pliers




Art. no.: 60029057000

Pliers for spring-loaded band-type clamp




Art. no.: 60029057100

Testing hose




Art. no.: 61029093000

Pressure testing tool




Art. no.: 61029094000

Engine work stand




Art. no.: 61229001000

Work stand




Art. no.: 62529055000

Support for engine work stand




Art. no.: 75012001060

Holder for engine work stand




Art. no.: 75012001070

Piston assembly ring



Art. no.: 75029015102


Extractor



400157-01

Art. no.: 75029021000


Assembly screws



400158-01

Art. no.: 75029033000


Piston pin lock ring insert



400160-01

Art. no.: 75029035000


Work stand adapter



400161-01

Art. no.: 75029036000


Push-in drift



500163-01

Art. no.: 75029044010


Push-in drift



500162-01

Art. no.: 75029044020


Pressing device for crankshaft, complete



400185-01

Art. no.: 75029047000


Upper part, pressing-out tool



400186-01

Art. no.: 75029047050


Under part, pressing-out tool



400187-01

Art. no.: 75029047051


Extractor



400162-01


Art. no.: 75029048000

Clamping plate




Art. no.: 75029050000

Push-out drift




Art. no.: 75029051000

Floor jack attachment




Art. no.: 75029055000

Mounting sleeve




Art. no.: 75029080000

Gear segment




Art. no.: 75029081000

Protection cover




Art. no.: 75029090000

Holding spanner




Art. no.: 75029091000

Spark plug wrench




Art. no.: 75029172000

Oil pressure adapter




Art. no.: 77329006000

Engine blocking screw



Art. no.: 77329010000


Release device for timing chain tensioner



400181-01

Art. no.: 77329051000


Valve spring mounting device



500165-01

Art. no.: 78029060000


Hook wrench



301085-01

Art. no.: T106S

Depth micrometer



300577-10

Art. no.: T107S

Pin



201235-10

Art. no.: T120

Pressing tool



200583-10

Art. no.: T1206

Pressing tool



200585-01

Art. no.: T1207S

Vacuum pump



200273-10

Art. no.: T1240S

Pressing tool



200584-01

Art. no.: T129


Protecting sleeve



200635-10

Art. no.: T1401


Clamping stand



200733-10

Art. no.: T14015S

Clamping stand



200688-10

Art. no.: T14016S

Gripping tool



200639-10

Art. no.: T14026S1

Assembly tool



200634-10

Art. no.: T1402S

Open-end wrench



200640-10

Art. no.: T14032

Clamping stand



200637-10

Art. no.: T1403S


Mounting sleeve



300569-10

Art. no.: T1515

Nitrogen filling tool



300574-10

Art. no.: T170S1

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles– the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. With most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

A

Accessories	6
Air filter	
installing	63
removing	63
Air filter box	
fitting	64
removing	63
Alternator	
stator winding, checking	176
Antifreeze	
checking	168
Assembling the engine	
alternator cover, installing	164
camshafts, installing	159
clutch cage, installing	154
clutch cover, installing	161
crankshaft and balancer shaft, installing	151
crankshaft position sensor distance, adjusting	156
crankshaft position sensor, installing	155
cylinder head, installing	158
engine, setting to top dead center	157
gear position sensor, installing	163
left engine case, installing	151
locking lever, installing	152
oil filter, installing	162
oil pumps, installing	152
oil screens, installing	164
piston, installing	157
primary gear, installing	153
rotor, installing	156
shift drum locating, installing	152
shift shaft, installing	153
spacer, installing	163
spark plug, installing	161
starter drive, installing	153
starter motor, installing	165
taking engine off universal mounting rack	165
thermostat, installing	162
timing chain and timing chain sprocket, installing	155
timing chain rails, installing	156
timing chain tensioner, installing	159
transmission shafts, installing	150
valve clearance, adjusting	160
valve clearance, checking	160
valve cover, installing	165
water pump cover, mounting	162

B

Battery	
connecting	82
disconnecting	81
fitting	81
recharging	82
removing	81
Brake discs	
checking	74
Brake fluid	
front brake, adding	89

front brake, changing	89
rear brake, adding	93
rear brake, changing	94

Brake fluid level

front brake, checking	88
rear brake, checking	93

Brake linings

front brake, changing	86
front brake, checking	86
rear brake, changing	91
rear brake, checking	90

C**Cartridge**

of fork legs, disassembling	20
of the fork legs, assembling	26

Chain

checking	77
cleaning	78

Chain guide

adjusting	77
-----------------	----

Chain tension

adjusting	76
checking	76

Charging voltage

checking	83
----------------	----

Chassis number

.....	7
-------	---

Clutch

checking/correcting fluid level	166
---------------------------------------	-----

Combination instrument

clock, setting	96
setting kilometers or miles	96
TRIP 1 display, setting/resetting	97
TRIP 2 display, setting/resetting	97
wheel circumference, setting	98

Coolant

draining	167
----------------	-----

Coolant level

checking	168-169
----------------	---------

Cooling system

filling	167
---------------	-----

Cylinder - Nikasil® coating

.....	128
-------	-----

D**Disassembling the engine**

alternator cover, removing	111
camshafts, removing	114
clutch cage, removing	116
clutch cover, removing	113
crankshaft and balancer shaft, removing	120
crankshaft position sensor, removing	116
cylinder head, removing	114
engine into engine work stand, clamping	110
engine oil, draining	110
engine, setting to ignition top dead center	112
gear position sensor, removing	111
left engine case, removing	119
locking lever, removing	119
oil filter, removing	111

oil pumps, removing	119
piston, removing	114
primary gear, removing	118
rotor, removing	115
shift drum locating, removing	118
shift shaft, removing	118
spacer and spring, installing	161
spacer and spring, removing	113
spacer, removing	111
spark plug, removing	113
starter drive, removing	118
starter motor, removing	110
thermostat, removing	112
timing chain and timing chain sprocket, removing	116
timing chain rails, removing	115
timing chain tensioner, removing	114
transmission shafts, removing	120
valve cover, removing	110
water pump wheel, removing	112

E**EFI control unit**

coding	184
flashing	182

Enabling code

requesting	183
------------	-----

Engine

fitting	106
removing	104

Engine - Work on individual parts

antihopping clutch, dismantling	137
antihopping clutch, preassembling	139
autodecompressor	131
axial clearance of crankshaft and balancer shaft, measuring	128
balancer shaft drive wheel, installing	127
balancer shaft drive wheel, removing	125
camshaft bearing, changing	133
clutch cover	124
clutch, checking	138
countershaft, assembling	146
countershaft, dismantling	142
crankshaft bearing inner ring, installing	127
crankshaft bearing inner ring, removing	125
crankshaft run-out at bearing pin, checking	127
cylinder - Nikasil® coating	128
cylinder head, checking	135
cylinder, checking/measuring	129
electric starter drive, checking	147
freewheel, checking	148
freewheel, installing	149
freewheel, removing	148
left engine case section	123
main shaft, assembling	145
main shaft, disassembling	141
oil pumps for wear, checking	131
piston ring end gap, checking	130
piston, checking/measuring	129
piston/cylinder mounting clearance, checking	131
right engine case section	122
rocker arm, installing	137

rocker arm, removing	133
shift mechanism, checking	140
shift shaft, preassembling	140
the conrod bearing, changing	125
timing assembly, checking	133
timing chain tensioner, preparing for installation	132
transmission, checking	143
valve spring retainer, checking	135
valve springs, checking	135
valves, checking	135
valves, installing	136
valves, removing	134

Engine characteristic

adjusting	85
-----------	----

Engine guard

installing	39
removing	39

Engine number

7

Engine oil

adding	175
changing	172
draining	172
refilling	175

Engine oil level

checking	170
----------	-----

Engine oil pressure

checking	171
----------	-----

Engine sprocket

checking	77
----------	----

EPT control unit

coding	184
flashing	182

Exhaust manifold

fitting	59
removing	59

F**Filler cap**

closing	66
opening	66

Foot brake lever

basic position, adjusting	92
free travel, checking	92

Fork

compression damping, adjusting	12
dust boots, cleaning	13
fork legs, bleeding	13
rebound, adjusting	12

Fork legs

assembling	27, 31
cartridge, assembling	26
cartridge, disassembling	20
checking	23-24
dismantling	18
fitting	16
fork, servicing	17
removing	15
tap compression, assembling	25
tap compression, disassembling	22

Fork part number	8	Oil screens	
Fork protector		cleaning	172, 174
positioning	14	P	
remove	14	Parking light bulb	
Front wheel		changing	101
installing	72	Play in throttle cable	
removing	72	adjusting	38
Fuel filter		checking	37
changing	68	Protective treatment for winter operation	199
Fuel pressure		Putting into operation	
checking	67	after storage	200
Fuel, oils, etc.	6	R	
Fuse		Rear hub rubber dampers	
of individual power consumer, changing	84	checking	79
H		Rear sprocket	
Hand brake lever		checking	77
free travel, adjusting	88	Rear wheel	
free travel, checking	88	installing	75
Handlebar position	37	removing	75
adjusting	37	Riding sag	
Headlight		adjusting	43
light range, adjusting	99	Rim run-out	
Headlight bulb, changing	102	checking	80
Headlight mask with headlight		S	
installing	100	Seat	
removing	99	mounting	66
Headlight setting, checking	98	removing	66
I		Service schedule	201
Ignition coil		Servicing the fork	17
secondary winding, checking	177	Servicing the shock absorber	46
K		Shock absorber	
Key number	7	compression damping, high-speed, adjusting	40
M		compression damping, low-speed, adjusting	40
Main fuse		damper, assembling	53
changing	83	damper, bleeding and filling	55
Main silencer		damper, checking	49
fitting	61	damper, dismantling	47
removing	60	damper, filling with nitrogen	57
Motor drive		heim joint, installing	51
basic setting, checking	178	heim joint, removing	50
basic settings, adjusting	179	installing	45
Motorcycle		piston rod, assembling	52
cleaning	198	piston rod, disassembling	48
raising with lift stand	9	rebound damping, adjusting	41
raising with work stand	9	removing	44
removing from lift stand	9	riding sag, checking	42
removing from work stand	10	shock absorber, servicing	46
O		spring preload, adjusting	43
Oil circuit	170	spring, installing	58
Oil filter		spring, removing	46
changing	172	static sag, checking	42
installing	173	Shock absorber part number	8
removing	173	Side cover	
		mounting	67
		removing	67
		Spare parts	6

Spark plug connector	
checking	176
Spoke tension	
checking	79
Starting	10
Starting procedure	
for making checks	11
Steering head bearing play	
adjusting	35
checking	35
Storage	200

T

Tap compression	
of fork legs, disassembling	22
of the fork legs, assembling	25
Technical data	
chassis	191-192
chassis tightening torques	196-197
engine	186
engine - tolerance, wear limits	187-188
engine tightening torques	189-190
fork	193
shock absorber	194-195
Tire air pressure	
checking	73
Tire condition	
checking	73
Turn signal bulb	
changing	103
Type label	7

W

Warranty	6
Wiring diagram	202-241
page 1 of 10	202, 222
page 10 of 10	220, 240
page 2 of 10	204, 224
page 3 of 10	206, 226
page 4 of 10	208, 228
page 5 of 10	210, 230
page 6 of 10	212, 232
page 7 of 10	214, 234
page 8 of 10	216, 236
page 9 of 10	218, 238
Work rules	6



3206076en



02/2010 Photo: Mitterbauer



KTM-Sportmotorcycle AG
5230 Mattighofen/Austria
<http://www.ktm.com>